

Operating instructions Compax3 Fluid T40: Cam

Hydraulics controller



Autoryzowany dystrybutor Parker:

**ARA**

**PNEUMATIK**

53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)



Release R08-0

192-121102 N04

June 2008



Windows NT®, Windows 2000™, Windows XP™, Windows Vista are trademarks of Microsoft Corporation.

## Nonwarranty clause

We checked the contents of this publication for compliance with the associated hard and software. We can, however, not exclude discrepancies and do therefore not accept any liability for the exact compliance. The information in this publication is regularly checked, necessary corrections will be part of the subsequent publications.

## Production site:



Parker Hannifin GmbH & Co. KG  
 Electromechanical Automation Europe [EME]  
 Robert-Bosch-Strasse 22  
 77656 Offenburg (Germany)  
 Tel.: + 49 (0781) 509-0  
 Fax: + 49 (0781) 509-98176  
 Internet: [www.parker-automation.com](http://www.parker-automation.com) <http://www.parker-automation.com>  
 E-mail: [sales.automation@parker.com](mailto:sales.automation@parker.com) <mailto:sales.automation@parker.com>

Parker Hannifin GmbH & Co. KG - registered office: Bielefeld - Amtsgericht: Bielefeld HRA 14808  
 Personally liable shareholder: Parker Hannifin Management GmbH - Amtsgericht: Bielefeld HRB 35489  
 executive board: Dr. Gerd Scheffel, Günter Schrank, Christian Stein, Kees Veraart, Hans Wolfs - Chairman of the board: Hansgeorg Greuner

## Headquarters:

### England:

Parker Hannifin plc  
 Electromechanical Automation  
 Arena Business Centre  
 Holy Rood Close  
 Poole, Dorset BH17 7FJ UK  
 Tel.: +44 (0)1202 606300  
 Fax: +44 (0)1202 606301  
 E-mail:  
[sales.automation@parker.com](mailto:sales.automation@parker.com)  
<mailto:sales.automation@parker.com>  
 Internet:  
[www.parker-automation.com](http://www.parker-automation.com)  
<http://www.parker-automation.com>

### USA:

Parker Hannifin Corporation  
 Electromechanical Automation  
 5500 Business Park Drive  
 Rohnert Park, CA 94928  
 Phone #: (800) 358-9068  
 FAX #: (707) 584-3715  
 E-mail:  
[CMR\\_help@parker.com](mailto:CMR_help@parker.com)  
[mailto:emn\\_support@parker.com](mailto:emn_support@parker.com)  
 Internet:  
[www.compumotor.com](http://www.compumotor.com)  
<http://www.compumotor.com>

### Worldwide sales

[http://apps.parker.com/divapps/eme/EME/Contact\\_sites/Sales%20Channel\\_Parker-EME.pdf](http://apps.parker.com/divapps/eme/EME/Contact_sites/Sales%20Channel_Parker-EME.pdf)

# Contents

<b>1. Introduction.....</b>	<b>12</b>
<b>1.1 Device assignment Compax3 Fluid.....</b>	<b>12</b>
1.1.1. Type specification plate Compax3 Fluid.....	13
<b>1.2 Safety Instructions.....</b>	<b>14</b>
1.2.1. General hazards.....	14
1.2.2. Safety-conscious working.....	14
1.2.3. Special safety instructions.....	15
<b>1.3 Warranty conditions.....</b>	<b>15</b>
<b>1.4 Conditions of utilization for CE-conform operation.....</b>	<b>15</b>
<b>2. Positioning with IEC61131-3.....</b>	<b>17</b>
<b>3. Compax3F device description.....</b>	<b>21</b>
<b>3.1 State of delivery.....</b>	<b>21</b>
<b>3.2 Plug and connector assignment Compax3 Fluid.....</b>	<b>21</b>
3.2.1. Meaning of the front panel LEDs (via X10).....	21
3.2.2. Plug and connector assignment.....	22
3.2.3. Plug and connector assignment complete.....	23
3.2.4. Analog Input (plug X1).....	25
3.2.4.1 Wiring of the analog inputs.....	25
3.2.5. Analog Output (plug X2).....	26
3.2.5.1 Wiring of analog outputs.....	26
3.2.6. Voltage supply (plug X3).....	27
3.2.7. RS232 / RS485 interface (plug X10).....	27
3.2.8. Analog / Encoder (plug X11).....	28
3.2.8.1 Connections of the encoder interface.....	29
3.2.9. Digital inputs/outputs (plug X12).....	29
3.2.9.1 Connection of the digital Outputs/Inputs.....	30
3.2.10. Feedback (connector X13).....	30
3.2.10.1 Connections of the encoder interface.....	31
3.2.11. Profibus connector X23 with Interface I20.....	32
3.2.11.1 Adjusting the bus address.....	32
3.2.11.2 Function of the Bus LEDs.....	32
3.2.12. CANopen connector X23 Interface I21.....	33
3.2.12.1 Adjusting the bus address.....	33
3.2.12.2 Function of the Bus LEDs.....	34
3.2.13. DeviceNet connector X23.....	35
3.2.13.1 Adjusting the bus address.....	35
3.2.13.2 Function of the Bus LEDs.....	36
3.2.14. Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24.....	36
3.2.14.1 Set Ethernet Powerlink (option I30) bus address.....	37
3.2.14.2 Meaning of the Bus LEDs (Ethernet Powerlink).....	37
3.2.14.3 Meaning of the Bus LEDs (EtherCAT).....	38

3.2.15. Mounting and dimensions .....	40
---------------------------------------	----

## **4. Setting up Compax3.....41**

<b>4.1 Configuration .....</b>	<b>41</b>
4.1.1. <b>C3HydraulicsManager .....</b>	<b>44</b>
4.1.1.1 Function description .....	44
4.1.1.2 Structure of the databases .....	44
4.1.2. <b>Compax3F structure image .....</b>	<b>45</b>
4.1.3. <b>Drive configuration.....</b>	<b>46</b>
4.1.4. <b>Configuring drive1 .....</b>	<b>47</b>
4.1.4.1 Position feedback system drive1 .....	47
4.1.4.2 Cylinder / motor selection .....	48
4.1.4.3 Load configuration drive1 .....	48
4.1.5. <b>Configuring drive2.....</b>	<b>49</b>
4.1.6. <b>Sensors.....</b>	<b>49</b>
4.1.6.1 Pressure sensors .....	49
4.1.6.2 Force sensor drive 1 .....	50
4.1.6.3 Pressure and force sensor drive 2.....	51
4.1.7. <b>Valve configuration .....</b>	<b>51</b>
4.1.7.1 Selection and configuration of the valves .....	52
4.1.8. <b>Defining the reference system .....</b>	<b>53</b>
4.1.8.1 Position transducer .....	53
4.1.8.2 Machine Zero .....	54
4.1.8.3 Travel Limit Settings .....	70
4.1.8.4 Change assignment direction reversal / limit switches .....	74
4.1.8.5 Change initiator logic .....	74
4.1.8.6 Debouncing: Limit switch, machine zero and input 0 .....	74
4.1.9. <b>Ramp upon error and switch to currentless .....</b>	<b>74</b>
4.1.10. <b>Limit and monitoring settings of force.....</b>	<b>75</b>
4.1.10.1 Force window - force achieved .....	75
4.1.10.2 Maximum control deviation of force controller .....	76
4.1.10.3 Maximum force .....	76
4.1.10.4 Hydraulic corner power limitation.....	76
4.1.11. <b>Positioning window - Position reached.....</b>	<b>77</b>
4.1.12. <b>Following error limit .....</b>	<b>78</b>
4.1.13. <b>Maximum permissible speed.....</b>	<b>78</b>
4.1.14. <b>Encoder Simulation .....</b>	<b>79</b>
4.1.15. <b>Recipe table.....</b>	<b>80</b>
4.1.16. <b>Error response .....</b>	<b>80</b>
4.1.17. <b>Configuration name / comments.....</b>	<b>81</b>
<b>4.2 Configuring the signal source .....</b>	<b>82</b>
4.2.1. <b>Physical Source .....</b>	<b>82</b>
4.2.1.1 Encoder A/B 5V, step/direction or SSI feedback as signal source .....	82
4.2.1.2 +/-10V Master speed .....	85
4.2.2. <b>Internal virtual master .....</b>	<b>85</b>
4.2.3. <b>HEDA Master signal source.....</b>	<b>85</b>
<b>4.3 Optimization .....</b>	<b>87</b>
4.3.1. <b>Optimization window.....</b>	<b>88</b>
4.3.2. <b>Scope .....</b>	<b>89</b>
4.3.2.1 Monitor information .....	89
4.3.2.2 User interface.....	90



4.3.2.3	Example: Setting the Oscilloscope .....	95
<b>4.3.3.</b>	<b>Control Loop Dynamics .....</b>	<b>97</b>
4.3.3.1	Preparatory settings for the controller alignment.....	98
4.3.3.2	Signal filtering with external command value .....	102
4.3.3.3	Controller structure of main axis .....	105
4.3.3.4	Controller structure auxiliary axis.....	106
4.3.3.5	Feedforward main axis (status controller).....	107
4.3.3.6	Feedforward auxiliary axis (status controller) .....	108
4.3.3.7	Position controller main axis (status controller).....	109
4.3.3.8	Position controller auxiliary axis (status controller).....	113
4.3.3.9	Filter main axis.....	116
4.3.3.10	Filter auxiliary axis .....	117
4.3.3.11	Analog Input.....	118
4.3.3.12	Force-/Pressure Control main axis .....	123
4.3.3.13	Force-/Pressure Control auxiliary axis.....	127
4.3.3.14	Output signal conditioning 0 .....	131
4.3.3.15	Step-by-step optimization .....	138
<b>4.3.4.</b>	<b>Input simulation .....</b>	<b>147</b>
4.3.4.1	Calling up the input simulation.....	147
4.3.4.2	Functionality.....	148
<b>4.3.5.</b>	<b>Setup mode .....</b>	<b>149</b>
4.3.5.1	Motion objects in Compax3 .....	150
<b>4.3.6.</b>	<b>ProfileViewer for the optimization of the motion profile .....</b>	<b>150</b>
4.3.6.1	Mode 1: Time and maximum values are deduced from Compax3 input values.....	151
4.3.6.2	Mode 2: Compax3 input values are deduced from times and maximum values .....	151

## **5. Motion control..... 152**

<b>5.1</b>	<b>Programming based on IEC61131-3.....</b>	<b>152</b>
5.1.1.	Prerequisites .....	152
5.1.2.	CoDeSys / Compax3 target system (Target Package).....	153
5.1.2.1	Program development and test.....	153
5.1.2.2	Recipe management.....	154
5.1.3.	Languages supported .....	154
5.1.4.	Function range supported .....	154
5.1.4.1	Operators supported .....	154
5.1.4.2	Standard functions supported .....	155
5.1.4.3	Standard function modules supported .....	156
5.1.5.	Data types supported .....	157
5.1.6.	Retain Variables.....	157
5.1.7.	Recipe table with 9 columns and 32 lines.....	157
5.1.8.	Maximum program size.....	158
5.1.9.	Cycle time.....	158
5.1.10.	Access to the Compax3 object directory .....	158
5.1.11.	Compilation, debugging and down/upload of IEC61131 programs .....	159
5.1.12.	General rules / timing .....	160
5.1.13.	Library constants.....	161
<b>5.2</b>	<b>Status diagrams .....</b>	<b>162</b>
5.2.1.	Status diagram of Compax3F main axis .....	162
5.2.2.	Status diagram of Compax3F auxiliary axis .....	163
5.2.3.	Status diagram of the virtual master .....	164

<b>5.3</b>	<b>Control functions .....</b>	<b>165</b>
5.3.1.	Activation of the drive (MC_Power) .....	165
5.3.2.	Stop (MC_Stop) .....	166
5.3.2.1	MC_Stop at pressure/force control .....	167
5.3.2.2	MC_Stop: Example 1 .....	167
5.3.2.3	MC_Stop: Example 2 .....	168
5.3.3.	C3_SetControlMode .....	169
<b>5.4</b>	<b>Reading values .....</b>	<b>170</b>
5.4.1.	Reading the current position (MC_ReadActualPosition) .....	170
5.4.2.	Read access to the (C3_ReadArray) array .....	172
5.4.3.	Reading the device status (MC_ReadStatus) .....	173
<b>5.5</b>	<b>Determine valve/range parameters (C3_GetSystemFingerPrint).....</b>	<b>174</b>
5.5.1.	Important notes .....	176
5.5.2.	Procedure when working with the C3_getSystemFingerPrint .....	177
<b>5.6</b>	<b>Positioning functions (standard) .....</b>	<b>178</b>
5.6.1.	Value range for positioning parameters .....	178
5.6.2.	Absolute positioning (MC_MoveAbsolute) .....	179
5.6.2.1	Position mode in reset operation .....	182
5.6.2.2	Description of jerk .....	183
5.6.3.	Relative positioning (MC_MoveRelative) .....	184
5.6.4.	Additive positioning (MC_MoveAdditive) .....	186
5.6.5.	Continuous positioning (MC_MoveVelocity) .....	188
5.6.6.	Manual operation (C3_Jog) .....	190
5.6.7.	Homing (MC_Home) .....	192
5.6.8.	Electronic gearbox (MC_GearIn) .....	195
<b>5.7</b>	<b>Superimposed motion .....</b>	<b>198</b>
5.7.1.	Dynamic positioning .....	198
5.7.2.	Superimposed positioning (MC_MoveSuperImposed) .....	199
5.7.3.	Zero point shift caused by superimposed positioning (C3_ShiftPosition) .....	201
<b>5.8</b>	<b>Adjust force / pressure (C3_PressureForceAbsolute) .....</b>	<b>203</b>
<b>5.9</b>	<b>Dynamic switching: Position- on force/pressure - adjustment.....</b>	<b>204</b>
5.9.1.	Switching: from force to position mode (C3_pQ) .....	205
<b>5.10</b>	<b>Cam Control .....</b>	<b>207</b>
5.10.1.	Introduction: Electronic cam control .....	208
5.10.1.1	Function principle .....	209
5.10.2.	Overview .....	210
5.10.3.	Basics 211	
5.10.3.1	Cam types .....	211
5.10.3.2	Cam parameters / terms .....	212
5.10.3.3	Basic procedure .....	213
5.10.4.	Generating cams .....	214
5.10.4.1	Introduction to the CamDesigner (example) .....	215
5.10.4.2	Cam functions of the Compax3 ServoManager / motion laws .....	220
5.10.5.	Cam function structure .....	224
5.10.5.1	Function modules of the cam .....	224
5.10.5.2	Signal image .....	225
5.10.5.3	Cam reference systems .....	229

<b>5.10.6. Master signal source</b> .....	<b>235</b>
5.10.6.1 Setting the position of the selected master source (C3_SetMaster) .....	236
5.10.6.2 Recording the position of the selected master source (C3_MasterControl) .....	237
5.10.6.3 Control of the cam generator (C3_CamTableSelect) .....	240
5.10.6.4 C3_MasterConfig .....	243
5.10.6.5 Master signal phase shift (MC_Phasing) .....	244
<b>5.10.7. Alignment of the slave axis</b> .....	<b>246</b>
5.10.7.1 Start cam / coupling .....	246
5.10.7.2 Exiting the active curve with coupling movement (C3_CamOut) .....	257
<b>5.10.8. 10 Steps for cam generation</b> .....	<b>261</b>
5.10.8.1 Step 1: C3 ServoManager .....	261
5.10.8.2 Step 2: Connect motor .....	261
5.10.8.3 Step 3: Supply & I/O wiring .....	261
5.10.8.4 Step 4: RS232 connection & C3 ServoManager .....	261
5.10.8.5 Step 5: Set Compax3 device type .....	262
5.10.8.6 Step 6: Configuration .....	262
5.10.8.7 Step 7: Selecting Master signal source .....	262
5.10.8.8 Step 8: Generating the cam .....	262
5.10.8.9 Step 9: Create IEC program .....	263
5.10.8.10 Step 10: Starting and monitoring cam .....	263
<b>5.10.9. Cam applications</b> .....	<b>264</b>
5.10.9.1 Example 1: Single start of a closed cam .....	264
5.10.9.2 Example 2: Change between single start of an open cam and POSA .....	267
5.10.9.3 Example 3: Single Start for run through curve 5 times .....	269
5.10.9.4 Example 4: Composing curves .....	271
5.10.9.5 Example 5: Cyclic operation with event-triggered change of curve .....	274
5.10.9.6 Example 6: Operation with curve segments and standstill area .....	276
5.10.9.7 Example 7: Curve operation with slave reg synchronization .....	279
5.10.9.8 Example 8: Curve operation with master reg synchronization .....	281
5.10.9.9 Example case of damage .....	284
5.10.9.10 Application note: Drift .....	286
<b>5.11 Cam switching mechanism</b> .....	<b>288</b>
<b>5.11.1. Cam switching mechanism function overview</b> .....	<b>288</b>
5.11.1.1 Example of cam function .....	289
5.11.1.2 Examples of a cam cycle .....	289
<b>5.11.2. Redirect the fast cams directly to the physical output (C3_OutputSelect)</b> .....	<b>291</b>
<b>5.11.3. Objects of the cam switching mechanism</b> .....	<b>292</b>
<b>5.11.4. Behavior of the switch-on/switch-off anticipation</b> .....	<b>293</b>
5.11.4.1 Behavior depending on the travel direction .....	293
5.11.4.2 Switching behavior with reset operation .....	295
5.11.4.3 Switch-on anticipation is corrected via reset distance .....	295
5.11.4.4 Note: No switching operation with overlapping cams .....	296
<b>5.11.5. Hysteresis</b> .....	<b>296</b>
<b>5.11.6. CoDeSys-Project for the configuration of the cams</b> .....	<b>297</b>
<b>5.11.7. Example: Working with fast cams</b> .....	<b>298</b>
<b>5.12 Error handling</b> .....	<b>300</b>
<b>5.12.1. Acknowledging errors (MC_Reset)</b> .....	<b>300</b>
<b>5.12.2. Reading axis errors (MC_ReadAxisError)</b> .....	<b>301</b>
<b>5.12.3. Set error reaction (C3_SetErrorReaction)</b> .....	<b>302</b>

<b>5.13</b>	<b>Process image.....</b>	<b>303</b>
5.13.1.	Reading digital inputs (C3_Input) .....	303
5.13.2.	Write digital outputs (C3_Output) .....	303
5.13.3.	Reading/writing optional inputs/outputs.....	304
5.13.3.1	C3_IOAddition_0.....	304
5.13.3.2	C3_IOAddition_1.....	304
5.13.3.3	C3_IOAddition_2.....	305
5.13.4.	Memorizing the signals with the trigger event (C3_TouchProbe) .....	306
5.13.5.	Integration of Parker I/Os (PIOs) .....	309
5.13.5.1	Initializing the PIOs (PIO_Init).....	309
5.13.5.2	Reading the PIO inputs 0-15 (PIO_Inputx...y) .....	310
5.13.5.3	Writing the PIO outputs 0-15 (PIO_Outputx...y) .....	311
5.13.5.4	Example: Compax3 as CANopen Master with PIOs .....	312
<b>5.14</b>	<b>Interface to C3 powerPLmC .....</b>	<b>314</b>
5.14.1.	Interface module "PLmC_Interface" .....	315
5.14.2.	Cyclic data channel for C3T30 and C3T40 .....	317
5.14.3.	Example: C3 powerPLmC Program & Compax3 Program .....	319
<b>5.15</b>	<b>IEC examples.....</b>	<b>322</b>
5.15.1.	Example in CFC: Using Compax3-specific function modules and Compax3 objects .....	322
5.15.2.	Example in CFC: Positioning 1 .....	323
5.15.3.	Example in CFC: Positioning 2 .....	324
5.15.4.	Example in CFC: Positioning with set selection .....	325
5.15.5.	Example in CFC: Cycle mode.....	326
5.15.6.	Example in ST: Cycle mode with a Move module .....	327
<b>5.16</b>	<b>Profibus: Emulating the ProfiDrive profile (C3F_ProfiDrive_Statemachine) .....</b>	<b>329</b>
<b>6.</b>	<b>Communication .....</b>	<b>333</b>
<b>6.1</b>	<b>Compax3 communication variants.....</b>	<b>333</b>
6.1.1.	PC <-> Compax3 (RS232).....	334
6.1.2.	PC <-> Compax3 (RS485).....	335
6.1.3.	PC <-> C3M device combination (USB).....	336
6.1.4.	USB-RS485 Moxa Uport 1130 adapter .....	337
6.1.5.	ETHERNET-RS485 NetCOM 113 adapter.....	338
6.1.6.	Modem Westermo TD-36 485.....	340
6.1.7.	C3 settings for RS485 two wire operation.....	343
6.1.8.	C3 settings for RS485 four wire operation.....	344
<b>6.2</b>	<b>COM port protocol .....</b>	<b>345</b>
6.2.1.	RS485 setting values.....	345
6.2.2.	ASCII - record.....	346
6.2.3.	Binary record .....	347
<b>6.3</b>	<b>Remote diagnosis via Modem.....</b>	<b>350</b>
6.3.1.	Structure.....	350
6.3.2.	Configuration of local modem 1.....	351
6.3.3.	Configuration of remote modem 2.....	352
6.3.4.	Recommendations for preparing the modem operation .....	353

<b>6.4</b>	<b>Profibus .....</b>	<b>354</b>
6.4.1.	Typical application with fieldbus and IEC61131 .....	354
6.4.2.	Profibus configuration .....	354
6.4.2.1	Configuration of the process-data channel .....	355
6.4.2.2	PKW parameter channel .....	356
6.4.2.3	Error reaction to a bus failure .....	356
6.4.3.	Cyclic process data channel .....	356
6.4.3.1	Control and status word .....	356
6.4.4.	Acyclic parameter channel .....	357
6.4.4.1	Parameter access with DPV0: Required data channel .....	357
6.4.4.2	Data formats of the bus objects .....	363
6.4.5.	Simatic S7 -300/400 - modules .....	366
<b>6.5</b>	<b>CANopen - Node Settings .....</b>	<b>367</b>
6.5.1.	CANopen - configuration .....	367
6.5.1.1	CANopen Operating Mode .....	367
6.5.1.2	Error reaction to a bus failure .....	368
6.5.1.3	Baud rate .....	368
6.5.1.4	Possible PDO assignment .....	369
6.5.1.5	Transmission cycle time .....	369
6.5.2.	Supporting IEC modules .....	369
6.5.2.1	C3_CANopen_State .....	370
6.5.2.2	C3_CANopen_GuardingState .....	371
6.5.2.3	C3_CANopen_AddNode .....	372
6.5.2.4	C3_CANopen_ConfigNode .....	373
6.5.2.5	C3_CANopen_NMT .....	374
6.5.2.6	Reading an object in another node (C3_CANopen_SDO_Read4) .....	375
6.5.2.7	Writing an object in another node (C3_CANopen_SDO_Write4) .....	376
6.5.3.	CANopen communication profile .....	377
6.5.3.1	Object types .....	378
6.5.3.2	Communication objects .....	378
6.5.4.	Acyclic parameter channel .....	382
6.5.4.1	Service Data Objects (SDO) .....	382
6.5.4.2	Object up-/download via RS232 / RS485 .....	384
6.5.4.3	Data formats of the bus objects .....	384
<b>6.6</b>	<b>DeviceNet .....</b>	<b>385</b>
6.6.1.	DeviceNet Configuration .....	385
6.6.1.1	Error reaction to a bus failure .....	385
6.6.2.	DeviceNet object classes .....	386
6.6.2.1	Overview of the DeviceNet object classes .....	387
6.6.2.2	Object classes .....	387
6.6.3.	Data formats of the bus objects .....	387
<b>6.7</b>	<b>Ethernet Powerlink .....</b>	<b>388</b>
6.7.1.	Configuring Ethernet Powerlink / EtherCAT .....	388
6.7.1.1	CN Controlled Node (Slave) .....	388
6.7.1.2	Slave with configuration via master .....	388
6.7.1.3	Error reaction to a bus failure .....	388
6.7.1.4	Possible PDO assignment .....	389
<b>6.8</b>	<b>HEDA Bus .....</b>	<b>390</b>
6.8.1.	HEDA standard mode .....	391
6.8.1.1	Error reaction to a bus failure .....	391
6.8.1.2	HEDA-Master .....	392
6.8.1.3	HEDA-Slave .....	392

6.8.2.	<b>HEDA expansion (HEDA advanced)</b> .....	<b>393</b>
6.8.2.1	The possibilities of the HEDA expansion.....	393
6.8.2.2	Technical data of the HEDA interface / overview .....	394
6.8.2.3	Definitions .....	395
6.8.2.4	Calling up the HEDA wizard in the C3 ServoManager .....	395
6.8.2.5	Configuration of the HEDA communication .....	395
6.8.3.	<b>Coupling objects</b> .....	<b>412</b>
<b>7.</b>	<b>Compax3 - Objects</b> .....	<b>414</b>
7.1	<b>Objects for the process data channel</b> .....	<b>415</b>
7.2	<b>Object overview sorted by object name (T40)</b> .....	<b>417</b>
7.3	<b>Detailed object list</b> .....	<b>426</b>
<b>8.</b>	<b>Status values</b> .....	<b>427</b>
8.1	<b>D/A-Monitor</b> .....	<b>427</b>
8.2	<b>Status values</b> .....	<b>427</b>
<b>9.</b>	<b>Error:</b> .....	<b>428</b>
<b>10.</b>	<b>Order code</b> .....	<b>429</b>
10.1	<b>Order code device: Compax3 Fluid</b> .....	<b>429</b>
10.2	<b>Accessories order code</b> .....	<b>429</b>
<b>11.</b>	<b>Compax3 Accessories</b> .....	<b>432</b>
11.1	<b>ZBH plug set</b> .....	<b>432</b>
11.2	<b>Cable for path measurement systems</b> .....	<b>432</b>
11.2.1.	Encoder cable .....	433
11.2.2.	Feedback cable (Balluff) .....	434
11.2.3.	Feedback cable EnDat2.1.....	435
11.3	<b>Operator control module BDM</b> .....	<b>436</b>
11.4	<b>EAM06: Terminal block for inputs and outputs</b> .....	<b>437</b>
11.5	<b>Interface Cables</b> .....	<b>440</b>
11.5.1.	RS232 cable.....	441
11.5.2.	RS485 cable to Pop .....	442
11.5.3.	I/O interface X12 / X22 .....	443
11.5.4.	Ref X11 .....	444
11.5.5.	Encoder coupling of 2 Compax3 axes.....	445
11.5.6.	Modem cable SSK31.....	446
11.6	<b>Options M1x</b> .....	<b>447</b>
11.6.1.	Input/output option M12.....	447

11.6.1.1	Assignment of the X22 connector .....	447
11.6.2.	HEDA (motion bus) - Option M11 .....	448
11.6.3.	Option M10 = HEDA (M11) & I/Os (M12) .....	450
11.7	Profibus plug BUS08/01 .....	451
11.8	CAN - plug BUS10/01 .....	452
11.9	PIO: Inputs/Outputs .....	453
<b>12.</b>	<b>Specifications .....</b>	<b>454</b>
<b>13.</b>	<b>Index .....</b>	<b>461</b>

# 1. Introduction

**In this chapter you can read about:**

Device assignment Compax3 Fluid .....	12
Safety Instructions .....	14
Warranty conditions .....	15
Conditions of utilization for CE-conform operation .....	15

## 1.1 Device assignment Compax3 Fluid

**This manual applies to the following devices:**


- ◆ C3 F001 D2 F12 I11 T40
- ◆ C3 F001 D2 F12 I20 T40
- ◆ C3 F001 D2 F12 I21 T40
- ◆ C3 F001 D2 F12 I22 T40
- ◆ C3 F001 D2 F12 I30 T40
- ◆ C3 F001 D2 F12 I31 T40



**1.1.1. Type specification plate Compax3 Fluid**

You will find the exact description of the device on the type specification plate, which is located on the right side of the device:

Type specification plate Compax3 Fluid:



**Explanation:**

1	Type designation	The complete order designation of the device (2, 6, -9...) (Category No.)
2	C3F001D2	<b>C3:</b> Abbreviation for Compax3 <b>F =Fluid:</b> Hydraulics controller <b>001:</b> +/-10V and 0..20mA outputs (16 Bit) <b>D2:</b> 24VDC device
3	Unique number of the particular device	
4	Supply voltage	24 VDC
5	Date of factory test	
6	Designation of the feedback system	<b>F12:</b> Feedback Module
7	Device interface	<b>I11 / I12:</b> Digital Inputs / Outputs and RS232 / RS485 <b>I20:</b> Profibus DP <b>I21:</b> CANopen <b>I22:</b> DeviceNet
8	Technology function	<b>T11:</b> Positioning / pressure/force control <b>T30:</b> Motion control programmable according to IEC61131-3 <b>T40:</b> Electronic cam generation
9	Options	<b>Mxx:</b>
10	CE compliance	
11	UL certification	<b>PD2</b> (see page 456) (degree of pollution)

## 1.2 Safety Instructions

### In this chapter you can read about:

General hazards .....	14
Safety-conscious working .....	14
Special safety instructions .....	15

### 1.2.1. General hazards

#### General Hazards on Non-Compliance with the Safety Instructions

The device described in this manual is designed in accordance with the latest technology and is safe in operation. Nevertheless, the device can entail certain hazards if used improperly or for purposes other than those explicitly intended. Electronic, moving and rotating components can

- ◆ constitute a hazard for body and life of the user, and
- ◆ cause material damage

#### Usage in accordance with intended purpose

The device is designed for operation in electric power drive systems (VDE0160). Motion sequences can be automated with this device. Several motion sequences can be combined by interconnecting several of these devices. Mutual interlocking functions must be incorporated for this purpose.

### 1.2.2. Safety-conscious working

This device may be operated only by qualified personnel.

Qualified personnel in the sense of these operating instructions consists of:

- ◆ Persons who, by virtue to their training, experience and instruction, and their knowledge of pertinent norms, specifications, accident prevention regulations and operational relationships, have been authorized by the officer responsible for the safety of the system to perform the required task and in the process are capable of recognizing potential hazards and avoiding them (definition of technical personnel according to VDE105 or IEC364),
- ◆ Persons who have a knowledge of first-aid techniques and the local emergency rescue services.
- ◆ Persons who have read and will observe the safety instructions.
- ◆ Those who have read and observe the manual or help (or the sections pertinent to the work to be carried out).

This applies to all work relating to setting up, commissioning, configuring, programming, modifying the conditions of utilization and operating modes, and to maintenance work.

This manual and the help information must be available close to the device during the performance of all tasks.

### 1.2.3. Special safety instructions

- ◆ Check the correct association of the device and its documentation.
- ◆ Never detach electrical connections while voltage is applied to them.
- ◆ Safety devices must be provided to prevent human contact with moving or rotating parts.
- ◆ Make sure that the device is operated only when it is in perfect condition.
- ◆ Implement and activate the stipulated safety functions and devices.
- ◆ Operate the device only with the housing closed.
- ◆ Make sure that all axes are sufficiently fixed.
- ◆ Attention during configuration downloads with master - slave couplings (electronic gear, cam)  
Deactivate the drive before starting the configuration download: Master and Slave axis

## 1.3 Warranty conditions

- ◆ The device must not be opened.
- ◆ Do not make any modifications to the device, except for those described in the manual.
- ◆ Make connections to the inputs, outputs and interfaces only in the manner described in the manual.
- ◆ Fix the devices according to our **mounting instructions**. (see page 40)  
We cannot provide any guarantee for any other mounting methods.

#### **Note on exchange of options**

Compax3 options must be exchanged in the factory to ensure hardware and software compatibility.

## 1.4 Conditions of utilization for CE-conform operation

#### **- Industry and trade -**

The EC guidelines for electromagnetic compatibility 2006/95/EC and for electrical operating devices for utilization within certain voltage limits 2004/108/EC are fulfilled when the following boundary conditions are observed:

**Operation of the devices only in the condition in which they were delivered, i.e. with all housing panels.**

#### **Shielding connection of the valve cables**

The cable should be fully screened and connected to the Compax3 housing. We offer a special **Shield connecting terminal** (see page 432) as accessory item (ZBH./...).

The shield of the valve cable must also be connected with the valve housing. The fixing (via plug or screw in the terminal box) depends on the valve type.

**Requirements for  
encoder cable  
Compax3:**

<100m

**Control:** Use only with aligned controller (to avoid control loop oscillation).

**Cable installation:** Signal lines and power lines should be installed as far apart as possible. Signal leads should never pass close to excessive sources of interference (motors, transformers, contactors etc.).

**Accessories:** Make sure to use only the accessories recommended by Parker

**Connect all cable shields at both ends, ensuring large contact areas!**

**Warning:**

**This is a product in the restricted sales distribution class according to EN 61000-6-4. In a domestic area this product can cause radio frequency disturbance, in which case the user may be required to implement appropriate remedial measures.**

## 2. Positioning with IEC61131-3

### **Compax3F: Electrohydraulic servo drive**

Compax3F is another member of the Parker Hannifin servo drive family. Compax3F was especially designed to meet the requirements of electrohydraulic systems for the control of position and force of hydraulic axes.

#### **Compax3 Fluid – (Hydraulics controller)**

#### **Technical data**

Motion control with motion profiles, suitable for position and force/pressure control for up to 2 axes.

#### **Command value generator**

- ◆ Jerk-limited ramps.
- ◆ Travel data in increments, mm, inch.
- ◆ Specification of speed, acceleration, delay and jerk factor.
- ◆ Force/pressure data in N, bar, psi.

#### **Monitoring functions**

- ◆ Voltage range.
- ◆ Following error monitoring.
- ◆ Hard and Software limit switch

#### **Technology functions of servo controllers**

- ◆ IEC61131-3 programs in the servo controller (T30)
- ◆ Cam function in the servo controller (T40)

### IEC 61131-3 Programming

Due to its high functionality, Compax3 in the version “IEC 61131-3 - Positioning with function modules based on PLCopen” forms an ideal basis for many applications in high-performance motion automation. A standard with general applicability was created with Standard IEC 61131-3. The programming system is equipped with a series of functions in addition to the compliant editor. The Motion Control functions specified in PLCopen are also provided by Parker as a library with the device and control software.

The graphical program editor supports the following functions:

- ◆ Ladder diagram
- ◆ Function block diagram (structurally-guided)
- ◆ Function block diagram (free graphical editor)


The text-oriented editor supports programming in

- ◆ Instruction list
- ◆ Structured text

Programming of Compax3 based on IEC 61131-3 is also made considerably easier by a series of additional functions. This includes in particular Syntax Coloring, multi-level undo/redo and context-sensitive input help.

### Cam control T40

Rising rationalization pressure and an increasing degree of automation in process engineering demand modern and flexible drive concepts. The introduction of digital and communicating control devices was an important step towards the decentralization of control and regulation tasks. An increasing number of mechanical construction components can be replaced by programmable servo drives.



In particular mechanical cam switching mechanisms and discontinuous shafts maintained until today their fields of application in many areas of machine construction. Mechanical cam switching mechanisms offer, besides complex motion profiles, a high positioning accuracy and rigid coupling between master and slave drive. Their drawbacks are, however, the long changeover times and the limitation to a defined profile.

In this respect the Compax3 T40 electronic cam offers considerable time advantages, above all when changing between small batch sizes or with a wide range of products. The decentralization of the drive performance can reduce size, costs and maintenance effort considerably.

The switching command between different motion profiles takes only seconds – no fitter or wrench is required.

Large, mechanically coupled drive systems can be divided into small, independent drives. The dynamic and stationary behavior of every drive can be individually set and optimized.

Compax3 is able to simulate mechanical cams and cam switching mechanisms electronically.

This helps to realize discontinuous material supply, flying knife and similar drive applications with distributed drive performance.

The compact servo controller processes the signals of a master axis and controls a servo drive via the desired motion profile, which is defined in the form of an interpolation point memory.

The cam function modules (T40) and the CamDesigner make it easy to launch cam applications in the IEC program:

<b>Interfaces with superordinate controllers</b>	<p>Independent of your motion automation you can access Compax3 externally via different interfaces (e.g. with the superordinate control):</p> <ul style="list-style-type: none"> <li>◆ via RS232 / RS485</li> <li>◆ via digital Inputs/Outputs (Interface I11)</li> <li>◆ via Profibus (Interface I20)</li> <li>◆ via CANopen (Interface I21)</li> </ul>
<b>Profibus (I20 - functions)</b>	<p>The higher-level control system communicates with Compax3 via Profibus. A number of different cyclic transfer telegrams (which can be conveniently adjusted with the Compax3 ServoManager) can be used to adjust bus communication to the requirements of specific applications.</p> <p>In addition to the cyclic data channel, parameter access is also possible via a DPV1 master or using the parameter channel with a DPV0 master.</p>
<b>CANopen (I21 - functions)</b>	<p>The higher level control system communicates with Compax3 via CANopen. Via various cyclic process data objects (which can be comfortably set with the Compax3 ServoManager) the bus communication can be adapted to the application requirements.</p> <p>Apart from the cyclic process data objects, acyclic parameter access is possible via service data objects.</p>
<b>DeviceNet (I22 functions)</b>	<p>The higher level control system communicates with Compax3 via DeviceNet. Cyclic I/O messages (which can be conveniently adjusted with the Compax3 ServoManager) can be used to adjust bus communication to the requirements of specific applications.</p> <p>Besides the cyclic data, acyclic access to objects is possible via Explicit Messges.</p>
<b>Compax3 control technology</b>	<p>High-performance control technology and openness for various sender systems are fundamental requirements for a fast and high-quality automation of movement.</p>

**Model / standards / auxiliary material**

The structure and size of the device are of considerable importance. Powerful electronics is an important feature which made it possible to manufacture the Compax3F so small and compact. All connectors are located on the front of the Compax3.

The Compax3 is CE-conform.

The intuitive user interface familiar from many applications, together with the oscilloscope function, wizards and online help, simplifies making and modifying settings via the PC.

The optional **Operator control module (BDM01/01 (see page 435))** for Compax3 makes it possible to exchange devices quickly without requiring a PC.

**Configuration**

Configuration is made on a PC using the Compax3 ServoManager.  
General proceeding



# 3. Compax3F device description

**In this chapter you can read about:**

State of delivery.....21  
 Plug and connector assignment Compax3 Fluid.....21

## 3.1 State of delivery

Compax3 is delivered without configuration!  
 After switching on the 25VDC supply, the red LED is flashing while the green LED is dark.  
 Please configure the device with the help of the Windows-Software "Compax3 – ServoManager"!

## 3.2 Plug and connector assignment Compax3 Fluid


**In this chapter you can read about:**

Meaning of the front panel LEDs (via X10) .....21  
 Plug and connector assignment .....22  
 Plug and connector assignment complete .....23  
 Analog Input (plug X1).....25  
 Analog Output (plug X2).....26  
 Voltage supply (plug X3) .....27  
 RS232 / RS485 interface (plug X10) .....27  
 Analog / Encoder (plug X11) .....28  
 Digital inputs/outputs (plug X12) .....29  
 Feedback (connector X13) .....30  
 Profibus connector X23 with Interface I20 .....32  
 CANopen connector X23 Interface I21 .....33  
 DeviceNet connector X23 .....35  
 Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24 .....36  
 Mounting and dimensions .....40

### 3.2.1. Meaning of the front panel LEDs (via X10)

status	LED red	LED green
Voltages missing.	off	off
While booting.	alternately flashing	
No configuration present.	flashing	off
Compax3 IEC61131-3 program not compatible with Compax3 Firmware.		
no Compax3 IEC61131-3 program.		
Axis(es) blocked.	off	Flashes slowly
Axis(es) enabled.	off	on
Axis in fault status / fault present.	on	off

### 3.2.2. Plug and connector assignment




X1	Analog Inputs
X2	Analog Outputs
X3	24 VDC power supply
X10	RS232/RS485
X11	2. Feedback Type
X12	Inputs/Outputs
X13	1. Feedback Type




**Always switch devices off before wiring them!**

### 3.2.3. Plug and connector assignment complete

**In detail:** The fitting of the different plugs depends on the extension level of Compax3. In part, the assignment depends on the Compax3 option implemented.



### 3.2.4. Analog Input (plug X1)



Connector X1 Pin	Description	Combicon 3,81mm; female connector
1	24V	Supply Sensor 0
2	GND	Supply Sensor 0
3	IN0+	Signal Sensor 0 +
4	IN0-	Signal Sensor 0 -
5	24V	Supply Sensor 1
6	GND	Supply Sensor 1
7	IN1 +	Signal Sensor 1 +
8	IN1 -	Signal Sensor 1 -
9	24V	Supply Sensor 2
10	GND	Supply Sensor 2
11	IN2 +	Signal Sensor 2 +
12	IN2 -	Signal Sensor 2 -
13	24V	Supply Sensor 3
14	GND	Supply Sensor 3
15	IN3 +	Signal Sensor 3 +
16	IN3-	Signal Sensor 3 -
17	IN4+	+/-10V Input 4
18	IN4-	+/-10V Input 4
19	IN5+	+/-10V Input 5
20	IN5-	+/-10V Input 5

#### Requirement: Connection cable

Use shielded cables.


#### Shield connection of the cables

The cable should be fully screened and connected to the Compax3 housing. We offer a special **Shield connecting terminal** (see page 432) as accessory item (ZBH./...).

#### 3.2.4.1 Wiring of the analog inputs

##### Input IN0


##### Compax3 Fluid



IN0 to IN3 do have the same wiring!  
**Pin assignment** (see page 25) X1


##### Input IN4

##### Compax3 Fluid



IN4 and IN5 (X11/19 and X11/20) have the same wiring!

### 3.2.5. Analog Output (plug X2)



Plug X2 Pin	Description	Combicon 3,81mm; female connector
1	I/U Aout0	$\pm 10V/10mA$ or $4..20mA$
2	GND 0	
3	I/U Aout1	$\pm 10V/10mA$ or $4..20mA$
4	GND 1	
5	I/U Aout2	$\pm 10V/10mA$ or $4..20mA$
6	GND 2	
7	I/U Aout3	$\pm 10V/10mA$ or $4..20mA$
8	GND 3	
9	lout 0	$\pm 100mA$ current output 0
10	GND	
11	lout 1	$\pm 100mA$ current output 1
12	GND	

Terminating resistor:  
 Voltage  $\pm 10V$ :  $\geq 1000\Omega$   
 Current  $4..20mA$ :  $\leq 600\Omega$   
 Current  $100mA$ :  $\leq 100\Omega$   
 All outputs are short-circuit proof.

#### Requirement: Connection cable


Use shielded cables.

#### Shield connection of the cables

The cable should be fully screened and connected to the Compax3 housing. We offer a special **Shield connecting terminal** (see page 432) as accessory item (ZBH./...).


#### 3.2.5.1 Wiring of analog outputs

Output I/U Aout0



\* 20mA to max. 450Ω

Output lout0



\* at  $RL \leq 180\Omega$

Aout0 to Aout3 do have the same wiring!  
**Pin assignment** (see page 26) X2

lout0 and lout1 (X2/11 and X2/12) have the same wiring!

### 3.2.6. Voltage supply (plug X3)



Connector X3 Pin	Description	Combicon 5mm
1	+24 V	24 VDC (power supply)
2	Gnd 24 V	GND

#### Voltage supply 24VDC

Controller type	Compax3 F001 D2
Voltage range	21 - 27VDC
Mains module	with switch-on current limitation, due to capacitive load
Fuse	MTP miniature circuit breaker or "delayed action fuse", due to capacitive load
Current drain of the device	0.8A (max. 1.5A)
Total current drain	0.8A + total load of the digital outputs
Ripple	<1Vss
Requirement according to safe extra low voltage (SELV)	yes

### 3.2.7. RS232 / RS485 interface (plug X10)



Interface selectable by contact functions assignment of X10/1:

X10/1=0V RS232

X10/1=5V RS485

PIN X10	RS232 (Sub D)
1	(Enable RS232) 0V
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	+5V

#### RS485 2-wire

PIN X10	RS485 two wire (Sub D) Pin 1 and 9 jumpered externally
1	Enable RS485 (+5V)
2	res.
3	TxD_RxD/
4	res.
5	GND
6	res.
7	TxD_RxD
8	res.
9	+5V

**RS485 4-wire**

PIN X10	RS485 four wire (Sub D) Pin 1 and 9 externally jumpered
1	Enable RS485 (+5V)
2	RxD
3	TxD/
4	res.
5	GND
6	res.
7	TxD
8	RxD/
9	+5V

**USB - RS232/RS485 converter**

The following USB - RS232 converters were tested:

- ◆ ATEN UC 232A
- ◆ USB GMUS-03 (available under several company names)
- ◆ USB / RS485: **Moxa Uport 1130** [http://www.moxa.com/product/UPort\\_1130.htm](http://www.moxa.com/product/UPort_1130.htm)
- ◆ Ethernet/RS232/RS485: **NetCom 113** <http://www.vscom.de/666.htm>

**3.2.8. Analog / Encoder (plug X11)**

The following position sensors can be connected via X11:

- ◆ RS422 Encoder (max. 5MHz, or Step/Direction)
- ◆ SSI (RS422)
- ◆ Start / Stop (Time of Flight, RS422)




2. Feedback system / X11 High Density /Sub D				
PIN	D-A Monitor	RS422 Encoder	Start / Stop (Time of Flight)	SSI
1			+24V max. 100mA	+24V max. 100mA
2				
3	Aout1			
4	Aout0			
5		+5V (for encoder) max. 150mA		
6		A-	INIT-	Clock-
7		A+	INIT+	Clock+
8		B+	STSP+	
9				
10				
11				
12		B-	STSP-	
13		N-		DATA-
14		N+		DATA+
15	GND	GND	GND	GND

Max. start/stop time is 1.6ms (over 4.15m).



**3.2.8.1 Connections of the encoder interface**

### Compax3



The input connection is available in triple (for A & /A, B & /B, N & /N)

**3.2.9. Digital inputs/outputs (plug X12)**



X12 Pin	Input/output	I/O /X12 High density/Sub D
1	Output	+24VDC output (max. 340mA)
2	O0	Output 0 (max. 100mA)
3	O1	Output 1 (max. 100mA)
4	O2	Output 2 (max. 100mA)
5	O3	Output 3 (max. 100mA)
6	I0	Input 0
7	I1	Input 1
8	I2	Input 2
9	I3	Input 3
10	I4	Input 4
11	E	24V input for the digital outputs Pins 2 to 5
12	I5	Input 5
13	I6	Input 6
14	I7	Input 7
15	Output	Gnd 24 V

All inputs and outputs have 24V level.

The exact assignment depends on the device type!


You will find the description of the device-specific assignment in the online help which can be opened from the Compax3 – ServoManager.

Maximum capacitive loading of the outputs: 50nF (max. 4 Compax3 inputs).

**3.2.9.1 Connection of the digital Outputs/Inputs**

**Wiring of digital outputs**

**Compax3**




The circuit example is valid for all digital outputs!  
The outputs are short circuit proof; a short circuit generates an error.

F1: delayed action fuse

F2: quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

**Status of digital inputs**

**Compax3**



The circuit example is valid for all digital inputs!  
Signal level:

- ◆ > 9.15V = "1" (38,2% of the control voltage applied)
- ◆ > 8.05V = "0" (33.5% of the control voltage applied)

**3.2.10. Feedback (connector X13)**

The following position sensors can be connected via X13:

- ◆ 1VSS SineCosine (max. 400Hz)
- ◆ RS422 Encoder (max. 5MHz, or Step/Direction)
- ◆ SSI (RS422)
- ◆ Start / Stop (Time of Flight, RS422)
- ◆ EnDat2.1



1. Feedback system / X13 High Density /Sub D					
PIN	RS422 Encoder	SinusCosinus 1VSS	EnDat 2.1	Start / Stop (Time of Flight)	SSI
1				+24V max. 100mA	+24V max. 100mA
2	Sense +	Sense +	Sense +		
3		Sin +	Sin +		
4	Vcc +5V (controlled on the encoder side)	Vcc +5V (controlled on the encoder side)	Vcc +5V (controlled on the encoder side)		
5	+5V (for encoder) max. 150mA	+5V	+5V		
6	A-		Clock-	INIT-	Clock-
7	A+		Clock+	INIT+	Clock+
8	B+	COS+	COS+	STSP+	
9		SIN-	SIN-		
10					
11	Sense -	Sense -	Sense -		
12	B-	COS-	COS-	STSP-	
13	N-	N-	DATA-		DATA-
14	N+	N+	DATA+		DATA+
15	GND	GND	GND	GND	GND

Max. start/stop time is 1.6ms (over 4.15m).


**Note on F12:**

+5V (Pin 4) is measured and controlled directly at the end of the line via Sense – and Sense +.

Maximum cable length: 100m

**Caution!** Pin 4 and Pin 5 must under no circumstances be connected!

**3.2.10.1 Connections of the encoder interface**



The input connection is available in triple (for A & /A, B & /B, N & /N)

### 3.2.11. Profibus connector X23 with Interface I20



Pin X23	Profibus (Sub D)
1	Reserved
2	Reserved
3	Data line B
4	RTS
5	GND
6	+5V
7	Reserved
8	Data line A
9	Reserved

The assignment corresponds to Profibus standard EN 50170.

**Wiring** (see page 451).

#### 3.2.11.1 Adjusting the bus address



##### Address setting

##### Values:

1:  $2^0$ ; 2:  $2^1$ ; 3:  $2^2$ ; ... 7:  $2^6$ ; 8: reserved

##### Settings:

left: OFF

right: ON

(The address is set to 0 in the illustration to the left)

##### Range of values: 1 ...127

Address 0 is set internally to address 126.

#### 3.2.11.2 Function of the Bus LEDs

##### Meaning of the LEDs (under X23)

Green LED (left)	Red LED (right)	Description
alternately flashing		Field bus program missing
off	flashing	Device is not initialized
on	flashing	Bus operation mode (no DATA exchange)
on	off	Bus operation mode (DATA exchange)
on	on	Bus error

### 3.2.12. CANopen connector X23 Interface I21



Pin X23	CANopen (Sub D)	
1	Reserved	
2	CAN_L	CAN Low
3	GNDfb	Opto-isolated GND-supply
4	Reserved	
5	SHIELD	Shield optional
6	Reserved	
7	CAN_H	CAN High
8	Reserved	
9	Reserved	

The assignment corresponds to CANopen DS301.

At the beginning and end of the device chain a terminating resistor of 120Ω is required between CAN\_L and CAN\_H

**Wiring** (see page 452).

#### 3.2.12.1 Adjusting the bus address



##### Address setting

##### Values:

**1:** 2<sup>0</sup>; **2:** 2<sup>1</sup>; **3:** 2<sup>2</sup>; ... **7:** 2<sup>6</sup>; **8:** reserved

##### Settings:

left: OFF

right: ON

(The address is set to 0 in the illustration to the left)

##### Range of values: 1 ...127

Address 0 is set internally to address 126.

**3.2.12.2 Function of the Bus LEDs**

**LED red**


No.	Signal	Status	Description
1	off	No Error	The bus is operating
2	Single flash	Warning	at least one of the error counters of the CAN controller has reached the warning level.
3	Double flash	Error	Node Guarding Error
4	Triple flash	Error	Sync Error Buffer overflow (0x8110)
5	on	Bus not active	

If several errors occur at once, the error with the most significant number is reported.

**LED green**

Signal	Status	Description
Single flash	Stop	The bus is in STOPPED state
blinks (permanently)	pre-operational	The bus is ready to operate (Pre-Operational)
on	operational	The bus is operating (operational)

Single flash




Double flash



Triple flash



**CANopen states**



- 6: Start Remote Node
- 7: Stop Remote Node
- 8: Enter Pre-Operational State
- 10: Reset Node
- 11: Reset Communication

The "Initialization" state is no fixed state but only a transition state.

### 3.2.13. DeviceNet connector X23



Pin X23	DeviceNet (Open Plug Phoenix MSTB 2.5/5-GF5.08 ABGY AU)	
1	V-	Mass
2	CAN-	CAN Low
3	Shield	Shield
4	CAN+	CAN High
5	V+	not required, internal supply

A mating plug is included in the delivery.

If Compax3 is used as first or last device in the fieldbus network, a terminal resistance of 121  $\Omega$  is required. This is integrated between Pin 2 and Pin 4.

Additional information on the DeviceNet wiring can be found under [www.odva.org](http://www.odva.org) <http://www.odva.org>

Please do also heed the instructions in the DeviceNet master manual.

#### 3.2.13.1 Adjusting the bus address



##### Address setting (NA: Node Address)

##### Values:

1: 2<sup>0</sup>; 2: 2<sup>1</sup>; 3: 2<sup>2</sup>; ... 6: 2<sup>5</sup>reserved

##### Settings:

left: OFF

right: ON

(The address is set to 2 in the illustration)

**Range of values: 1 ... 63**

**Address 0 is set internally to address 63.**

##### Data Rate setting (DR):

Data Rate [kBit/s]	S24_7	S24_8
125	left: OFF	left: OFF
250	left: ON	right: OFF
500	right: OFF	left: ON
Reserved	right: ON	right: ON

Bear in mind that the maximum cable length depends on the Data rate:

Data Rate	Maximum length
500kbit/s	100m
250kbit/s	250m
125kbit/s	500m

**3.2.13.2 Function of the Bus LEDs**

**LED (red)**


No.	Signal	Status	Description
1	off	No Error	The bus is operating
2	Single flash	Warning	at least one of the error counters of the CAN controller has reached the warning level.
3	Double flash	Error	Communication Fault
4	Triple flash	Error	Double Mac ID
5	on	Error	Bus Off

If several errors occur at once, the error with the most significant number is reported.

**LED green**

Signal	Status	Description
Single flash	On-line Not Connected	Online, not at the master (not allocated)
blinks (permanently)	On-line Connected	Online, at the master (allocated)
on	On-line I/O Connected	I/O Messages allocated

Single flash




Double flash



Triple flash



**3.2.14. Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24**



	RJ45 (X23)	RJ45 (X24)
<b>PIN</b>	<b>in</b>	<b>out</b>
1	Tx +	Tx +
2	Tx -	Tx -
3	Rx +	Rx +
4	-	Reserved
5	-	Reserved
6	Rx -	Rx -
7	-	Reserved
8	-	Reserved

Wiring with Ethernet Crossover cable Cat5e (from X24 to X23 of the next device without termination); for this, we recommend our **SSK28** (see page 430, see page 445) interface cable.

**Meaning of the RJ45 LEDs (only for Ethernet Powerlink, I30)**

Green LED (top): connection established (RPT\_LINK/RX)  
 Yellow LED (bottom): Traffic (exchange of data) (Transmit / Receive Data) (RPT\_ERR)



### 3.2.14.1 Set Ethernet Powerlink (option I30) bus address

#### Automatic address assignment with EtherCAT



#### Address setting

##### Values:

1:  $2^0$ ; 2:  $2^1$ ; 3:  $2^2$ ; ... 7:  $2^6$ ; 8:  $2^7$

##### Settings:

left: OFF

right: ON

(The address is set to 0 in the illustration)

Range of values: 1 ... 239

### 3.2.14.2 Meaning of the Bus LEDs (Ethernet Powerlink)

#### Red LED (right): Ethernet Powerlink error

LED is influenced by the transitions of the NMT - status diagram (for further details, please refer to the **Ethernet Powerlink Specification**  
[http://www.parker.com/euro\\_emd/EME/downloads/compax3/EPL/epl2.0-ds-v-1-1-0-0.pdf](http://www.parker.com/euro_emd/EME/downloads/compax3/EPL/epl2.0-ds-v-1-1-0-0.pdf))

Error LED	Transition
off => on	NMT_CT11, NMT_GT6, NMT_MT6
on => off	NMT_CT6, NMT_GT2, NMT_CT3, NMT_MT5

#### Green LED (left): Ethernet Powerlink Status

LED indicates the states of the NMT - status diagram (for further details, please refer to the **Ethernet Powerlink Specification**  
[http://www.parker.com/euro\\_emd/EME/downloads/compax3/EPL/epl2.0-ds-v-1-1-0-0.pdf](http://www.parker.com/euro_emd/EME/downloads/compax3/EPL/epl2.0-ds-v-1-1-0-0.pdf))

Status LED		status
off	off	NMT_GS_OFF, NMT_GS_INITIALISATION, NMT_CS_NOT_ACTIVE / NMT_MS_NOT_ACTIVE
flickering	flickering	NMT_CS_BASIC_ETHERNET
single flash	Single flash	NMT_CS_PRE_OPERATIONAL_1 / NMT_MS_PRE_OPERATIONAL_1
double flash	Double flash	NMT_CS_PRE_OPERATIONAL_2 / NMT_MS_PRE_OPERATIONAL_2
triple flash	Triple flash	NMT_CS_READY_TO_OPERATE / NMT_MS_READY_TO_OPERATE
on	on	NMT_CS_OPERATIONAL / NMT_MS_OPERATIONAL
blinking	flashing	NMT_CS_STOPPED

**3.2.14.3 Meaning of the Bus LEDs (EtherCAT)**

**Red LED (right): EtherCAT error**

LED is influenced by the transitions of the status diagram


Error LED	Error:	Description
Off	No Error	
Flickering	Boot error	Error during initialization
Blinking	Invalid configuration	
Single Flash	Unsolicited change of status	Slave changed the status independently
Double Flash	Application Watchdog Timeout	Watchdog
On	PDI Watchdog Timeout	

**Green LED (left): EtherCAT Status**

LED shows the states of the status diagram


Status LED	status	Description
Off	INITIALIZATION	Initialisation
Blinking	PRE-OPERATIONAL	Ready
Single Flash	SAFE-OPERATIONAL	Master reads values
On	OPERATIONAL	Operation

**Status diagram**



Transition	Action
1	Start mailbox communication
2	Stop mailbox communication
3	Start input update
4	Stop input update
5	Start output update
6	Stop output update
7	Stop output update, stop input update
8	Stop input update, stop mailbox communication
9	Stop output update, stop input update, stop mailbox communication


**Meaning of the LED states**



### 3.2.15. Mounting and dimensions

**Mounting:**

- ◆ 3 socket head screws M5 or
- ◆ by direct snapping on a 35mm supporting rail (according to DIN EN 50 022),  
Mounting material: DIN rail clip and distance piece available as accessories - **Set ZBH02/04** (see page 432)



Stated in mm

# 4. Setting up Compax3

## In this chapter you can read about:

Configuration .....	41
Configuring the signal source .....	82
Optimization .....	87

## 4.1 Configuration

### In this chapter you can read about:

C3HydraulicsManager .....	44
Compax3F structure image .....	45
Drive configuration .....	46
Configuring drive1 .....	47
Configuring drive2 .....	49
Sensors .....	49
Valve configuration .....	51
Defining the reference system .....	53
Ramp upon error and switch to currentless .....	74
Limit and monitoring settings of force .....	75
Positioning window - Position reached .....	77
Following error limit .....	78
Maximum permissible speed .....	78
Encoder Simulation .....	79
Recipe table .....	80
Error response .....	80
Configuration name / comments .....	81

**Configuration sequence:****Installation of the C3 ServoManager**

The Compax3 ServoManager can be installed directly from the Compax3 DVD. Click on the appropriate hyperlink or start the installation program "C3Mgr\_Setup\_V.... .exe" and follow the instructions.

**PC requirements****Recommendation:**

Operating system:	MS Windows XP SP2 / MS Windows 2000 as from SP4 / (MS Vista)
Browser:	MS Internet Explorer 6.x
Processor:	Intel Pentium 4 / Intel Core 2 Duo / AMD Athlon class as from >=2GHz
RAM memory:	>= 1024MB
Hard disk:	>= 20GB available memory
Drive:	DVD drive
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB

**Minimum requirements:**

Operating system:	MS Windows XP SP2 / MS Windows 2000 as from SP4
Browser:	MS Internet Explorer 6.x
Processor:	>= 1.5GHz
RAM memory:	512MB
Hard disk:	10GB available memory
Drive:	DVD drive
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB

**Note:**

- ◆ For the installation of the software you need administrator authorization on the target computer.
- ◆ Several applications running parallelly, reduce the performance and operability.
- ◆ especially customer applications, exchanging standard system components (drivers) in order to improve their own performance, may have a strong influence on the communication performance or even render normal use impossible.
- ◆ Operation under virtual machines such as Vware Workstation 6/ MS Virtual PC is not possible.
- ◆ Onboard graphics card solutions reduce the system performance by up to 20% and cannot be recommended.
- ◆ Operation with notebooks in current-saving mode may lead, in individual cases, to communication problems.

- Connection between PC - Compax3** Your PC is connected with Compax3 via a RS232 cable (**SSK1** (see page 441)). Cable **SSK1** (see page 441) (COM 1/2-interface on the PC to X10 on the Compax3 or via adapter SSK32/20 on programming interface of Compax3H). Start the Compax3 servo manager and make the setting for the selected interface in the menu "**Options Communication settings RS232/RS485...**".
- Device Selection** In the menu tree under device selection you can read the device type of the connected device (Online Device Identification) or select a device type (Device Selection Wizard).
- Configuration** Then you can double click on "Configuration" to start the configuration wizard. The wizard will lead you through all input windows of the configuration.

**Input quantities will be described in the following chapters, in the same order in which you are queried about them by the configuration wizard.**

## 4.1.1. C3HydraulicsManager

### In this chapter you can read about:

Function description .....	44
Structure of the databases .....	44

### 4.1.1.1 Function description

With the aid of the C3Hydraulicsmanager, component databases for

- ◆ hydraulic valves (2/2, 3/3, 4/3 valves)
- ◆ actors (constant- and differential cylinders, hydromotors)
- ◆ Position feedback systems (with SSI-, Start/Stop, +/-10V-, 0..20mA-, RS422, Sine/Cosine- or EnDat2.1 interface)

can be created and updated. A distinction is made between customer components and Parker components. Databases with Parker components are already available upon delivery, the customer has furthermore the possibility to create new components from different suppliers in the customer database in order to make possible their operation together with Compax3.

All component data can be called up and printed out. Existing components can be used as templates for new components. A characteristic with the specific flow rate can be read in and memorized for each valve .

The detailed characterization of the components facilitates the commisioning of the hydraulic system, as a pre-parameterization of the control loop is effected during the Compax3 configuration with the aid of these characteristic values.

An up-to-date Parker component database can be downloaded from the internet. The customer component databases are not overwritten.


### 4.1.1.2 Structure of the databases

4 databases contain the data of the hydraulics components.

- ◆ Parker valves with characteristics (Valve.mdb)
- ◆ Parker actuators and path-measurement systems (CylinderDrive.mdb)
- ◆ Customer valves with characteristics (ValveC.mdb)
- ◆ Customer actuators and path-measurement systems (CylinderDriveC.mdb)



### 4.1.2. Compax3F structure image




### Components of Compax3F:

- ◆ 4 controllers for 2 axes
  - ◆ Main axis position controller (Main axis: Pos Control 1)
  - ◆ Main axis pressure difference / force controller (Main axis: PressureForce Control 1)
  - ◆ Auxiliary axis position controller (Auxiliary axis: Pos Control 2)
  - ◆ Auxiliary axis pressure difference / force controller (Auxiliary axis: PressureForce Control 2)
- ◆ 4 Conditioning Chains for the linearisation of the valves and cylinders
  - ◆ The axis assignment is made via the valve configuration (Valve configuration)
  - ◆ For the linearisation, pressures can be made available to the Conditioning Chains (fixed or measured pressures: pA, pB, p0, pT).
  - ◆ The Conditioning Chains are fixedly connected to the analog outputs.
- ◆ Interfaces for actual position values
  - ◆ Pos Feedback 2 or configurable analog interface for the auxiliary axis (Configuration switch)
  - ◆ Pos Feedback 2 or configurable analog interface for the main axis (Configuration switch)
- ◆ 6 analog interfaces for pressures or force (or position)
  - ◆ Assignment to the axis via configuration
  - ◆ Assignment to the Conditioning Chain via the configuration (axis assignment, valve assignment)
- ◆ Setpoint predefinition via IEC61131-3 modules
- ◆ Static (1), (2), or dynamic (dynamic) (3) switching via IEC61131-3 modules

### 4.1.3. Drive configuration

- ◆ Please select the number of drives (1 or 2) to be controlled (by open or closed loop) with Compax3F.
- ◆ Physical system: Selection of the unit for the force or pressure control
  - ◆ The unit for force is Newton and a force is controlled
  - ◆ For differential pressure the unit is Bar or PSI (depending on the unit system) and a differential pressure is controlled.
- ◆ Unit system: Global selection of units for the entry and display of data
  - ◆ Metric (SI): N, Bar, m
  - ◆ Imperial (US/UK): N, PSI, inch
- ◆ Inversion of the direction: Inverts the direction of movement of the drives.



Definition of the sense of direction (without direction inversion): In positive direction, the cap end (A) of a cylinder is charged with pressure.

## 4.1.4. Configuring drive1

### In this chapter you can read about:

Position feedback system drive1 .....	47
Cylinder / motor selection .....	48
Load configuration drive1 .....	48

### 4.1.4.1 Position feedback system drive1

If the position feedback system is part of the cylinder / motor, it has already been parameterized in the C3HydraulicsManager and this step is not needed.  
Parameterizing a position feedback system:

#### General entries for each position feedback system:

- ◆ Inversion of the direction: Inverts the sense of direction.
- ◆ Rotatory position feedback system?

#### 'EnDat (no further entries)

#### Sine cosine & RS422 encoder

- ◆ Resolution in  $\mu\text{m}$  / bit

#### SSI:


- ◆ Resolution in  $\mu\text{m}$  / bit
- ◆ Update rate: Necessary updating time of the actual value in  $\mu\text{s}$ .
- ◆ Word length: Gives the telegram length of the sensor.
- ◆ Gray code: Sensor gray code coded yes/no.
- ◆ Synchronous system: Sensor sends data synchronously to Compax3F step yes/no
- ◆ Baud rate/step: Max. transmission rate of the path measurement system.

#### Start-Stop:

- ◆ Velocity of sound: Speed, at which the mechanical wave moves within the range of the wave guide (e.g. 2830 m/s).
- ◆ Update rate: Necessary updating time of the actual value in  $\mu\text{s}$ .

#### Analog:

- ◆ Selection of the C3f analog interface



- ◆ (2) - (1): Length path measurement system.
- ◆ (3): Minimum signal of the path measurement system.
- ◆ (4): Maximum signal of the path measurement system.

#### 4.1.4.2 Cylinder / motor selection

The selection is made from the hydraulics database. Parker cylinders or Parker motors are stored there. Furthermore you can create customer-specific cylinders/motors with the aid of the C3HydraulicsManager and then select them here. The selection of the drive is separated as follows:

- ◆ Parker Cylinder
- ◆ Customer cylinders.


##### Cylinder / motor data from the hydraulics database

A cylinder / motor can be created in the hydraulics database with or without position feedback system.

#### 4.1.4.3 Load configuration drive1

In order to make the settings of the servo controller, information on the external load is needed. The more accurately the load of the system is known, the better is the stability and the shorter is the settle-down time of the control loop. It is important to specify the minimum and maximum external load for best possible behavior under varying loads.

- ◆ With rotatory drives: as minimum and maximum external moment of inertia.
- ◆ With linear drives: as minimum and maximum external mass.
- ◆ With a fixed load, minimum = maximum load or moment is entered.
- ◆ Installation position for linear drives:  
The installation position is entered as an angle. For an upright load upwards, the installation position is  $90^\circ$ .



- ◆ Stroke length for linear drives:  
This value is not stored in the hydraulics database.

Autoryzowany dystrybutor Parker:

**ARA**

**PNEUMATIK**

53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)



### 4.1.5. Configuring drive2

The following dialogs can only be selected, if under "number of drives" 2 drives were selected.  
 Drive2 is configured as described under drive1, the selection of the path measurement system EnDat and Sine/Cosine is however not available for drive2.

#### Select operating mode (only applies for Compax3 T30 and T40; not for Compax3 lxx11)

The possible operating mode of the auxiliary axis depends on the operating mode set for the main axis


Main axis operating mode	Possible operating mode of the auxiliary axis
Pressure/Force Controller	Pressure/Force Controller
Positioning & Pressure/Force Controller	Positioning & Pressure/Force Controller or Pressure/Force Controller

### 4.1.6. Sensors


Force or pressure sensors are required for the control of force or pressure. Altogether 6 analog inputs are available for the integration of the pressure and force sensors for the drives 1 and 2 (if no analog input is used as position feedback system). Inputs that are not utilized can be used in an IEC61131-3 program (for example as setpoint input).

#### 4.1.6.1 Pressure sensors

Pressure sensors can be used for the control of pressure or force (with pressure  $P_A$  &  $P_B$ ).  
 If pressure sensors are utilized for the control of force, the resulting force is calculated via the differential pressure  $P_A - P_B$  and the ratio of major area to minor area of the cap.  
 A maximum of 4 pressure sensors per axis can be parameterized. The logic assignment of the sensors results from the following image.




- ◆ Interface:  
Select the interface where the sensor is connected. Only the freely available inputs are displayed.




- ◆ (1) pressure min.: Enter the minimum pressure.
- ◆ (2) pressure max.: Enter the maximum pressure.
- ◆ (3) Sensor signal min.: Enter the minimum signal of the pressure sensor.
- ◆ (4) Sensor signal max.: Enter the maximum signal of the pressure sensor.
- ◆ Constant pressure: If the pressure is constant, a pressure sensor is not necessary. You can then specify a constant pressure value instead.

**Example: Parameterization interface supply pressure p0**




**4.1.6.2 Force sensor drive 1**



If a force sensor is used for force control, the following parameters must be entered:

◆ Interface:

Select the interface where the sensor is connected. Only the freely available inputs are displayed.



- ◆ Force min.: Enter the minimum force (1).
- ◆ Force max.: Enter the maximum force (2).
- ◆ Sensor signal min.: Enter the minimum signal of the pressure sensor (3).
- ◆ Sensor signal max.: Enter the maximum signal of the pressure sensor (4).
- ◆ Force constant: If the force is constant, a force sensor is not necessary. You can then specify a constant force value instead.

#### 4.1.6.3 Pressure and force sensor drive 2

The following dialogs can only be selected, if under "number of drives" 2 drives were selected before.

The sensors for drive 2 are configured as described under drive 1.

#### 4.1.7. Valve configuration

Up to 4 valves can be selected. Those valves (0..3) are fixedly assigned to the analog outputs I/Uout0...3 and are assigned within the configuration to the drives 1 and 2 as well as to the position and force/pressure control loops. Not all valves must necessarily be used.

### 4.1.7.1 Selection and configuration of the valves

The selection of the respective valves is made from the hydraulics database. You can choose between Parker valves or customized valves that were created with the aid of the C3HydraulicsManager from the database.


The valves in the valve database are structured as follows:

- ◆ Parker Valves
  - ◆ Porportional direction control valves
    - ...
    - High dynamics, high repeatability
    - VCD® Dynamics, highest precision
    - D\*FP
    - ...
    - ...
  - ◆ Pressure valves
    - ◆ Pressure control valves
      - PE
      - ...
    - ◆ Pressure reducing valves
      - RE
      - ...
    - ◆ Flow-control valves
      - ...
      - TDL
      - ...
  - ◆ Other valves

#### **Input values:**

#### **Control variable limitation [min.][max.]:**

Via these parameters, the control signal of the valve is limited. This limitation is above all sensible during commissioning in order to avoid an uncontrolled movement of the axis if the parameterization is not yet optimal.



- (1) min. control variable limitation
- (2) max. control variable limitation

#### **Drive:**

Hereby you can define the assignment of the selected valve to a specific drive. This dialog comes only up, if 2 drives were selected.



**Control range of the position controller.**

The "control range" parameter

- ◆ --
- ◆ -100%...100%
- ◆ 0...100% (P -> A)
- ◆ -100%...0 (A -> T)
- ◆ 0...100% (B -> T)
- ◆ -100%...0 (P -> B)

defines the output range of the position controller for the selected valve.  
If you enter "--", the valve is not influenced by the position controller.

**Control range of the force/pressure control loop:**

The "control range" parameter

- ◆ --
- ◆ -100%...100%
- ◆ 0...100% (P -> A)
- ◆ -100%...0 (A -> T)
- ◆ 0...100% (B -> T)
- ◆ -100%...0 (P -> B)

defines the output range of the force/pressure controller for the selected valve.  
If you enter "--", the valve is not influenced by the force/pressure controller.

## 4.1.8. Defining the reference system

The reference system for positioning is defined by:

- ◆ a unit,
- ◆ the travel distance per motor revolution,
- ◆ a machine zero point with true zero,
- ◆ positive and negative end limits.

### 4.1.8.1 Position transducer

**Absolute feedback system**

**For positioning operation of two axes with a Compax3F, we recommend an absolute feedback system**

Thus the homing run after switching on, which is only possible in coupled state for 2 axes and may lead to difficulties with definedly referencing the auxiliary axis is not necessary.

### 4.1.8.2 Machine Zero

**In this chapter you can read about:**

- Positioning after homing run ..... 54
- Machine zero speed and acceleration ..... 55
- Machine zero modes overview ..... 56
- Homing modes with home switch (on X12/14) ..... 58
- Machine zero modes without home switch ..... 65
- Adjusting the machine zero proximity switch ..... 69

The Compax3 machine zero modes are adapted to the CANopen profile for Motion Control CiADS402.

**Position reference point**

Essentially, you can select between operation with or without machine reference. The reference point for positioning is determined by using the machine reference and the machine reference offset.

#### Machine reference run

In a homing run the drive normally moves to the position value 0 immediately after finding the home switch. The position value 0 is defined via the homing offset.

A machine reference run is required each time after turning on the system for operation with machine reference.



**Please note:**


**During homing run the software end limits are not monitored.**

#### Positioning after homing run


The positioning made after the home switch has been found can be switched off. For this enter in the "machine zero" window in the configuration wizard "no" under "approach MN point after MN run".

#### Example Homing mode 20 (Home on homing switch) with T40 by homing offset 0

With positioning after homing run The motor stands then on 0:



Without positioning after homing run The position reached is not exactly on 0, as the drive brakes when detecting the home and stops:



**Please note:**

**In controlled operation (open loop) no machine zero run is possible!**

**The home of the auxiliary axis is automatically set, by coupling the auxiliary axis to the main axis for the homing run!**

**Homing run for 2 axes**

- ◆ Axis 2 is coupled to axis 1 and moves along
- ◆ Axis 1 and axis 2 set the home at the same time after axis 1 has detected the homing switch

Therefore you should bring the auxiliary axis to a defined start position before the homing run.

**Or use absolute feedback systems:**

**Absolute feedback system**

**For positioning operation of two axes with a Compax3F, we recommend an absolute feedback system**

Thus the homing run after switching on, which is only possible in coupled state for 2 axes and may lead to difficulties with definedly referencing the auxiliary axis is not necessary.

**Machine zero speed and acceleration**

With these values you can define the motion profile of the machine zero run.

## Machine zero modes overview


### Selection of the machine zero modes (MN-M)

<b>Machine home switch on X12/14: MN-M 3 ... 14, 19 ... 30</b>	Without motor reference point MN-M 19 ...30	without direction reversal switches: <b>MN-M 19, 20</b> (see page 58), <b>MN-M 21, 22</b> (see page 59) with reversal switches: <b>MN-M 23, 24, 25, 26</b> (see page 60), <b>MN-M 27, 28, 29, 30</b> (see page 61)
	With motor reference point MN-M 3 ... 14	without direction reversal switches: <b>MN-M 3, 4</b> (see page 62), <b>MN-M 5, 6</b> (see page 63) with reversal switches: <b>MN-M 7, 8, 9, 10</b> (see page 64), <b>MN-M 11,12,13, 14</b> (see page 64)
<b>Without machine zero initiator on X12/14: MN-M 1, 2, 17, 18, 33 .. 35, 128, 129, 130 ... 133</b>	Without motor reference point MN-M 17, 18, 35, 128, 129	<b>MN-M 35: at the current Position</b> (see page 65) <b>MN-M 128, 129: while moving to block</b> (see page 65) With limit switch as machine zero: <b>MN-M 17, 18</b> (see page 66)
	With motor reference point	Only motor reference: <b>MN-M 33, 34</b> (see page 67), <b>MN-M 130, 131</b> (see page 67)
	MN-M 1, 2, 33, 34, 130 ... 133	With limit switch as machine zero: <b>MN-M 1, 2</b> (see page 68), <b>MN-M 132, 133</b> (see page 69)

### Definition of terms / explanations:

Motor zero point	<p>Zero pulse of the feedback</p> <p>Motor feedback systems such as resolvers or SinCos® / EnDat give one pulse per revolution.</p> <p>Some motor feedback systems of direct drives do also have a zero pulse, which is generated once or in defined intervals.</p> <p>By interpreting the motor zero point (generally in connection with the machine zero initiator) the machine zero can be defined more exactly.</p>
Machine zero initiator:	<p>For creating the mechanical reference</p> <p>Has a defined position within or on the edge of the travel range.</p>
Direction reversal switches:	<p>Initiators on the edge of the travel range, which are used only with a machine zero run in order to detect the end of the travel range.</p> <p>In some cases, the function " direction reversal via Following error threshold" is also possible, then you will need no initiator, Compax3 detects the end of the travel range via the threshold. Please observe the respective notes.</p> <p>During operation, the direction reversal switches are often used as limit switches.</p>

Example axis with the initiator signals



- 1: Direction reversal / end switch on the negative end of the travel range (the **assignment of the reversal / end switch inputs** (see page 74) to travel range side can be changed).
- 2: Machine zero initiator (can, in this example, be released to 2 sides)
- 3: Direction reversal / end switch on the positive end of the travel range (the **assignment of the reversal / end switch inputs** (see page 74) to travel range side can be changed).
- 4: Positive direction of movement
- 5: Signals of the motor zero point (zero pulse of the motor feedback)
- 6: Signal of the machine zero initiator (**without inversion of the initiator logic** (see page 74)).
- 7: Signal of the direction reversal resp. end switch on the positive end of the travel range (without inversion of the initiator logic).
- 8: Signal of the direction reversal / resp. end switch on the negative end of the travel range (without inversion of the initiator logic).
- 9: Signal of the machine zero initiator (**with inversion of the initiator logic** (see page 74)).
- 10: Signal of the direction reversal / resp. end switch on the positive end of the travel range (with inversion of the initiator logic).
- 11: Signal of the direction reversal / resp. end switch on the negative end of the travel range (with inversion of the initiator logic).
- 12: Logic state of the home switch (independent of the inversion)
- 13: Logic state of the direction reversal resp. end switch on the positive end of the travel range (independent of the inversion)
- 14: Logic state of the direction reversal resp. end switch on the negative end of the travel range (independent of the inversion)

The following principle images of the individual machine zero modes always refer to the logic state (12, 13, 14) of the switches.

**Homing modes with home switch (on X12/14)**

**In this chapter you can read about:**

Without motor reference point ..... 58  
 With motor reference point ..... 62

**Without motor reference point**

**In this chapter you can read about:**

Without direction reversal switches ..... 58  
 With direction reversal switches ..... 60

**Without direction reversal switches**

**In this chapter you can read about:**

MN-M 3.4: MN-Initiator = 1 on the positive side ..... 62  
 MN-M 5.6: MN initiator = 1 on the negative side ..... 63

**In this chapter you can read about:**

MN-M 19.20: MN-Initiator = 1 on the positive side ..... 58  
 MN-M 21.22: MN initiator = 1 on the negative side ..... 59

**MN-M 19.20: MN-Initiator = 1 on the positive side**


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

**Without motor zero point, without direction reversal switches**

**MN-M 19:**The negative edge of the MN proximity switch is used directly as MN (home) (the motor zero point remains without consideration).

**MN-M 20:**The positive edge of the MN proximity switch is used directly as MN (home) (the motor zero point remains without consideration).



**MN-M 21.22: MN initiator = 1 on the negative side**


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

**Without motor zero point, without direction reversal switches**

**MN-M 21:** The negative edge of the MN proximity switch is used directly as MN (home) (the motor zero point remains without consideration).

**MN-M 22:** The positive edge of the MN proximity switch is used directly as MN (home) (the motor zero point remains without consideration).



**With direction reversal switches**

**In this chapter you can read about:**

MN-M 1, 2: Limit switch as machine zero ..... 68  
 MN-M 132, 133: Determine absolute position via distance coding with direction reversal switches ..... 69

**In this chapter you can read about:**


MN-M 7...10: Direction reversal switches on the positive side ..... 64  
 MN-M 11...14: With direction reversal switches on the negative side ..... 64

**In this chapter you can read about:**

MN-M 23...26: Direction reversal switches on the positive side ..... 60  
 MN-M 27...30: With direction reversal switches on the negative side ..... 61  
 Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.  
 The **assignment of the direction reversal switches** (see page 74) can be changed.

**Function Reversal via Following error threshold**

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Following error threshold"  
 Here the drive runs towards the mechanical limit mounted at the end of the travel range.  
 When the settable Following error threshold is reached, the drive is braked and changes the travel direction.


	<p><b>Caution!</b>                  Wrong settings can cause hazard for man and machine.</p>
--	--

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.

**MN-M 23...26: Direction reversal switches on the positive side**

Without motor zero point, with direction reversal switches




1: Logic state of the home switch  
 2: Logic state of the direction reversal switch



**MN-M 27...30: With direction reversal switches on the negative side**

Without motor zero point, with direction reversal switches



- 1: Logic state of the home switch
- 2: Logic state of the direction reversal switch

**With motor reference point**

**In this chapter you can read about:**

Without direction reversal switches ..... 62  
 With direction reversal switches ..... 63

**Without direction reversal switches**

**MN-M 3.4: MN-Initiator = 1 on the positive side**


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

**With motor zero point, without direction reversal switches**

**MN-M 3:** The 1st motor zero point with MN initiator = "1" is used as MN.

**MN-M 4:** The 1st motor zero point with MN initiator = "1" is used as MN.




- 1: Motor zero point
- 2: Logic state of the home switch

**MN-M 5.6: MN initiator = 1 on the negative side**

The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).  
 When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

**With motor zero point, without direction reversal switches**

**MN-M 5:**The 1st motor zero point with MN proximity switch = "0" is used as MN.  
**MN-M 6:**The 1st motor zero point with MN initiator = "1" is used as MN.




1: Motor zero point  
 2: Logic state of the home switch

**With direction reversal switches**

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.  
 The **assignment of the direction reversal switches** (see page 74) can be changed.

**Function Reversal via Following error threshold**

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Following error threshold"  
 Here the drive runs towards the mechanical limit mounted at the end of the travel range.  
 When the settable Following error threshold is reached, the drive is braked and changes the travel direction.

	<p><b>Caution!</b>                  Wrong settings can cause hazard for man and machine.</p>
---	--


It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.

**With motor zero point, with direction reversal switches**

**MN-M 7...10: Direction reversal switches on the positive side**

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.




- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

**With motor zero point, with direction reversal switches**

**MN-M 11...14: With direction reversal switches on the negative side**

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.



- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

**Machine zero modes without home switch**

**In this chapter you can read about:**

Without motor reference point ..... 65  
 With motor reference point ..... 67

**Without motor reference point**

**In this chapter you can read about:**

MN-M 35: MN at the current position ..... 65  
 MN-M 128/129: Following error threshold when moving to block ..... 65  
 MN-M 17.18: Limit switch as machine zero ..... 66

**MN-M 35: MN at the current position**

The current position when the MN run is activated is used as an MN.



**MN-M 128/129: Following error threshold when moving to block**

Without a MN (machine zero) initiator, an end of travel region (block) is used as MN (machine zero).

For this the Following error threshold is evaluated if the drive pushes against the end of the travel region. If the limit is exceeded, the MN is set. During the homing run (MN), the error reaction "following error" is deactivated.

**Please observe:**


The homing offset must be set so that the home (reference point) for positioning lies within the travel range.

**MN-M 128: Travel in the positive direction to the end of the travel region**




**MN-M 129: Travel in the negative direction to the end of the travel region**



	<p><b>Caution!</b>                  Wrong settings can cause hazard for man and machine.</p>
---	--

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.

**MN-M 17.18: Limit switch as machine zero**

1: Logic state of the direction reversal switch

**Function Reversal via Following error threshold**

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Following error threshold"

Here the drive runs towards the mechanical limit mounted at the end of the travel range.

When the settable Following error threshold is reached, the drive is braked and changes the travel direction.

**Caution!**

Wrong settings can cause hazard for man and machine.

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.

**With motor reference point**

**In this chapter you can read about:**

Machine zero only from motor reference ..... 67  
 With direction reversal switches ..... 68

**Machine zero only from motor reference**

**In this chapter you can read about:**

MN-M 33,34: MN at motor zero point ..... 67  
 MN-M 130, 131: Determine absolute position via distance coding ..... 67


**MN-M 33,34: MN at motor zero point**

The motor reference point is now evaluated (no MN initiator):

**Without home switch**

**MN-M 33:** For a MN run, starting from the current position, the next motor zero point in the negative travel direction is taken as the MN.

**MN-M 34:** For a MN run, starting from the current position, the next motor zero point in the positive travel direction is taken as the MN.



1: Motor zero point

**MN-M 130, 131: Determine absolute position via distance coding**

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).



1: Signals of the distance coding

### With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see page 74) can be changed.

### Function Reversal via Following error threshold

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Following error threshold"

Here the drive runs towards the mechanical limit mounted at the end of the travel range.

When the settable Following error threshold is reached, the drive is braked and changes the travel direction.



#### Caution!


Wrong settings can cause hazard for man and machine.

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.

### MN-M 1, 2: Limit switch as machine zero


#### End switch on the negative side



1: Motor zero point

2: Logic state of the direction reversal switch

#### End switch on the positive side:



1: Motor zero point


2: Logic state of the direction reversal switch



**MN-M 132, 133: Determine absolute position via distance coding with direction reversal switches**

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).




1: Signals of the distance coding  
2: Logic state of the direction reversal switches

**Adjusting the machine zero proximity switch**

This is helpful in some cases with homing modes that work with the home switch and motor reference point.

If the motor reference point happens to coincide with the position of the MN initiator, there is a possibility that small movements in the motor position will cause the machine reference point to shift by one motor revolution (to the next motor reference point).



1: Motor zero point  
2: Logic state of the home switch

A solution to this problem is to move the MN initiator by means of software. This is done using the value initiator adjustment.

**Initiator adjustment**

Unit: Motor angle in degrees	Range: -360 ... 360	Standard value: 0
Move the machine reference initiator using software		

### 4.1.8.3 Travel Limit Settings

#### Please note:

**Both the software and the hardware end limits are the same for the main axis and the auxiliary axis!**

#### Software end limits

The error reaction when reaching the software end limits can be set:


Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

If "no reaction" was set, no software limits must be entered.

#### Software end limits:

The travel range is defined via the negative and positive end limits.




1: negative end limit

2: positive end limit

#### Software end limit in absolute operating mode

The positioning is restricted to the range between the travel limits.

A positioning order aiming at a target outside the travel range is not executed.



1: negative end limit

2: positive end limit

The reference is the position reference point that was defined with the machine reference and the machine reference offset.

#### Software end limits in reset mode

The reset mode does not support software end limits

**Software end limit in continuous mode**

Each individual positioning is confined within the travel limits.  
 A positioning order aiming at a target outside the software end limits is not executed.  
 The reference is the respective current position.

**Error when disregarding the software end limits**

A software end limit error is triggered, if the position value exceeds an end limit.  
 For this, the position setpoint value is evaluated in energized state; in currentless state, the actual position value is evaluated.

**Hysteresis in disabled state:**

If the axis stands currentless at an end limit, another error may be reported due to position jitter after acknowledging the end limit error. To avoid this, a hysteresis surrounding the end limits was integrated (size corresponds to the size of the positioning window).  
 Only if the distance between axis and the end limits was larger than the positioning window, another end limit error will be detected

Error codes of the end limit errors:

- 0x7323 Error when disregarding the positive software end limit.
- 0x7324 Error when disregarding the negative software end limit.

**Activating / deactivating the end limit error:**

In the C3 ServoManager under configuration: End limits, the error can be (de)activated.  
 For IEC-programmable devices with the "C3\_ErrorMask" module.

**Behavior after the system is turned on**


The end limits are not active after switching on. The end limits do not refer to the position reference point until after a machine reference run.  
 During homing run the end limits are not monitored.  
 With a Multiturn encoder or with active Multiturn emulation, the limit is valid immediately after switching on.

**Behavior outside the travel range**

**1. If the software end limit errors are deactivated, all movements are possible.**

**2. if the software end limit errors are activated:**

After disregarding the software end limits, an error is triggered. First of all, this error must be acknowledged.  
 Then a direction block is activated: only motion commands in the direction of the travel range are executed. These will not trigger another error.  
 Motion commands inciting a movement in the opposite direction of the travel range are blocked and will trigger another error.



- 1: negative end limit
- 2: positive end limit

**Notes on special feedback systems (Feedback F12)**

During automatic commutation, the end limit monitoring is deactivated!

**Behavior with software end limits of a referenced axis**

	<b>Position within target outside</b>	<b>Position outside target outside and aiming in the opposite direction of the travel range</b>	<b>Position outside target within and aiming in the direction of the travel range</b>
<b>JOG +/-</b>	<ul style="list-style-type: none"> <li>◆ Positioning up to the end limits</li> <li>◆ No Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ No Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ Positioning</li> </ul>
<b>MC_MoveAbsolute, MC_MoveRelative, MC_MoveAdditive, MC_MoveSuperImposed</b>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ Positioning</li> </ul>
<b>MC_GearIn, MC_Cam..., C3_Cam...</b>	<ul style="list-style-type: none"> <li>◆ Positioning up to the end limits, from these on braking with the error ramp. The end limit is exceeded</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ Error</li> </ul>
<b>MC_MoveVelocity</b>	<ul style="list-style-type: none"> <li>◆ Positioning up to the end limits</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ No positioning</li> <li>◆ Error</li> </ul>	<ul style="list-style-type: none"> <li>◆ Positioning</li> </ul>
<b>MC_Home</b>	◆ No monitoring of the software end limits		


The software end limit error can be deactivated in general via the configuration or separately for each end limit via the C3\_Error\_Mask f module.

## Hardware end limits

The error reaction when reaching the hardware end limits can be set:  
Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

Hardware end limits are realized with the aid of end switches. These are connected to X12/12 (input 5) and X12/13 (input 6) and can be (de)activated separately in the C3 ServoManager under Configuration: End limits. After a limit switch has been detected, the drive decelerates with the ramp values set for errors (error code 0x54A0 at X12/12 active, 0x54A1 at X12/13 active) and the motor is switched to currentless. Please make sure that after the detection of the end switch there is enough travel path left up to the limit stop.



- 1: Limit switch E5 (X12/12)  
2: Limit switch E6 (X12/13)  
3: Limit switch position E5 (X12/12)  
4: Limit switch position E6 (X12/13)

The **assignment of the end switches** (see page 74) can be changed!

**Please note:** The limit switches must be positioned so that they cannot be released towards the side to be limited.

**Limit switch / direction reversal switch**  
**Behavior in the case of an active limit switch**

Limit switches functioning as direction reversal switches during homing run, will not trigger a limit switch error.

The error can be acknowledged with activated limit switch.  
The drive can then be moved out of the end switch range with a normal positioning.  
Both directions of movement are possible.  
A direction block can be programmed in the IEC program with the aid of the limit switch bits or the error message.

**(De)activate limit switch errors**

The end limit error can be deactivated in general via the configuration or separately for each end limit via the C3\_Error\_Mask module.

#### 4.1.8.4 Change assignment direction reversal / limit switches

If this function is not activated, the direction reversal / end switches are assigned as follows:

Direction reversal / limit switch on E5 (X12/12): negative side of the travel range  
 Direction reversal / limit switch on E6 (X12/13): Direction reversal / limit switch on E6 (X12/13):

#### Change assignment of direction reversal / limit switch is activated

If this function is activated, the direction reversal / limit switches are assigned as follows:

Direction reversal / limit switch on **E5** (X12/12): **positive side** of the travel range  
 Direction reversal / limit switch on **E6** (X12/13): **negative side** of the travel range

#### 4.1.8.5 Change initiator logic

The initiator logic of the limit switches (this does also apply for the direction reversal switches) and the machine zero initiator can be changed separately.

- ◆ Limit switch E5 low active
- ◆ Limit switch E6 low active
- ◆ Home switch E7 low active

In the basic settings the inversion is deactivated, so that the signals are "high active".

With this setting the inputs I5 to I7 can even be switched within their logic, if they are not used as direction reversal/limit switches or machine zero.

#### 4.1.8.6 Debouncing: Limit switch, machine zero and input 0

A majority gate is used for debouncing.

The signal is sampled every 0.5ms

The debounce time determines the number of scans the majority gate will perform. If the level of more than half of the signals was changed, the internal status will change.


The debounce time can be set in the configuration wizard within the range of 0 ... 20ms.

The value 0 deactivates the debouncing.

If the debouncing time is stated, the input I0 can be debounced as well (checkbox below).

#### 4.1.9. Ramp upon error and switch to currentless

##### Ramp (deceleration) upon error and "switch to currentless"



3: Deceleration upon error and upon deactivation of **MC\_Power** (see page 165)

##### Please observe:

The configured error ramp is limited. The error ramp will not be smaller than the deceleration set in the last motion set.

## 4.1.10. Limit and monitoring settings of force

**In this chapter you can read about:**

Force window - force achieved ..... 75  
 Maximum control deviation of force controller ..... 76  
 Maximum force ..... 76  
 Hydraulic corner power limitation ..... 76

**Please note:**

**Limit and monitoring settings are the same for the main axis as well as for the auxiliary axis!**


### 4.1.10.1 Force window - force achieved

"Force achieved" indicates that the actual force is within the tolerance window of the setpoint force. In addition to the force window, a force window time is supported. If the actual force goes inside the force window, the force window time is started.

If the actual force is still within the force window after the force window time, "force achieved = 1" will be set.

If the actual force leaves the force window within the force window time, the force window time is started again. When leaving the force window, "force achieved" is set immediately to "0".

The force monitoring is even active, if the force leaves the force window due to external measures.



- 1: Force window
- 2: Force window time
- 3: Setpoint force reached (== object ForceAccuracy\_ForceReached)

**Linkage to the setpoint value**


The signal "force attained" can be linked to the setpoint value.

In addition, the internal setpoint value generation is evaluated.

It applies: **The force window is only evaluated with a constant internal setpoint value.**

**4.1.10.2 Maximum control deviation of force controller**

The force control deviation is a dynamic error. The dynamic difference between the setpoint force and the actual force during a force control is called the force control deviation. Do not confuse this with the static difference which is always 0; the target force is always achieved exactly. If the force control deviation exceeds the given limit (max. control deviation of force controller), the "time window" elapses. If the force control deviation after the time window still exceeds the threshold, an error is reported. If the force control deviation is below the threshold, the time window is started anew.




- 1: max. control deviation of force controller
- 2: time window force control deviation
- NO ERROR: Error output of positioning modules
- QUIT: Ackn with MC\_Reset module

**4.1.10.3 Maximum force**

if the "maximum force" is exceeded, an error is reported. This monitoring is only active, if pressure sensors are present for pA and / or pB.

**4.1.10.4 Hydraulic corner power limitation**

The hydraulic corner power is calculated from the differential pressure between p0 and pA or pB. If pressure sensors are present for pA as well as for pB, both differential pressures are evaluated.





The corner power limitation can only be activated, if at least one pressure sensor for pA or pB and p0 was parameterized before.

**Note:**

- ◆ Currently, the corner power is calculated; which must however, if necessary, be limited in the IEC program!  
the corner power can be read from the objects C3.HydraulicPower\_Axis1, C3.HydraulicPower\_Axis2 and C3.HydraulicPower\_Sum.  
the unit is [W]; this means that the standardization is only correct for the metric system.
- ◆ The hydraulic power is calculated from the units bar and l/min according to the following equation:

$$P[kW] = \frac{\Delta p[bar] \cdot Q[l/min]}{600}$$

#### 4.1.11. Positioning window - Position reached


Position reached indicates that the target position is located within the position window.

In addition to the position window, a position window time is supported. If the actual position goes inside the position window, the position window time is started. If the actual position is still inside the position window after the position window time, "Position reached" is set.

If the actual position leaves the position window within the position window time, the position window time is started again.

When the actual position leaves the position window with Position reached = "1", Position reached is immediately reset to "0".

Position monitoring is active even if the position leaves the position window because of measures taken externally.



- 1: Positioning window  
 2: positioning window time  
 3: Setpoint position reached (== object 420.6 C3.PositioningAccuracy\_PositionReached)

### 4.1.12. Following error limit

The error reaction upon a following error can be set:

Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

The following error is a dynamic error.

The dynamic difference between the setpoint position and the actual position during a positioning is called the following error. Do not confuse this with the static difference which is always 0; the target position is always reached exactly.

The change of position over time can be specified exactly using the parameters jerk, acceleration and speed. The integrated Setpoint value generator calculates the course of the target position. Because of the delay in the feedback loop, the actual position does not follow the setpoint position exactly. This difference is referred to as the following error.

#### Disadvantages caused by a following error

In joint operation of several servo controllers (e.g. master controller and slave controller), following errors lead to problems due to the dynamic position differences, and a large following error can lead to positioning overshoot.


#### Error message

If the following error exceeds the specified following error limit, the "following error time" then expires. If the following error is even greater than the following error limit at the end of the following error time, an error is reported.

If the following error falls short of the following error limit, a new following error time is then started.

#### Minimizing the following error

The following error can be minimized with the help of the extended (advanced) control parameters, in particular with the feed forward parameters.



1: Following error limit [parameterized unit]

2: Tracking error time

**ERROR:**Error output of positioning modules

**QUIT:**Ackn with MC\_Reset module

### 4.1.13. Maximum permissible speed

The limitation of the speed controller is deduced from the maximum permissible speed. In order to ensure control margins, the speed is limited to a higher value.

The speed setpoint value is actively limited to 1.1 times the given value.

If the speed actual value exceeds the preset maximum permissible speed by 21% (= "switching off limit speed"), error 0x7310 is triggered.

#### 4.1.14. Encoder Simulation

You can make use of a permanently integrated encoder simulation feature to make the actual position value available to additional servo drives or other automation components.

**Caution!**

- ◆ The encoder simulation is not possible at the same time as the encoder input resp. the step/direction input or the SSI interface.  
The same interface is used here.
- ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.  
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.

#### Simulated Encoder Output Resolution

Unit: Increments per 500mm*	Range: 4 - 16384	Standard value: 1024
Any resolution can be set		
<b>Limit frequency: 620kHz</b> i. e. for:		
Increments per 500mm	max. velocity	
1024	30m/s	
4096	7.5m/s	
16384	1.8m/s	


\* or with a rotary feedback travel per feedback rotation

### 4.1.15. Recipe table

If you would like to work with the **recipe array** (see page 157), (e.g. for the storage of variable machine data) you can make preassignments in it with Compax3 ServoManager.

**Note:**

The recipe array can also be loaded separately into the device (>button on the right side).



### 4.1.16. Error response

Under "configuring: Under "configuration: error reaction" you can change the error reaction for individual errors (the error no. which can be influenced is displayed). Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

### 4.1.17. Configuration name / comments

Here you can name the current configuration as well as write a comment.  
Then you can download the configuration settings or, in T30 or T40 devices,  
perform a complete Download (with IEC program and curve).

**Caution!**

Deactivate the drive before downloading the configuration software!

**N.B.!**

Incorrect configuration settings entail danger when activating the drive.  
Therefore take special safety precautions to protect the travel range of  
the system.

**Mechanical limit values!**

Observe the limit values of the mechanical components!

Ignoring the limit values can lead to destruction of the mechanical  
components.

## 4.2 Configuring the signal source

### In this chapter you can read about:

Physical Source.....	82
Internal virtual master.....	85
HEDA Master signal source .....	85

### Possible master signal sources

Under the tree entry "Configuring the signal source" of the C3 ServoManager you can configure 3 signal sources for Master – Slave applications.

The master signal source can then be selected in the IEC program with the aid of the **C3\_MasterControl** (see page 237) module via the input "Master".

3 signal sources are available:

- ◆ Physical Source
  - ◆ analog value above +/-10V
  - ◆ Encoder signal A/B (5V)
  - ◆ Step/Direction signal (5V)
  - ◆ SSI Feedback
- ◆ Internal virtual master (IEC program) (only T40)
- ◆ HEDA

the "use as current signal source" CheckBox can be found in the signal source configuration wizards.

This CheckBox is only relevant for the Compax3 firmware versions < V2.05; it is used to define the signal source for the CoDeSys program.

Otherwise, the signal source is directly selected at the IEC module.

### Signal source of the load feedback system

Configuration of the load control (Dual Loop Option)

### 4.2.1. Physical Source

#### In this chapter you can read about:

Encoder A/B 5V, step/direction or SSI feedback as signal source.....	82
+/-10V Master speed .....	85

#### 4.2.1.1 Encoder A/B 5V, step/direction or SSI feedback as signal source

#### Caution!

- ◆ The encoder simulation is not possible at the same time as the encoder input resp. the step/direction input or the SSI interface.  
The same interface is used here.
- ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.  
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.

The dimensional reference to the master is established via the following settings:

- ◆ Travel path per motor revolution master axis numerator = 50mm or with a rotary feedback system: Travel per feedback revolution.

With denominator = 1 the value can be entered directly.

Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.

- ◆ Increments per revolution of the master axis

If required the direction of rotation of the master axis read in can be changed.

**Example: Electronic gearbox with position detection via encoder**

**Reference to master axis**

The reference to the master axis is established via the increments per revolution and the travel path per revolution of the master axis (corresponds to the circumference of the measuring wheel).

That is:

$$\text{MasterPos} = \frac{\text{Master\_I}}{\text{I\_M}} * \frac{\text{Travel Distance per Master Axis revolution (M\_Units/rev)}}{\text{Travel Distance per Master Axis revolution - Denominator}} \quad (1)$$

MasterPos: Master Position

Master\_I: master increments read in

I\_M: Increments per revolution of the master axis

**External signal source**

Encoder with 1024 increments per master revolution and a circumference of the measuring wheel of 40mm.

**Settings:**

Travel path per revolution of the master axis numerator = 40

Travel path per revolution of the master axis denominator = 1

Increments per revolution of the master axis = 1024

**Configuration wizard:**

Reference system of Slave axis: Unit of measure [mm]

Travel path per revolution numerator = 1

Travel path per revolution denominator = 1

**Gearing:**

Gearing numerator = 2

Gearing denominator = 1

**This results in the following interrelations:**

If the measuring wheel moves by 40mm (1 master revolution), the slave axis will move by 80mm.


$$\text{Slave unit} = \text{MasterPos} * \frac{\text{Gearing numerator}}{\text{Gearing denominator}} \quad (2)$$

(1) set into (2) and with numerical values results with 1024 increments read in (=1 Master revolution):

$$\text{Slave unit} = 1024 * \frac{1}{1024} * \frac{40\text{mm}}{1} * \frac{2}{1} = 80\text{mm}$$

Master - Position = +40mm => Slave - Position = +80mm

**Structure:**



Detailed structure image with:

$$MD = \frac{Z1}{N1} * \frac{\text{Travel Distance per Master Axis revolution (M_Units/rev)}}{\text{Travel Distance per Master Axis revolution - Denominator}}$$

Entry in the "configuration of the signal source" wizard

$$SD = \frac{Z2}{N2} * \frac{\text{Travel path per revolution slave axis numerator}}{\text{Travel path per revolution slave axis denominator}}$$

Entry in the "configuration of the signal source" wizard

- MD:** Feed of the master axis
- SD:** Feed of the slave axis

**SSI configuration**

**Notes on the SSI sensor (see page 84)**


- ◆ With Multiturn: Number of sensor rotations with absolute reference
- ◆ Word length: Gives the telegram length of the sensor.
- ◆ Baud rate/step: Max. transmission rate of the path measurement system.
- ◆ Gray code: Sensor gray code coded yes/no (if no binary coded).

**Note:**

The absolute position is not evaluated!  
 It is available in the objects 680.24 (load position) and 680.25 (master position) (C3T30, C3T40).

**General requirements for supported SSI feedbacks**

- ◆ Baud rate: 350k ... 5MBaud
- ◆ Word length: 8 ... 32 Bit
- ◆ Binary or gray code (start value = 0)
- ◆ Initialization time after PowerOn: < 1.1s
- ◆ Signal layout:





The most significant bit must be transmitted the first!

**Caution!** Feedback systems, transmitting data containing error or status bits are not supported!

◆ Examples of supported SSI feedback systems:

- ◆ IVO / GA241 SSI;
- ◆ Thalheim / ATD 6S A 4 Y1;
- ◆ Hübner Berlin / AMG75;
- ◆ Stegmann / ATM60 & ATM90;
- ◆ Inducoder / SingleTurn: EAS57 & Multiturn: EAMS57

#### 4.2.1.2 +/-10V Master speed

Via Analog channel 4 (X11/17 and X1/18) the speed of the master is read in. From this value a position is internally derived.

The reference to the master is established with the velocity at 10V.


If required the direction of rotation of the master axis read in can be changed.

#### Time grid of master signal source

Averaging and a following filter (interpolation) can help to avoid steps caused by discrete signals.

If the external signal is analog, there is no need to enter a value here (Value = 0).

For discrete signals e.g. from a PLC, the scanning time (or cycle time) of the signal source is entered.



This function is only available if the analog interface +/-10V is used!

### 4.2.2. Internal virtual master

#### In this chapter you can read about:

The reset distance of the virtual master is only used for resetting the displayed value (Object680.2).

The travel per motor revolution of the master axis (numerator/denominator) is set to 1 for a virtual master.

If required the direction of rotation of the master axis read in can be changed.

### 4.2.3. HEDA Master signal source

Please choose if the virtual master of the HEDA master is transmitted via the HEDA.

If yes, the input "travel per revolution" is not necessary, as a positioning signal is already present.

The dimensional reference to the master is established via the following settings:

- ◆ Travel path per motor revolution ( or pitch for linear motors) master axis numerator

With denominator = 1 the value can be entered directly.

Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.

- ◆ Travel per motor revolution (or pitch ofr linear motors) master axis denominator

If required the direction of rotation of the master axis read in can be changed.

## 4.3 Optimization

### In this chapter you can read about:


Optimization window.....	88
Scope .....	89
Control Loop Dynamics .....	97
Input simulation .....	147
Setup mode .....	149
ProfileViewer for the optimization of the motion profile .....	150

- ◆ Select the entry "**Optimization**" in the tree.
- ◆ Open the optimization window by clicking on the "**Optimization Tool**" button.

### 4.3.1. Optimization window

#### Layout and functions of the optimization window

Segmentation	Functions (TABs)
Window 1:	◆ <b>Scope</b> (see page 89)
Window 2:	◆ <b>Optimization: Controller optimization</b> (see page 97)
	◆ <b>D/A Monitor</b> (see page 427): Output of status values via 2 analog outputs
	◆ Scope Settings
Window 3:	◆ Status Display
	◆ Compax3 Error History
Window 4:	◆ Status values
	◆ Commissioning: Setup mode with load identification
	◆ Parameters for commissioning, test movements (relative & absolute) and for load identification.



### 4.3.2. Scope

**In this chapter you can read about:**


Monitor information..... 89  
 User interface ..... 90  
 Example: Setting the Oscilloscope..... 95

The integrated oscilloscope function features a 4-channel oscilloscope for the display and measurement of signal images (digital and analog) consisting of a graphic display and a user interface.

**Special feature:**

in the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement into the ServoManager later.

#### 4.3.2.1 Monitor information








- 1: Display of the trigger information
- 2: Display of the operating mode and the zoom setting
- ◆ 2a: Green indicates, that a measurement is active (a measurement can be started or stopped by clicking here).
- ◆ 2b: Active channel: the active channel can be changed sequentially by clicking here (only with valid signal source).
- 3: Trigger point for Single and Normal operating mode
- 4: Channel information: Type of display and trigger setting
- 5: X-DIV: X deviation set
- 6: Single channel sources

**Cursormodes/ -functions**

Depending on the operating mode, different cursor functions are available within the osci monitor.

The functions can be changed sequentially by pressing on the right mouse button.


Cursor Symbol	Function
	Set Marker 1 the measurement values of the active channel as well as the y difference to marker 2 are displayed
	Set Marker 2
	Delete and hide marker
	Move offset of the active channel. The yellow symbol indicates that the scrolling is active.
	Set trigger level and pretrigger

In the ROLL operating mode, marker functions and set trigger level positions are not available.

**4.3.2.2 User interface**

In this chapter you can read about:

Oscilloscope operating mode switch: .....	91
Setting the time basis XDIV .....	91
Settings for channels 1..4 .....	92
Trigger settings .....	93
Special functions .....	93



- 1: **Operating mode switch** (see page 91) (Single / Normal / Auto / Roll)
- 2: **Setting the time basis** (see page 91)
- 3: Starting / Stopping the measurement (prerequisites are valid channel sources and if necessary valid trigger settings.)
- 4: **Setting channel** (see page 92) (Channels 1 ...4)
- 5: **Special functions** (see page 93) (Color settings; memorizing settings and measurement values)
- 6: Loading a measurement from Compax3: in the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement later.
- 7: **Setting triggering** (see page 93)
- 8: Copy osci display to clipboard
- 9: Zoom of the osci display (1, 2, 3, 8, 16 fold) with the possibility to move the zoom window (<,>)

### Oscilloscope operating mode switch:

#### Oscilloscope operating mode switch:



Selection of the desired operating mode: SINGLE, NORMAL; AUTO and ROLL by clicking on this button.

Changing the operating mode is also permitted during a measurement. The current measurement is interrupted and started again with the changed settings.

The following operating modes are possible:


Operating mode	Short description
SINGLE	Single measurements of 1-4 channels with trigger on a freely selectable channel
NORMAL	Like Single, but after each trigger event, the measurement is started again.
AUTO	No Trigger. Continuous measuring value recording with the selected scanning time or XDIV setting
ROLL	Continuous measuring value recording of 1 .. 4 channels with selectable scanning time and a memory depth of 2000 measuring values per channel.

With SINGLE / NORMAL / AUTO, the measurement is made in Compax3 and is then loaded into the PC and displayed.

With ROLL, the measuring values are loaded into the PC and displayed continuously.

### Setting the time basis XDIV

Setting the time basis XDIV



Depending on the selected operating mode, the time basis can be changed via the arrow keys.



For the operating modes **SINGLE**, **NORMAL** and **AUTO**, the following **XDIV** time settings are possible:


XDIV	Mode	Scanning time	Samples DIV/TOTAL	Measuring time
0.5ms	1	125us	4/40	5ms
1.0ms	2	125µs	8/80	10ms
2.0ms	3	125µs	16/160	20ms
5.0ms	4	125µs	40/400	50ms
10.0ms	5	125µs	80/800	100ms
20.0ms	6	250µs	80/800	200ms
50.0ms	7	625µs	80/800	500ms
100.0ms	8	1.25ms	80/800	1s
200.0ms	9	2.50ms	80/800	2s
500.0ms	10	6.25ms	80/800	5s
1s	11	12.50s	80/800	10s
2s	12	25.00ms	80/800	20s
5s	13	62.50ms	80/800	50s
10s	14	125.00ms	80/800	100s

For the operating **ROLL**, the following **XDIV** time settings are possible:

XDIV	Mode	Scanning time	Samples DIV/TOTAL
2 ms	54	125us	200/2000
2ms	54	125µs	200/2000
4ms	55	125µs	200/2000
10ms	56	125µs	200/2000
20ms	57	125µs	200/2000
40ms	58	125µs	200/2000
100ms	59	250µs	200/2000
200ms	60	625µs	200/2000

Changing the time basis is also permitted during an OSCI measuring sequence. This means, however, that the current measurement is interrupted and started again with the changed settings.

#### Settings for channels 1..4



#### 1: Select channel color

#### 2: Open menu for channel-specific settings

- ◆ **Reset Channel CH 1..4** all channel settings are deleted.  
Please note: Channels can only be filed with sources one after the other. It is, for example, not possible to start a measurement which has only a signal source for channel 2!
- ◆ **Select channel color:** Here you can change the color of the channel..
- ◆ **show/hide channel:** Hide/show display of the channel.
- ◆ **Change logic display mask:** Mask bits in logic display.
- ◆ **auto scaling** Calculation of YDIV and Offset: The program calculates the best settings for YDIV and channel offset in order to display the complete signal values optimally.



**3: Set signal source with object name, number and if necessary unit**


- ◆ Define source: Draw the desired status object with the mouse (drag & drop) from the "Status value" window (right at the bottom) into this area.

**4: Set Channel offset to 0****5: Select channel display (GND, DC, AC, DIG)**

- ◆ **DC**: Display of the measurement values with constant component
- ◆ **AC**: Display of the measurement values without constant component
- ◆ **DIG**: Display of the individual bits of an INT signal source.  
The displayed bits can be defined via the logic display mask.
- ◆ **GND**: A straight line is drawn on the zero line.

**6: Set Y-amplification (YDIV)**

Change of the Y amplification YDIV in the stages 1,2,5 over all decades.  
Arrow upwards increases YDIV, arrow downwards diminishes YDIV.  
the standard value is 1 per DIV.  
The measurement value of the channel at the cursor cross is displayed.


**Trigger settings**


Select trigger channel: Buttons C1, C2, C3, C4

Select trigger mode: DC, AC, DG

Select trigger edge: rising  $\nearrow$  or falling  $\searrow$

the pretrigger as well as the trigger level are set by clicking on the trigger cursor

() directly in the OSCI display.

**Special functions**

Menu with special oscilloscope functions such as memorizing or loading settings.

**Functions:**

- ◆ **Select background color:** Adapt background color to personal requirements.
- ◆ **Select grid color:** Adapt grid color to personal requirements.
- ◆ **Memorize OSCI settings in file:** The settings can be memorized in a file on any drive. The file ending is \*.OSC.
- ◆ The format corresponds to an INI file and is presented in the appendix.
- ◆ **open OSCI settings from file.** Loading a memorized set of settings. The file ending is \*.OSC.
- ◆ **Memorizing OSCI settings in the project:** Up to four sets of OSCI settings can be memorized in the current C3 ServoManager project. .
- ◆ **open OSCI settings from project.** If settings were memorized in the project, they can be read in again.
- ◆ **Memorize OSCI measurement in file:** Corresponds to memorizing the setting; the measurement values of the measurement are stored in addition. Thus it is possible to memorize and read measurements completely with settings. The file ending is \*.OSM.
- ◆ **Exporting measurement values into a CSV file:** e.g. for reading into Excel.

**4.3.2.3 Example: Setting the Oscilloscope**

**SINGLE measurement with 2 channels and logic trigger on digital inputs**

The order of the steps is not mandatory, but provides a help for better understanding.  
 As a rule, all settings can be changed during a measurement. This will lead to an automatic interruption of the current measurement and to a re-start of the measurement with the new settings:

**Assumption: A test movement in the commissioning mode is active.**

1.) Select OSCI operating mode



2.) Select Time basis XDIV



3.) Select channel 1 signal source digital inputs 120.2 from status tree with the aid of Drag & Drop

4.) Select channel 2 (filtered actual speed) via "Drag and drop" from the status tree

5.) Set trigger to channel 1 and DG.

Input of the mask in HEX  
 Triggering a rising edge to input I1.  
 BIT 0 (value 1) = I0  
 BIT 1 (value 2) = I1  
 BIT 2 (value 4) = I2 etc.

<b>Trigger to input</b>	I0	I1	I2	I3	I4	I5	I6	I7
<b>Trigger mask in hex</b>	1	2	4	8	10	20	40	80

The masks can also be combined so that the trigger is only active, if several inputs are active. Example: Triggering to I2 and I5 and I6 -> 4h + 20h + 40h = 64h  
 The mask for input I1 is in this case 2.  
 select rising edge.

Note: If the trigger mask DG (digital) is selected for a channel, the display mode of the trigger channel is automatically set to DIG display.


6.) Start measurement

7.) Set pretrigger in the OSCI window

Note: There is no level for the DIG trigger The the event limit determines the mask  
 If a trigger event occurs, the measurement values are captured until the measurement is completed.

Afterwards, the measurement values are read from the Compax3 and displayed.  
 The display mask of trigger channel 1 was not yet limited, therefore it shows all 16 bit tracks (b0...b15). In order to limit it to 8 bit tracks, you must call up the menu for channel 1 via [CH1] and select "change logic of display mask [H].  
 Limit the display mask to 8 bit tracks with Mask FFh.  
 In the display the bit tracks b0 to b7 are now shown:

**Example: Only b0 and b1 are to be displayed: Set display mask to 03**



### 4.3.3. Control Loop Dynamics

**In this chapter you can read about:**


- Preparatory settings for the controller alignment..... 98
- Signal filtering with external command value ..... 102
- Controller structure of main axis..... 105
- Controller structure auxiliary axis ..... 106
- Feedforward main axis (status controller) ..... 107
- Feedforward auxiliary axis (status controller)..... 108
- Position controller main axis (status controller)..... 109
- Position controller auxiliary axis (status controller) ..... 113
- Filter main axis ..... 116
- Filter auxiliary axis ..... 117
- Analog Input ..... 118
- Force-/Pressure Control main axis..... 123
- Force-/Pressure Control auxiliary axis ..... 127
- Output signal conditioning 0 ..... 131
- Step-by-step optimization ..... 138

The controller optimization of the Compax3 is carried out by setting the optimization objects in 2 steps:

- ◆ Via the standard settings, with the help of which many applications can be optimized in a simple manner.
- ◆ With advanced settings for users familiar with control loops.

#### Editing the optimization objects

The settings are made in the controller optimization window:



- 1: Selection of the optimization tab
- 2: Selection of the optimization value
- 3: List of the optimization objects, with object name and object number
- 4: Command VP for accepting a changed optimization object.  
Yellow background indicates that an object has been changed, was however not yet set to valid with VP.
- 5: Command WF for permanently saving the changed objects (also after mains off/on)
- 6: Acknowledging a Compax3 error.
- 7: Setting options:
  - ◆ Standard / Advanced mode
  - ◆ Load protocol to clipboard, load into notepad or delete
- 8: Editing window: The value of an object selected with the aid of the mouse (in 3) can here be edited and confirmed with return.
- 9: Additional functions, depending on the Compax3 technology function.

### 4.3.3.1 Preparatory settings for the controller alignment

#### In this chapter you can read about:

Configuring the device .....	98
Checking the feedback direction and the valve output polarity.....	98
Compensation of non-linearities of the distance.....	99
Checking the open loop gain .....	101
Filter alignment .....	101
Controller optimization.....	102

#### Configuring the device

The configuration settings must be made before with the aid of the Configuration Wizard.

Optimization takes place in the **optimization window** (see page 88).

#### Checking the feedback direction and the valve output polarity


Feedback direction and valve polarity are verified in the open loop.

#### ATTENTION:

**In the open loop operation, the drive axis might drift, as the position controller is deactivated!**



With the aid of the jog+/- function, the axis can be moved.  
 The setpoint generator- (681.4 or 681.2) and the actual speed (681.9 or 681.14) must have the same sign (shown in the roll mode of the oscilloscope).



**If this is not the case, there are two possible causes:**

- ◆ Wrong orientation of the position feedback system: The actual position can be displayed in order to check this. Resolve by changing the feedback direction in the configuration wizard or in the C3HydraulicsManager.
- ◆ Incorrect wiring of the valves. The polarity can either be changed by changing the wiring at the clamp or by inverting the output (Optimization → Output Chain X → Inversion).

**Compensation of non-linearities of the distance**


Before the controller alignment, the non-linear components of the path should be compensated with the aid of the Output Conditioning Chains. This helps to achieve an improvement of the system behavior. There are several possibilities:

**a) Pressure compensation**

If pressure sensors are available, those can be used to compensate the differential pressure. This makes the control more robust with respect to variations in the system pressure or the load.

Before the activation, please notice the following:

- ◆ Correct connection of the pressure sensors to the controller.
  - ◆ By approaching the end limits and simultaneously monitoring the pressure values (Status values → pressure of main or auxiliary axis →  $p_a$ ,  $p_b$ ,  $p_T$  and  $p_0$ ) it is possible to conclude if the pressure sensors are correctly assigned.



A = cylinder at limit A

B = cylinder at limit B

1 = valve position

- ◆ The pressure signals should be well filtered (smooth). (Optimization → Analog input → InX Filter)

If those conditions are fulfilled, the pressure compensation can be activated under (Optimization → Output Chain → PressureCompensation).

### b) characteristics compensation

The control behavior of valves with bent characteristic lines or overlap can be considerably improved if the valve characteristics are stored in the controller and are used for the compensation. The characteristic is integrated into the respective valve data via the C3HydraulicsManager and is loaded into the controller via the C3ServoManager. The activation of the characteristic line is made via optimization → Output Chain → Characteristic Flow.

If the valve characteristic line is activated, the behavior between control signal and speed should be mainly linear.

(Doubling of the setpoint speed → Doubling of the resulting speed in the open control loop).

### c) Deadband compensation

If for valves with overlap or gap no adequate characteristics are available, they can be optimized with the aid of the deadband compensation. The corresponding values are set in (Optimization → Output Chain → Deadband ...).

Autoryzowany dystrybutor Parker:

# ARA

## PNEUMATIK

53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)





### Checking the open loop gain

In order to verify the open loop gain calculated from the component data. In the ideal case, the axis achieves the setpoint speed in both directions during open loop operation.

- ◆ Oscilloscope settings:
  - ◆ Setpoint speed of the setpoint generator
  - ◆ Actual speed (filtered)

Initially compensate a possible valve offset. In order to do this the value optimization → Output chain X → Offset is changed until the axis comes to a standstill.

Afterwards, the axis is moved for example with the aid of the jog function in the setup window. When comparing the setpoint speed and the actual speed you have distinguish between four different cases:

- ◆ **Setpoint speed > actual speed, positive travel direction:**
  - ◆ The open loop gain is too small → Optimization → Output chain X → increase Gain factor positive.
- ◆ **Setpoint speed < actual speed, positive travel direction:**
  - ◆ The open loop gain is too high → Optimization → Output chain X → decrease Gain factor positive.
- ◆ **Setpoint speed > actual speed, negative travel direction:**
  - ◆ The open loop gain is too small → Optimization → Output chain X → increase Gain factor negative.
- ◆ **Setpoint speed < actual speed, negative travel direction:**
  - ◆ The open loop gain is too high → Optimization → Output chain X → decrease Gain factor negative.

Now the axis must move in open loop with the preset speed.

### Filter alignment

Especially when using feedback systems with low resolution, a filter alignment is necessary. With high resolution systems, this step might not be necessary.

- ◆ Oscilloscope settings:
  - ◆ Actual speed (filtered)

The Parameter Optimization → Controller dynamic → Filter 2 speed actual value is increased until there are no longer any spikes in the speed signal during the open loop movement of the axis.


**ATTENTION: too strong filtering causes additional deceleration and phase shifting in the control loop and may later make the control instable! Filter as moderately as possible.**

**ATTENTION: when using analog position feedback systems, you should at first perform an input filtering. Optimization → Analog input → Inx → Filter.**

**Example: analog path measurement system +/-10V on input IN4:**

Without input filter

With input filter 550%

**Controller optimization**

Now the control loop of the axis can be closed. Before you should **Save the settings** (see page 97).

Then the axis can be switched into the preoperational mode (power-off) in order to change then to closed loop operation. Switching between open and closed loop operation is only possible in this state.

**ATTENTION: When the control is activated, uncontrolled movements of the axis may occur, if the control is inadequately parameterized!**

**ATTENTION: In order to limit the speed of the axis, the control signal range for the valve control can be limited with the aid of the output limitation. Settings: Optimization → Output Chain X → Upper Limit bzw. Lower Limit. The limitation should not be set too small, as this would put into effect an additional non-linearity (limitation) in the distance, which complicates the controller alignment.**

**Oscilloscope settings:**

- ◆ Following error
- ◆ Actual speed
- ◆ Setpoint speed

**4.3.3.2 Signal filtering with external command value****In this chapter you can read about:**


Signal filtering for external setpoint specification and electronic gearbox .....	103
Signal filtering for external setpoint specification and electronic cam.....	104

The command signal read in from an external source (via HEDA or physical input) can be optimized via different filters.

For this the following filter structure is available:


**Signal filtering for external setpoint specification and electronic gearbox**

**Does not apply for Compax3I11T11!**



B: Structure image of the signal processing  
 D/E: **Structure of Gearing** (see page 196)  
 Control structure

**Symbols**




**Trackingfilter**

The displayed filter influences all outputs of the tracking filter.  
**Number:** Object number of the filter characteristic




**Differentiator**

Output signal =  $d(\text{input signal})/dt$   
 The output signal is the derivation (gradient) of the input signal



**Filter**

**Number:** Object number of the filter characteristic



**Interpolation**


Linear Interpolation.  
 Values in the 500µs grid are converted into the more exact time grid of 125µs.

**Note:**

- ◆ A setpoint jerk setpoint feedback is not required for external setpoint specification.
- ◆ The description of the objects can be found in the **object list** (see page 414).


**Signal filtering for external setpoint specification and electronic cam**

**Only Compax3 T40!**




B: Structure image of the signal processing  
 D/E: **Structure of Cam** (see page 225)  
 Control structure

**Symbols**




**Trackingfilter**

The displayed filter influences all outputs of the tracking filter.  
**Number:** Object number of the filter characteristic




**Differentiator**

Output signal =  $d(\text{input signal})/dt$   
 The output signal is the derivation (gradient) of the input signal



**Filter**

**Number:** Object number of the filter characteristic




**Interpolation**

Linear Interpolation.  
 Values in the 500µs grid are converted into the more exact time grid of 125µs.

**Note:**


- ◆ A setpoint jerk setpoint feedback is not required for external setpoint specification.
- ◆ The description of the objects can be found in the **object list** (see page 414).

4.3.3.3 Controller structure of main axis



Measurement values: Status objects are displayed in red.  
 Factors and time constants Corresponding objects are displayed in blue.  
 Below you can find the descriptions of the individual objects.

**4.3.3.4 Controller structure auxiliary axis**



Measurement values: Status objects are displayed in red.  
 Factors and time constants Corresponding objects are displayed in blue.  
 constants  
 Below you can find the descriptions of the individual objects.

### 4.3.3.5 Feedforward main axis (status controller)

#### In this chapter you can read about:

Object 2010.23: Speed .....	107
Object 2010.24: Acceleration.....	107

#### Object 2010.23: Speed

Object name	<i>C3.FeedForward_Speed_FFW</i>		
Object No.	2010.23	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:	Factor for speed feedforward (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

#### Object 2010.24: Acceleration

Object name	<i>C3.FeedForward_Speed_FFW</i>		
Object No.	2010.24	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s <sup>2</sup> /unit		
Minimum value	%s <sup>2</sup> /unit	Maximum value	%s <sup>2</sup> /unit
Remark:	Factor for acceleration feedforward (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

### 4.3.3.6 Feedforward auxiliary axis (status controller)

#### In this chapter you can read about:

Object 2050.9: Speed .....	108
Object 2050.10: Acceleration.....	108

#### Object 2050.9: Speed

Object name	<i>C3.FeedForward_2_Speed_FFW</i>		
Object No.	2050.9	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:	Factor for speed feedforward (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

#### Object 2050.10: Acceleration

Object name	<i>C3.FeedForward_2_Accel_FFW</i>		
Object No.	2050.10	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s <sup>2</sup> /unit		
Minimum value	%s <sup>2</sup> /unit	Maximum value	%s <sup>2</sup> /unit
Remark:	Factor for acceleration feedforward (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3



**4.3.3.7 Position controller main axis (status controller)**

**In this chapter you can read about:**

Object 2200.24: Filter - Following Error ..... 109  
 Object 2200.11: Filter - Following Error ..... 109  
 Object 2200.38: P-term ..... 110  
 Object 2200.37: I-term ..... 110  
 Object 2200.30: Internal window I-term ..... 110  
 Object 2200.31: External window I-term ..... 110  
 Object 2200.32: Positive limit I-term ..... 111  
 Object 2200.33: Negative limit I-term ..... 111  
 Object 2100.13: Speed feedback ..... 111  
 Object 2100.14: Acceleration feedback ..... 112  
 Object 2210.8: Filter control signal ..... 112

**Object 2200.24: Filter - Following Error**

<b>Object name</b>	<i>C3Plus.PositionController_TrackingErrorFilter_us</i>		
<b>Object No.</b>	<b>2200.24</b>	<b>HEDA-channel</b>	no
<b>Access:</b>	Read/write	<b>Valid after:</b>	VP
<b>CodeSys object:</b>	no	<b>CodeSys format:</b>	INT
<b>Unit</b>	us		
<b>Minimum value</b>	0 us	<b>Maximum value</b>	8300000 us
<b>Remark:</b>	Time constant of the following error filter of the position controller in µs (analog to 2200.11 in %) Is set to the default value corresponding to the motor in the configuration when changing the motor. Default value 0us. The filter is deactivated for values from 0 to 62us. C3F: The filter is deactivated for values from 0 to 125us.  Only internal: Due to structure, the following error is, as from R07, filtered with the sum time constant actual velocity value filter 1 + actual velocity value 2 + time constant of following filter + user filter 2200.24.		
<b>CAN No.</b>	-	<b>PD object:</b>	no
<b>Profibus-No. (PNU)</b>	-	<b>Bus format:</b>	U16

**Object 2200.11: Filter - Following Error**

<b>Object name</b>	<i>C3Plus.PositionController_TrackingErrorFilter</i>		
<b>Object No.</b>	<b>2200.11</b>	<b>HEDA-channel</b>	no
<b>Access:</b>	Read/write	<b>Valid after:</b>	VP
<b>CodeSys object:</b>	yes	<b>CodeSys format:</b>	INT
<b>Unit</b>	%		
<b>Minimum value</b>	0 %	<b>Maximum value</b>	554 %
<b>Remark:</b>	Is set to the corresponding default value when changing the motor.		
<b>CAN No.</b>	-	<b>PD object:</b>	no
<b>Profibus-No. (PNU)</b>	-	<b>Bus format:</b>	U16

**Object 2200.38: P-term**

Object name	<i>C3Plus.PositionController_Kp_PPart</i>		
Object No.	2200.38	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/unit		
Minimum value	%/unit	Maximum value	%/unit
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2200.37: I-term**

Object name	<i>C3Plus.PositionController_Ki_IPart</i>		
Object No.	2200.37	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/(s unit)		
Minimum value	%/(s unit)	Maximum value	%/(s unit)
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2200.30: Internal window I-term**

Object name	<i>C3Plus.PositionController_InsideWindow_IPart</i>		
Object No.	2200.30	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	Unit		
Minimum value	Unit	Maximum value	Unit
Remark:	I term internal window (beginning of the integration) main axis (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2200.31: External window I-term**

Object name	<i>C3Plus.PositionController_OutsideWindow_IPart</i>		
Object No.	2200.31	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	Unit		
Minimum value	Unit	Maximum value	Unit
Remark:	I term external window (end of the integration) main axis (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2200.32: Positive limit I-term**

Object name	<i>C3Plus.PositionController_PosLimit_IPart</i>		
Object No.	2200.32	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%/unit	Maximum value	%/unit
Remark:	Upper limit of the I term (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2200.33: Negative limit I-term**

Object name	<i>C3Plus.PositionController_NegLimit_IPart</i>		
Object No.	2200.33	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:	Lower limit of the I term (man axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2100.13: Speed feedback**

Object name	<i>C3.ControllerTuning_SpeedFeedback_Kv</i>		
Object No.	2100.13	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:	Feedback of the speed signal (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2100.14: Acceleration feedback**

Object name	<i>C3.ControllerTuning_AccelFeedback_Ka</i>		
Object No.	2100.14	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s <sup>2</sup> /unit		
Minimum value	%s <sup>2</sup> /unit	Maximum value	%s <sup>2</sup> /unit
Remark:	Feedback of the acceleration signal (main axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2210.8: Filter control signal**

Object name	<i>C3.SpeedController_ActuatingSignal_filt</i>		
Object No.	2210.8	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**4.3.3.8 Position controller auxiliary axis (status controller)**

**In this chapter you can read about:**

Object 2260.8: Filter - Following Error ..... 113  
 Object 2260.22: P-term ..... 113  
 Object 2260.21: I-term ..... 113  
 Object 2260.14: Internal window I-term ..... 114  
 Object 2260.15: External window I-term ..... 114  
 Object 2260.16: Positive limit I-term ..... 114  
 Object 2260.17: Negative limit I-term ..... 115  
 Object 2101.13: Speed feedback ..... 115  
 Object 2101.14: Acceleration feedback ..... 115  
 Object 2270.8: Filter control signal ..... 115

**Object 2260.8: Filter - Following Error**

Object name	<i>C3.PositionController_2_TrackingErrorFilter_us</i>		
Object No.	2260.8	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2260.22: P-term**

Object name	<i>C3Plus.PositionController_2_Kp_PPart</i>		
Object No.	2260.22	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/unit		
Minimum value	n/a	Maximum value	n/a
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2260.21: I-term**

Object name	<i>C3Plus.PositionController_2_Ki_IPart</i>		
Object No.	2260.21	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/(s unit)		
Minimum value	%/(s unit)	Maximum value	%/(s unit)
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2260.14: Internal window I-term**

Object name	<i>C3Plus.PositionController_2_InsideWindow_IPart</i>		
Object No.	2260.14	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	Unit		
Minimum value	Unit	Maximum value	Unit
Remark:	I term internal window (beginning of the integration) auxiliary axis (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2260.15: External window I-term**

Object name	<i>C3Plus.PositionController_2_OutsideWindow_IPart</i>		
Object No.	2260.15	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	Unit		
Minimum value	Unit	Maximum value	Unit
Remark:	I term external window (end of the integration) auxiliary axis (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2260.16: Positive limit I-term**

Object name	<i>C3Plus.PositionController_2_PosLimit_IPart</i>		
Object No.	2260.16	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:	Upper limit of the I term (auxiliary axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2260.17: Negative limit I-term**

Object name	<i>C3Plus.PositionController_2_NegLimit_IPart</i>		
Object No.	2260.17	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:	Lower limit of the I term (auxiliary axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 2101.13: Speed feedback**

Object name	<i>C3.ControllerTuning_2_SpeedFeedback_Kv</i>		
Object No.	2101.13	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:	Feedback of the speed signal (auxiliary axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2101.14: Acceleration feedback**

Object name	<i>C3.ControllerTuning_2_AccelFeedback_Ka</i>		
Object No.	2101.14	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%s <sup>2</sup> /unit		
Minimum value	%s <sup>2</sup> /unit	Maximum value	%s <sup>2</sup> /unit
Remark:	Feedback of the acceleration signal (auxiliary axis) (does only apply for single-loop status control)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2270.8: Filter control signal**

Object name	<i>C3.SpeedController2_ActuatingSignal_filt</i>		
Object No.	2270.8	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

### 4.3.3.9 Filter main axis

#### In this chapter you can read about:

Object 2100.10: Filter 2 actual speed .....	116
Object 2100.11: Filter 2 actual accel .....	116

#### Object 2100.10: Filter 2 actual speed

Object name	<i>C3.ControllerTuning_FilterSpeed2</i>		
Object No.	2100.10	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:	Works in line with actual velocity filter Default value 0us The filter is deactivated for values from 0 to 62us.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

#### Object 2100.11: Filter 2 actual accel

Object name	<i>C3.ControllerTuning_FilterAccel2</i>		
Object No.	2100.11	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:	Works in line with actual acceleration filter Default value 0us The filter is deactivated for values from 0 to 62us.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16



### 4.3.3.10 Filter auxiliary axis

#### In this chapter you can read about:

Object 2101.7: Filter 2 actual speed .....	117
Object 2101.8: Filter 2 actual accel .....	117

#### Object 2101.7: Filter 2 actual speed

Object name	<b><i>C3.ControllerTuning_2_FilterSpeed2</i></b>		
Object No.	2101.7	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:	Works in line with actual velocity filter Default value 0us The filter is deactivated for values from 0 to 62us.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

#### Object 2101.8: Filter 2 actual accel

Object name	<b><i>C3.ControllerTuning_2_FilterAccel2</i></b>		
Object No.	2101.8	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	us		
Minimum value	0 us	Maximum value	8300000 us
Remark:	Works in line with actual acceleration filter Default value 0us The filter is deactivated for values from 0 to 62us.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

### 4.3.3.11 Analog Input

#### In this chapter you can read about:

Object 172.11: IN0 Offset .....	118
Object 172.4: IN0 Offset .....	118
Object 172.3: IN0 Filter .....	119
Object 173.11: IN1 Offset .....	119
Object 173.4: IN1 Offset .....	119
Object 173.3: IN1 Filter .....	119
Object 174.11: IN2 Offset .....	120
Object 174.4: IN2 Offset .....	120
Object 174.3: IN2 Filter .....	120
Object 175.11: IN3 Offset .....	120
Object 175.4: IN3 Offset .....	121
Object 175.3: IN3 Filter .....	121
Object 176.11: IN4 Offset .....	121
Object 176.4: IN4 Offset .....	121
Object 176.3: IN4 Filter .....	122
Object 177.11: IN5 Offset .....	122
Object 177.4: IN5 Offset .....	122
Object 177.3: IN5 Filter .....	122

#### Object 172.11: IN0 Offset

Object name	<i>C3Plus.AnalogInput0_Offset_normed</i>		
Object No.	172.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	mA		
Minimum value	mA	Maximum value	mA
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

#### Object 172.4: IN0 Offset

Object name	<i>C3.AnalogInput0_Offset</i>		
Object No.	172.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	Increments		
Minimum value	0 n/a	Maximum value	65535 n/a
Remark:	Offset in AD converter increments.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 172.3: IN0 Filter**

Object name	<i>C3Plus.AnalogInput0_FilterCoefficient</i>		
Object No.	172.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 173.11: IN1 Offset**

Object name	<i>C3Plus.AnalogInput1_Offset_normed</i>		
Object No.	173.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	mA		
Minimum value	mA	Maximum value	mA
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 173.4: IN1 Offset**

Object name	<i>C3.AnalogInput1_Offset</i>		
Object No.	173.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	Increments		
Minimum value	n/a	Maximum value	n/a
Remark:	Offset in AD converter increments. Range 0..65535		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 173.3: IN1 Filter**

Object name	<i>C3Plus.AnalogInput1_FilterCoefficient</i>		
Object No.	173.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 174.11: IN2 Offset**

Object name	<i>C3Plus.AnalogInput2_Offset_normed</i>		
Object No.	174.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	mA		
Minimum value	mA	Maximum value	mA
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 174.4: IN2 Offset**

Object name	<i>C3.AnalogInput2_Offset</i>		
Object No.	174.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	Increments		
Minimum value	n/a	Maximum value	n/a
Remark:	Offset in AD increments. Range 0..65535.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 174.3: IN2 Filter**

Object name	<i>C3Plus.AnalogInput2_FilterCoefficient</i>		
Object No.	174.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	us	Maximum value	us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 175.11: IN3 Offset**

Object name	<i>C3Plus.AnalogInput3_Offset_normed</i>		
Object No.	175.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	mA		
Minimum value	mA	Maximum value	mA
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 175.4: IN3 Offset**

Object name	<i>C3.AnalogInput3_Offset</i>		
Object No.	175.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	Increments		
Minimum value	n/a	Maximum value	n/a
Remark:	Offset in AD increments		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 175.3: IN3 Filter**

Object name	<i>C3Plus.AnalogInput3_FilterCoefficient</i>		
Object No.	175.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	us	Maximum value	us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 176.11: IN4 Offset**

Object name	<i>C3Plus.AnalogInput4_Offset_normed</i>		
Object No.	176.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	V		
Minimum value	V	Maximum value	V
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 176.4: IN4 Offset**

Object name	<i>C3.AnalogInput4_Offset</i>		
Object No.	176.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	n/a		
Minimum value	n/a	Maximum value	n/a
Remark:	Offset in AD increments		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 176.3: IN4 Filter**

Object name	<i>C3Plus.AnalogInput4_FilterCoefficient</i>		
Object No.	176.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	us
Remark:	Filter of time constant in us for the filtering of the input signal 0 => Filter off => output = input		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 177.11: IN5 Offset**

Object name	<i>C3Plus.AnalogInput5_Offset_normed</i>		
Object No.	177.11	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	V		
Minimum value	V	Maximum value	V
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	C4_3

**Object 177.4: IN5 Offset**

Object name	<i>C3.AnalogInput5_Offset</i>		
Object No.	177.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	INT
Unit	n/a		
Minimum value	n/a	Maximum value	n/a
Remark:	Offset in AD increments		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 177.3: IN5 Filter**


Object name	<i>C3Plus.AnalogInput5_FilterCoefficient</i>		
Object No.	177.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	DINT
Unit	us		
Minimum value	0 us	Maximum value	us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

4.3.3.12 Force-/Pressure Control main axis

**In this chapter you can read about:**

Object 2250.13: P-term.....	124
Object 2250.14: I-term.....	124
Object 2250.15: Internal window I-term.....	124
Object 2250.16: External window I-term.....	124
Object 2250.17: Positive limit I-term.....	125
Object 2250.18: Negative limit I-term.....	125
Object 2250.19: D-term.....	125
Object 2250.8: Delay T1.....	125
Object 2250.20: Speed feedback.....	126
Object 2250.23: Force feedforward.....	126
Object 2250.24: Inversion of the control variable [on/off].....	126
Object 2250.22: Filter control signal.....	126

**Signal image of pressure / force control of the main axis:**



**Object 2250.13: P-term**

Object name	<i>C3Plus.PressureController_1_Proportional_Part_Kp</i>		
Object No.	2250.13	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/pres		
Minimum value	%/pres	Maximum value	%/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.14: I-term**

Object name	<i>C3Plus.PressureController_1_Integration_Part_KFi</i>		
Object No.	2250.14	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/(s pres)		
Minimum value	0 %/(s pres)	Maximum value	4,000 %/(s pres)
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.15: Internal window I-term**

Object name	<i>C3Plus.PressureController_1_InsideWindow_IPart</i>		
Object No.	2250.15	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	pres		
Minimum value	pres	Maximum value	pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.16: External window I-term**

Object name	<i>C3Plus.PressureController_1_OutsideWindow_IPart</i>		
Object No.	2250.16	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	pres		
Minimum value	pres	Maximum value	pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32



**Object 2250.17: Positive limit I-term**

Object name	<i>C3Plus.PressureController_1_PosLimit_IPart</i>		
Object No.	2250.17	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.18: Negative limit I-term**

Object name	<i>C3Plus.PressureController_1_NegLimit_IPart</i>		
Object No.	2250.18	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.19: D-term**

Object name	<i>C3Plus.PressureController_1_Derivative_Part_KFd</i>		
Object No.	2250.19	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%s/pres		
Minimum value	%s/pres	Maximum value	%s/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2250.8: Delay T1**

Object name	<i>C3.PressureController_1_TimeDelay_DT1_T1</i>		
Object No.	2250.8	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	INT
Unit	us		
Minimum value	250 us	Maximum value	us
Remark:	PID force controller 1 delay time constant of the D-term T1 Influences the D-term of the controller		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U32

**Object 2250.20: Speed feedback**

Object name	<i>C3Plus.PressureController_1_Speed_Feedback_KFv</i>		
Object No.	2250.20	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2250.23: Force feedforward**

Object name	<i>C3Plus.PressureController_1_Force_FeedForward_KFs</i>		
Object No.	2250.23	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%/pres		
Minimum value	%/pres	Maximum value	%/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2250.24: Inversion of the control variable [on/off]**

Object name	<i>C3Plus.PressureController_1_ActuatingSignal_Inversion</i>		
Object No.	2250.24	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	BOOL
Unit	n/a		
Minimum value	0 n/a	Maximum value	1 n/a
Remark:	Inversion of the force controller control variable of the main axis. The inversion is only effective for the valve output and not for the status values of the force controller.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2250.22: Filter control signal**


Object name	<i>C3.PressureController_1_ActuatingSignalFilter</i>		
Object No.	2250.22	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	
Unit	us		
Minimum value	us	Maximum value	8300000 us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**4.3.3.13 Force-/Pressure Control auxiliary axis**

**In this chapter you can read about:**

Object 2251.13: P-term.....	128
Object 2251.14: I-term.....	128
Object 2251.15: Internal window I-term.....	128
Object 2251.16: External window I-term.....	128
Object 2251.17: Positive limit I-term.....	129
Object 2251.18: Negative limit I-term.....	129
Object 2251.19: D-term.....	129
Object 2251.8: Delay T1.....	129
Object 2251.20: Speed feedback.....	130
Object 2251.23: Force feedforward.....	130
Object 2251.24: Inversion of the control variable [on/off].....	130
Object 2251.22: Filter control signal.....	130

**Signal image of pressure / force control of the auxiliary axis:**



**Object 2251.13: P-term**

Object name	<i>C3Plus.PressureController_2_Proportional_Part_Kp</i>		
Object No.	2251.13	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/pres		
Minimum value	%/pres	Maximum value	%/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.14: I-term**

Object name	<i>C3Plus.PressureController_2_Integration_Part_KFi</i>		
Object No.	2251.14	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%/(s pres)		
Minimum value	%/(s pres)	Maximum value	4,000 %/(s pres)
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.15: Internal window I-term**

Object name	<i>C3Plus.PressureController_2_InsideWindow_IPart</i>		
Object No.	2251.15	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	pres		
Minimum value	pres	Maximum value	pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.16: External window I-term**

Object name	<i>C3Plus.PressureController_2_OutsideWindow_IPart</i>		
Object No.	2251.16	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	pres		
Minimum value	pres	Maximum value	pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.17: Positive limit I-term**

Object name	<i>C3Plus.PressureController_2_PosLimit_IPart</i>		
Object No.	2251.17	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.18: Negative limit I-term**

Object name	<i>C3Plus.PressureController_2_NegLimit_IPart</i>		
Object No.	2251.18	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	%	Maximum value	%
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.19: D-term**

Object name	<i>C3Plus.PressureController_2_Derivative_Part_KFd</i>		
Object No.	2251.19	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%s/pres		
Minimum value	%s/pres	Maximum value	%s/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2251.8: Delay T1**

Object name	<i>C3.PressureController_2_TimeDelay_DT1_T1</i>		
Object No.	2251.8	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	INT
Unit	us		
Minimum value	250 us	Maximum value	us
Remark:	Influences the D-term of the controller		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U32

**Object 2251.20: Speed feedback**

Object name	<i>C3Plus.PressureController_2_Speed_Feedback_KFv</i>		
Object No.	2251.20	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%s/unit		
Minimum value	%s/unit	Maximum value	%s/unit
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2251.23: Force feedforward**

Object name	<i>C3Plus.PressureController_2_Force_FeedForward_KFs</i>		
Object No.	2251.23	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	REAL
Unit	%/pres		
Minimum value	%/pres	Maximum value	%/pres
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	U16

**Object 2251.24: Inversion of the control variable [on/off]**

Object name	<i>C3Plus.PressureController_2_ActuatingSignal_Inversion</i>		
Object No.	2251.24	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	BOOL
Unit	n/a		
Minimum value	0 n/a	Maximum value	1 n/a
Remark:	Inversion of the force controller control variable of the auxiliary axis. The inversion is only effective for the valve output and not for the status values of the force controller.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2251.22: Filter control signal**

Object name	<i>C3.PressureController_2_ActuatingSignalFilter</i>		
Object No.	2251.22	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	no	CodeSys format:	
Unit	us		
Minimum value	us	Maximum value	8300000 us
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32


**4.3.3.14 Output signal conditioning 0**

**In this chapter you can read about:**

Conditioning Chain Symbols..... 132  
 Object 2400.3: Upper limit of ocontrol signal ..... 132  
 Object 2400.4: Lower limit of the control signal ..... 132  
 Object 2400.6: Output Offset ..... 133  
 Object 2400.7: Replacement value (inactive Chain 0)..... 133  
 Object 2401.4: Gain factor positive..... 133  
 Object 2401.5: Gain factor negative ..... 134  
 Object 2401.7: Gain positive direction (Force-/Pressure- control)..... 134  
 Object 2401.8: Gain negative direction (Force-/Pressure- control) ..... 134  
 Object 2401.6: Inversion [on/off]..... 135  
 Object 2402.1: Pressure Compensation [on/off] ..... 135  
 Object 2403.1: Characteristic flow [on/off] ..... 135  
 Object 2405.1: Deadband [on/off]..... 136  
 Object 2405.2: Deadband A-side..... 136  
 Object 2405.3: Deadband B-side..... 136  
 Object 2405.4: Deadband threshold value ..... 137

In order to linearize the valve as well as the entire control path 4 linearization chains (conditioning chains => output signal conditioning) are available.

**Layout of the path linearization (Conditioning Chains):**



**Objects of the conditioning chains:**

The Conditioning Chains are set via objects in the **optimization window** (see page 88).


The "x" in the objects given in the signal image depends on the conditioning chains to be parameterized:


x = 0,1,2,3 = Conditioning Chain No.


In the **Compax3F structure image** (see page 45) you can see how the Conditioning Chains are integrated in the total structure.


Below you can find the descriptions of the individual objects.


**Conditioning Chain Symbols**


- 

Direction dependent gain
- 

Direction dependent pressure compensation
- 

Non-linear characteristic (valve characteristic)
- 

Deadband  
No signal is transmitted in a range definable by objects.
- 

Change of gain for small signals.  
In a range definable by objects, the signal is transmitted with changed gain.
- 

Limitation  
The signal is limited to a range definable by objects.

**Object 2400.3: Upper limit of ocntrl signal**

<b>Object name</b>	<i>C3Plus.OutputConditioningChain_Ch0_Upper_Limit</i>		
<b>Object No.</b>	2400.3	<b>HEDA-channel</b>	no
<b>Access:</b>	Read/write	<b>Valid after:</b>	VP
<b>CodeSys object:</b>	yes	<b>CodeSys format:</b>	INT
<b>Unit</b>	%		
<b>Minimum value</b>	0 %	<b>Maximum value</b>	100 %
<b>Remark:</b>	Upper limit of valve output 0  Objects of the other conditioning chains: 24x0.3 (x = 0,1,2,3 = Conditioning Chain No.)		
<b>CAN No.</b>	-	<b>PD object:</b>	no
<b>Profibus-No. (PNU)</b>	-	<b>Bus format:</b>	I16

**Object 2400.4: Lower limit of the control signal**

<b>Object name</b>	<i>C3Plus.OutputConditioningChain_Ch0_Lower_Limit</i>		
<b>Object No.</b>	2400.4	<b>HEDA-channel</b>	no
<b>Access:</b>	Read/write	<b>Valid after:</b>	VP
<b>CodeSys object:</b>	yes	<b>CodeSys format:</b>	INT
<b>Unit</b>	%		
<b>Minimum value</b>	0 %	<b>Maximum value</b>	100 %
<b>Remark:</b>	Lower limit of valve output 0  Objects of the other conditioning chains: 24x0.4 (x = 0,1,2,3 = Conditioning Chain No.)		
<b>CAN No.</b>	-	<b>PD object:</b>	no
<b>Profibus-No. (PNU)</b>	-	<b>Bus format:</b>	I16



**Object 2400.6: Output Offset**

Object name	<i>C3Plus.OutputConditioningChain_Ch0_Output_Offset</i>		
Object No.	2400.6	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	-100 %	Maximum value	100 %
Remark:			
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2400.7: Replacement value (inactive Chain 0)**

Object name	<i>C3Plus.OutputConditioningChain_Ch0_Input_DefaultValue</i>		
Object No.	2400.7	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	REAL
Unit	%		
Minimum value	-100 %	Maximum value	100 %
Remark:	Replacement value on the input of the chain, if the corresponding controller (position or force controller) is not operating.		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2401.4: Gain factor positive**

Object name	<i>C3Plus.DirectionDependentGain_Ch0_Factor_positive</i>		
Object No.	2401.4	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	1		
Minimum value	n/a	Maximum value	n/a
Remark:	Gain factor for positive input values  Objects of the other conditioning chains: 24x1.4 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2401.5: Gain factor negative**

Object name	<i>C3Plus.DirectionDependentGain_Ch0_Factor_negative</i>		
Object No.	2401.5	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	REAL
Unit	1		
Minimum value	n/a	Maximum value	n/a
Remark:	Gain factor for negative input values  Objects of the other conditioning chains: 24x1.5 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2401.7: Gain positive direction (Force-/Pressure- control)**

Object name	<i>C3.DirectionDependentGain_Ch0_Factor_positiv_Pressure</i>		
Object No.	2401.7	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	
Unit	1		
Minimum value	n/a	Maximum value	n/a
Remark:	Gain factor for positive input values (with pressure/force control)  Objects of the other conditioning chains: 24x1.7 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2401.8: Gain negative direction (Force-/Pressure- control)**

Object name	<i>C3.DirectionDependentGain_Ch0_Factor_negative_Pressure</i>		
Object No.	2401.8	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	no	CodeSys format:	
Unit	1		
Minimum value	n/a	Maximum value	n/a
Remark:	Gain factor for negative input values (with pressure/force control)  Objects of the other conditioning chains: 24x1.8 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2401.6: Inversion [on/off]**

Object name	<i>C3Plus.DirectionDependentGain_Ch0_InvertType</i>		
Object No.	2401.6	HEDA-channel	no
Access:	Read/write	Valid after:	Immediately
CodeSys object:	yes	CodeSys format:	BOOL
Unit	n/a		
Minimum value	n/a	Maximum value	n/a
Remark:	Type=0 no inversion Type<>0 Signal is inverted (+<=>-)  Objects of the other conditioning chains: 24x1.6 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2402.1: Pressure Compensation [on/off]**

Object name	<i>C3Plus.PressureCompensation_Ch0_Type</i>		
Object No.	2402.1	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	n/a		
Minimum value	n/a	Maximum value	n/a
Remark:	Type=1 Differential pressure at side A is compensated Type=1 Differential pressure at side A is compensated  Objects of the other conditioning chains: 24x2.1 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2403.1: Characteristic flow [on/off]**

Object name	<i>C3Plus.SignalFlowCharacteristic_Ch0_Type</i>		
Object No.	2403.1	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	n/a		
Minimum value	n/a	Maximum value	n/a
Remark:	Type=0 characteristic compensation is switched off Type=1 characteristic compensation is switched on: when the limits of the characteristic line are exceeded, interpolation is continued with constant slope Type=2 characteristic compensation is switched on: when the limits of the characteristic line are exceeded, the output value is limited to the limit value of the characteristic line.  Objects of the other conditioning chains: 24x3.1 (x = 0,1,2,3 = Conditioning Chain No.)		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2405.1: Deadband [on/off]**

Object name	<i>C3Plus.DeadBandCompensation_Ch0_Type</i>		
Object No.	2405.1	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	1		
Minimum value	n/a	Maximum value	n/a
Remark:	<p>Type of deadband compensation            Type=0 block off (input=output)            Type=1 deadband compensation with constantly zero in the deadband            Type=2 deadband compensation with straight line in the deadband</p> <p>Objects of the other conditioning chains: 24x5.1            (x = 0,1,2,3 = Conditioning Chain No.)</p>		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I16

**Object 2405.2: Deadband A-side**

Object name	<i>C3Plus.DeadBandCompensation_Ch0_A_Side</i>		
Object No.	2405.2	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	°/oo		
Minimum value	0 °/oo	Maximum value	1,000 °/oo
Remark:	<p>Threshold value on A side</p> <p>Objects of the other conditioning chains: 24x5.2            (x = 0,1,2,3 = Conditioning Chain No.)</p>		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2405.3: Deadband B-side**

Object name	<i>C3Plus.DeadBandCompensation_Ch0_B_Side</i>		
Object No.	2405.3	HEDA-channel	no
Access:	Read/write	Valid after:	VP
CodeSys object:	yes	CodeSys format:	INT
Unit	°/oo		
Minimum value	0 °/oo	Maximum value	1,000 °/oo
Remark:	<p>Threshold value on B side</p> <p>Objects of the other conditioning chains: 24x5.3            (x = 0,1,2,3 = Conditioning Chain No.)</p>		
CAN No.	-	PD object:	no
Profibus-No. (PNU)	-	Bus format:	I32

**Object 2405.4: Deadband threshold value**

<b>Object name</b>	<i>C3Plus.DeadBandCompensation_Ch0_Threshold</i>		
<b>Object No.</b>	<b>2405.4</b>	<b>HEDA-channel</b>	no
<b>Access:</b>	Read/write	<b>Valid after:</b>	VP
<b>CodeSys object:</b>	yes	<b>CodeSys format:</b>	INT
<b>Unit</b>	°/oo		
<b>Minimum value</b>	0 °/oo	<b>Maximum value</b>	1,000 °/oo
<b>Remark:</b>	Width of the deadband on one side  Objects of the other conditioning chains: 24x5.4 (x = 0,1,2,3 = Conditioning Chain No.)		
<b>CAN No.</b>	-	<b>PD object:</b>	no
<b>Profibus-No. (PNU)</b>	-	<b>Bus format:</b>	I32

### 4.3.3.15 Step-by-step optimization


**In this chapter you can read about:**

General ..... 138  
 Procedure ..... 139

#### General

All parameters are changed in the optimization window in the optimization field via the object tree in the lower left window.

- ◆ Click on the object in the object tree (1).
- ◆ Enter new value in the command line (2) and press Return.
- ◆ Set value to valid with CP (3).
- ◆ **Attention:** Entry of the values must be terminated with a Return and must be set to valid via VP (3)!
- ◆ The changed objects are permanenty stored with WF (4).
- ◆ **ATTENTION:** When writing the data into the flash, control oscillations may occur due to increased processor load!  
 => Switch drive to currentless / PowerOff state before



**Procedure**

**In this chapter you can read about:**


Parameters for manual movement/jogging mode and test movement ..... 139  
 Limit valve set value ..... 140  
 Move drive controlledly ..... 140  
 Check sense of direction ..... 141  
 Set valve offset ..... 141  
 Check connection assignment of the pressure sensors ..... 141  
 Check input offset or zero of the pressure sensors ..... 141  
 Direction dependent gain ..... 142  
 Optimization of position controller ..... 142  
 Optimization of pressure/Force Controller ..... 145

**A valid configuration is a prerequisite for this operation and for force/pressure control, operation with one or 2 pressure sensors per cylinder is assumed.**

**Parameters for manual movement/jogging mode and test movement.**

In the optimization window => setup field => parameter.

- ◆ Activate dropdown list via button on the upper left (1)
- ◆ The parameters for manual movement/jogging mode can be found under general setup settings (2).
- ◆ Select test movement absolute (3) for linear drives (cylinders)
- ◆ If needs be, change the limit and homing settings from the configuration for the setup (4).
- ◆ Terminate with "accept entry".



### Limit valve set value

In the optimization tree under output chain:

- ◆ Upper limit of control signal (Object 2400.3) and lower limit of control signal (Object 2400.4) must be set sensibly.
- ◆ Take step 1 for all additional valves.

#### Tip:

In order to avoid a fast, uncontrolled movement of the drive during the setup, the valve outputs should at first be limited!

#### Attention:


- ◆ The drive does not reach its maximum power due to the limitation of the valve outputs.

As soon as the drive is stably positioned in the control loop, the limitation can be lifted.

### Move drive controlledly

In the optimization window ⇒ setup field ⇒ setup.

- ◆ Select "controlled movement" operating mode.
  - ◆ Energize drive (2).
  - ◆ Move the drive to both sides (3).
- Does the axis move?  
No:
- ◆ Valve positive overlap? -> activate valve characteristic line or set deadband compensation.
  - ◆ Check control value limitation -> increase control value limitation.
  - ◆ Control signal gain too small -> increase parameter control signal gain.



#### Tip:

Check, if the control signals to the valves (status values -> valve outputs -> output signal0..3) change.



**Check sense of direction**

- ◆ Select "controlled movement" operating mode
- ◆ Move drive into both directions.
- ◆ Are the directions of the setpoint and of the actual position the same?  
No: Switch on valve inversion(s): Inversion [on/off] = 1 (in the optimization tree under output chain:)
- ◆ Is the direction of the actual position identical with the desired direction in the machine?  
No: Change sense of direction of the feedback in the configuration

**Set valve offset**

- ◆ Select "controlled movement" operating mode
- ◆ Move drive to medium position  
In which direction does the axis drift?
  - ◆ Positive: Reduce output offset until the drive is at standstill.
  - ◆ Negative: Increase output offset until the drive is at standstill.

**Attention:**

- ◆ If the values are too high, the drive might move uncontrolledly at high speed!  
With activated valve inversion, the offset does also work in the opposite direction!  
(In the optimization tree under output chain)  
Approach additional positions and check setting.

**Check connection assignment of the pressure sensors**

- ◆ Check if the correct pressure is displayed when moving the cylinder.  
In the optimization window ⇒ setup field ⇒ status values select the corresponding values and drag them into the status display field.  
  
No:
  - ◆ Check connections and configuration of the pressure sensors.

**Check input offset or zero of the pressure sensors**

- ◆ Switch off hydraulics and make sure that there is no pressure (0 bar) on the pressure sensors.  
In the optimization window ⇒ setup field ⇒ status values select the corresponding values and drag them into the status display field.  
  
No:  
In the optimization window ⇒ optimization field ⇒ optimization.
  - ◆ Adapt zero for analog input offset.

### **Direction dependent gain**

For differential cylinders, the direction dependence can be compensated via object gain positive and negative direction.

In the optimization window  $\Rightarrow$  optimization field  $\Rightarrow$  object tree under path linearization.

- ◆ Positive direction
  - ◆ Object 2401.4: Direction dependent gain
  - ◆ Object 2401.7: Direction dependent gain (pressure control)
- ◆ Negative direction
  - ◆ Object 2401.5: Direction dependent gain
  - ◆ Object 2401.8: Direction dependent gain (pressure control)

#### **Attention:**

If several valves are used for a drive, the direction dependent gain must be set individually for each valve.

### **Optimization of position controller**

#### **In this chapter you can read about:**

Filter .....	142
Set control parameters .....	143
Feedforwards (advanced).....	144

#### **Filter**

#### **In this chapter you can read about:**

Set position (only analog feedback).....	142
Set filter for speed- and acceleration actual value.....	142
Close control loop .....	143

Depending on the feedback type, the actual signals for position, speed and acceleration are disturbed with different intensity. A strong noise on the signals influences the achievable quality of control negatively.

#### **Attention:**

Too high filter constants distort the signals and have a negative effect on the control quality!

#### **Set position (only analog feedback)**

In the optimization tree under analog input.  
Typical setting value: 7000 $\mu$ s.

#### **Set filter for speed- and acceleration actual value.**


In the optimization tree under filter main axis.  
Typical setting values for the individual path measurement system:

Type	Speed[ $\mu$ s]	Acceleration
Analog	7000	
EnDat	500	
RS422		
SSI	1000 ... 7000	
Start-Stop	7000	

**Close control loop**

- ◆ Switch drive to currentless (2)
- ◆ Select control operation (1)
- ◆ Re-energize drive (2)
- ◆ Move drive at low speed in manual mode (jogging) (3).
- ◆ In the event of oscillations, stop the movement  
Does the drive oscillate at standstill?
- ◆ Yes: Switch drive to currentless (2)

**Reduce control parameters (Proportional factor KP (see page 143) to acceleration feedback (see page 144)).**



**Set control parameters**

In this chapter you can read about:

Proportional factor KP.....	143
Integrator KI .....	144
Speed feedback .....	144
Acceleration feedback .....	144

In the optimization tree under position controller main axis

**Proportional factor KP**

- ◆ Increase Kp (2200.38/2260.22) at lowest speed up to the stability limit.
- ◆ Value will be preassigned by the configuration.
- ◆ Acceleration and jerk must be adapted to the potential of the axis.
- ◆ Deceleration and jerk\_deceleration must be adapted to the potential of the axis.
- ◆ Compensate unbalances with direction-dependant gain.
- ◆ Check settings at 50% Vmax and reduce if needs be.
- ◆ Check settings at Vmax and reduce if needs be.

### Integrator KI

- ◆ Increase KI (2200.37/2260.21), so that the following error becomes minimal and the axis does not overshoot.
- ◆ Value will be preassigned by the configuration.
- ◆ Set inner window (2200.30) so that the axis does not readjust constantly (only sensible larger than feedback resolution!)
- ◆ Set outer window (2200.31) so that possible overshoot is reduced.
- ◆ Limit maximum I term (2200.32 and 2200.33).
- ◆ Check settings at 50% Vmax and reduce if needs be.
- ◆ Check settings at Vmax and reduce if needs be.

### Speed feedback

The feedback of the speed can increase the natural frequency, i.e. the dynamic of the hydraulic drive.

#### Prerequisite:

Speed filter set correctly ( **Filter for Speed and Acceleration actual value** (see page 142))

- ◆ Increase speed feedback (2100.13) at lowest speed up to the stability limit.
- ◆ Check settings at 50% Vmax and reduce if needs be.
- ◆ Check settings at Vmax and reduce if needs be.

### Acceleration feedback

The feedback of the acceleration can dampen the hydraulic drive, i.e. reduce the oscillation tendency.

#### Prerequisite:

Acceleration filter set correctly ( **Filter for Speed and Acceleration actual value** (see page 142))

- ◆ Increase acceleration feedback (2100.14) at lowest speed up to the stability limit.
- ◆ Check settings at 50% Vmax and reduce if needs be.
- ◆ Check settings at Vmax and reduce if needs be.

### Feedforwards (advanced)

#### In this chapter you can read about:

Speed feedforward (advanced) .....	144
Acceleration feedforward (advanced) .....	145

The control behavior of the control can be adapted to the application via the feedforward (in the optimization tree under feedforward main axis)

The following error can be minimized at movement with constant speed via the feedforward without negative effect on the stability of the control.

#### Attention:

Feedforward controls may cause an overshoot over the target position!

### Speed feedforward (advanced)

- ◆ Reduce speed feedforward (2010.13) at lowest speed until the following error is minimized.
- ◆ Check settings at 50% Vmax and reduce if needs be.
- ◆ Check settings at Vmax and reduce if needs be.

### Acceleration feedforward (advanced)

- ◆ Reduce acceleration feedforward (2010.24) at lowest speed until the following error is minimized.
  - ◆ Check settings at 50% Vmax and reduce if needs be.
- Check settings at Vmax and reduce if needs be

### Optimization of pressure/Force Controller

#### In this chapter you can read about:

Activation of pressure / force control .....	145
Adapt control parameters .....	145
Force feedforward.....	146

### Activation of pressure / force control

- ◆ Set all control parameters to 0
  - ◆ P-term (%N)
    - main axis: Object 2250.13
    - auxiliary axis: Object 2251.13
  - ◆ I-term (%N)
    - main axis: Object 2250.14
    - auxiliary axis: Object 2251.14
  - ◆ Internal and external window of I-term (N)
    - internal window: Object 2250.15
    - external window: Object 2220.16
  - ◆ KFv (speed feedback) (%s/mm)
    - main axis: Object 2250.20
    - auxiliary axis: Object 2050.9
- ◆ Set force demand value and force gradient to expedient small values.
  - ◆ The actual force should be smaller than the demand force.

### Adapt control parameters

- ◆ Increase P-term in small increments until the actual force is near the demand force.
  - ◆ Pressure or force should remain stable and not be subject to instability.
  - ◆ P-term starts working at 0,0000001%/N
- ◆ Set window for I-term.
  - ◆ The value for the outer window should be greater than the actual difference between demand force and actual force (697.1, 697.11).
  - ◆ Value for the inner window should be set very small in order to equate demand force and actual force.
  - ◆ Positive limit of I-term to 100%
    - Main axis: Object 2250.17, auxiliary axis: Object 2251.17
    - Negative limit I-term to -100%
      - Main axis: Object 2250.18, auxiliary axis: Set object 2251.18.
- ◆ Increase P-term in small increments until the actual force = demand force.
  - ◆ Value should be held small in order to avoid strong overshoot.
  - ◆ I-term starts working at 0.00013%/N.
  - ◆ I-term is switching (only swiches on, if the actual force is within the window defined before).
- ◆ Increase speed feedback FKv slightly if necessary, this will reduce the error between the demand force and the actual force while the force is built up. The force is built up faster, peaks can however be the result of increased values.

**Force feedforward**

For the force control with pumps and pressure valves, the control signal is, differently from the control with path valves, proportional to the actual pressure value for dynamic control the integrator is not sufficient in order to generate the static component of the control variable.

This requires the force feedforward (KFs).

Main axis: Object 2250.23

auxiliary axis: Object 2251.23

- ◆ KFs (%/N) or(%/bar/PSI), a defined component of the force build-up is built up in a controlled manner.

## 4.3.4. Input simulation

### In this chapter you can read about:

Calling up the input simulation .....	147
Functionality .....	148

**Function** The input simulation is used for the performance of tests without the complete input/output hardware being necessary.  
The digital inputs (standard and inputs of M10/M12 option) as well as the analog inputs are supported.  
The following operating modes are available for digital inputs:

- ◆ The physical inputs are deactivated, the digital inputs are only influenced via the input simulation.
- ◆ The digital inputs and the physical inputs are logically or-linked.  
This necessitates very careful action, as the required function is, above all with low-active signals, no longer available.

The pre-setting of an analog input value is always made in addition to the physical analog input.

the function of the inputs depends on the Compax3 device type; please refer to the respective online help or the manual.

**The input simulation is only possible if the connection with Compax3 is active and if the commissioning mode is deactivated!**

### 4.3.4.1 Calling up the input simulation

Open the optimization window (double click in the C3 ServoManager tree entry: Optimization).  
Activate the Tab "Setup" in the right lower window.  
Clicking on the following button will open a menu; please select the input simulation.



#### 4.3.4.2 Functionality

Window Compax3 InputSimulator:

**1st series:** Standard inputs I7 ... I0 = "0" button not pressed; = "1" switch pressed

**2nd series:** Optional digital inputs (M10 / M12)

Green field: port 4 is defined as input

Red field: port 4 is defined as output

the least significant input is always on the right side

**3rd series:** if the button "deactivating physical inputs" is pressed, all physical, digital inputs are deactivated; only the input simulation is active.

If both sources (physical and simulated inputs) are active, they are or-linked!



**Caution!**

Please consider the effects of the or-linking; above all on low-active functions.

**4th series:** Simulation of the analog inputs 0 and 1 in 100mV – steps.

The set value is added to the value on the physical input.

**After the input simulation has been called up, all simulated inputs are on "0".**

**When the input simulation is left, the physical inputs become valid.**



### 4.3.5. Setup mode

The setup mode is used for moving an axis independent of the system control  
The following functions are possible:

- ◆ Machine reference run
- ◆ Jog+ / Jog-
- ◆ Activation / deactivation of the motor holding brake.
- ◆ Acknowledging errors
- ◆ Defining and activating a test movement
- ◆ Activating the digital outputs.

#### Activating the setup mode



By activating the setup mode, the the control program (IEC Program) is deactivated; the system function of the device is no longer available. Access via an interface (RS232/RS485, Profibus, CANopen,...) and via digital inputs is deactivated.

**Attention! The safety functions are not always guaranteed during the setup mode!**

- ◆ In the Commissioning window (left at the bottom) the commissioning mode is activated.
- ◆ Then parameterize the desired test movement in the Parameter window. You can accept changed configuration settings into the current project.
- ◆ Now energize drive in the commissioning window and start the test movement.



**Caution! Safeguard the travel range before energizing!**

#### Deactivating the setup mode



If the setup mode is left, the drive is deactivated and the the control program (IEC Program) is re-activated.

- Note:**
- ◆ The parameters of the setup window are saved with the project and are loaded into Compax3 if the setup mode is activated (see below).

Autoryzowany dystrybutor Parker:

**ARA**

**P N E U M A T I K**

53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)



**4.3.5.1 Motion objects in Compax3**

The motion objects in Compax3 describe the active motion set. The motion objects can be influenced via different interfaces. The following table describes the correlations:

Source	active motion objects		Compax3 device
	==>	describe	
	<==	read	
<b>Set-up</b> (working with the commissioning window)	==>	<ul style="list-style-type: none"> <li>◆ With the "accept entry" button.</li> <li>◆ The current project gets a motion set. Download by activating the motion</li> </ul>	<b>Active motion objects</b> <ul style="list-style-type: none"> <li>◆ Position [O1111.1]</li> <li>◆ Speed [O1111.2]</li> <li>◆ Acceleration [O1111.3]</li> <li>◆ Deceleration [O1111.4]</li> <li>◆ jerk* [O1111.5] (Acceleration)</li> <li>◆ Jerk* [O1111.6] (Deceleration)</li> </ul> * for lxxT11 - devices, both jerk values are identical
	<==	<ul style="list-style-type: none"> <li>◆ When opening the commisioning window of a new project for the first time.</li> <li>◆ Activated via the "Upload settings fromdevice" button (bottom at the left side).</li> </ul>	
<b>Compax3 ServoManager project</b>	==>	<ul style="list-style-type: none"> <li>◆ C3lxxT11: via an activated motion set</li> <li>◆ C3l2xT11: via a configuration download</li> </ul>	
	<==	For Compax3 l2xT11: <ul style="list-style-type: none"> <li>◆ via a configuration upload</li> <li>◆ in the commissioning window via "accept configuration"</li> </ul>	
<b>Fieldbus (Compax3 l2xTxx)</b>	==>	◆ Changing the motion objects directly	
	<==	◆ Reading the motion objects	
<b>IEC61131-3 program</b> (Compax3 lxxT30, lxxT40)	==>	◆ via positioning modules	

**4.3.6. ProfileViewer for the optimization of the motion profile**

In this chapter you can read about:

- Mode 1: Time and maximum values are deduced from Compax3 input values..... 151
- Mode 2: Compax3 input values are deduced from times and maximum values..... 151

You will find the ProfileViewer in the Compax3 ServoManager under the "Tools" Menu:



#### 4.3.6.1 Mode 1: Time and maximum values are deduced from Compax3 input values

- ◆ The motion profile is calculated from Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
  - ◆ Times for the acceleration, deceleration and constant phase
  - ◆ Maximum values for acceleration, deceleration and speed

#### 4.3.6.2 Mode 2: Compax3 input values are deduced from times and maximum values

- ◆ A jerk-limited motion profile is calculated from the positioning time and the maximum speed / acceleration
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
  - ◆ the parameters Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
  - ◆ Times for the acceleration, deceleration and constant phase
  - ◆ Maximum values for acceleration, deceleration and speed

#### Set deceleration and acceleration phase


The profile can be defined more exactly by entering the segmentation into deceleration and acceleration phase.

When setting 50% and 50%, a symmetrical design will result, the values for triangular operation are calculated, which is limited by the maximum speed.

The total of the percentage values may not exceed 100.

The percentage entries refer to the total positioning time.

#### **Example:**



# 5. Motion control

## In this chapter you can read about:

Programming based on IEC61131-3 .....	152
Status diagrams .....	162
Control functions .....	165
Reading values .....	170
Determine valve/range parameters (C3_GetSystemFingerPrint) .....	174
Positioning functions (standard) .....	178
Superimposed motion .....	198
Adjust force / pressure (C3_PressureForceAbsolute) .....	203
Dynamic switching: Position- on force/pressure - adjustment .....	204
Cam Control .....	207
Cam switching mechanism .....	288
Error handling .....	300
Process image .....	303
Interface to C3 powerPLmC .....	314
IEC examples .....	322
Profibus: Emulating the ProfiDrive profile (C3F_ProfiDrive_Statemachine) .....	329

## 5.1 Programming based on IEC61131-3

### In this chapter you can read about:

Prerequisites .....	152
CoDeSys / Compax3 target system (Target Package) .....	153
Languages supported .....	154
Function range supported .....	154
Data types supported .....	157
Retain Variables .....	157
Recipe table with 9 columns and 32 lines .....	157
Maximum program size .....	158
Cycle time .....	158
Access to the Compax3 object directory .....	158
Compilation, debugging and down/upload of IEC61131 programs .....	159
General rules / timing .....	160
Library constants .....	161

### 5.1.1. Prerequisites

- ◆ Installation of the CoDeSys programming tool.
- ◆ Installation of necessary Target Packages (target systems):
  - ◆ Bring up the "InstallTarget" program (program group "3S Software": "CoDeSys V2.3")
  - ◆ From "Open", select the target file; file name: "Compax3.tnf".
  - ◆ The selected target can be installed with "Install".

## 5.1.2. CoDeSys / Compax3 target system (Target Package)

### Targets for Compax3 servo axes

Beginning with Compax3 software version V2.0, two Compax3 targets are included with delivery (containing module and object descriptions).

- ◆ **CoDeSys for C3 T30:** for Compax3 T30 (beginning with Compax3 software version V2.0)
- ◆ **CoDeSys for C3 T40:** for Compax3 T40 (beginning with Compax3 software version V2.0)

The old target is still available for programs that were created earlier (created with Compax3 software version < V2.0).

- ◆ **CoDeSys for Compax3:** for Compax3 T30  
This programs are thus still capable of running.

When migrating to a new target, you must be certain that the module and object names have been changed.  
Edit the appropriate parts of the IEC program accordingly.

### Targets for Compax3F hydraulic axes

- CoDeSys for C3F T30:** for Compax3 T30
- CoDeSys for C3F T40:** For Compax3 T40

### 5.1.2.1 Program development and test

- |                            |   |
|----------------------------|---|
| <b>Program development</b> | <p>CoDeSys is the development environment for control systems which will help you develop Compax3 IEC61131 programs. CoDeSys is called up from the Compax3 ServoManager (under "programming: IEC61131-3 development environment")<br/>The IEC program can be integrated into the C3 ServoManager project or exported again from the project as required.<br/>When CoDeSys is brought up, the IEC program stored in the project is opened. If the project does not contain an IEC program, a selection dialog appears.</p>   |
| <b>Download to Compax3</b> | <p>After the IEC61131 program has been developed and compiled with CoDeSys, it is downloaded to Compax3 by means of the ServoManager (in "Download: IEC61131-3").</p>   |
| <b>Program test</b>        | <p>For testing your program directly with Compax3, you may use the Compax3 IEC61131-3 debugger (the debug functions of CoDeSys are not supported in conjunction with Compax3). The debugger is called up from the ServoManager (under Programming: IEC61131-3 debugger). It automatically accesses the last IEC61131-3 program in the ServoManager to be loaded into Compax3 with "Download: IEC61131-3" and makes its modules and variables available in the project tree.<br/>The data from Compax3 are read via the instruction "log in". Please note in this regard that the interface to Compax3 can only be assigned once: Online functions in the ServoManager such as Upload, Download, Status display in the Optimization window or oscilloscope functions are not possible simultaneously. These functions interrupt the connection between debugger and Compax3 automatically.</p> |

### 5.1.2.2 Recipe management

The recipe management function in CoDeSys is not supported in conjunction with Compax3. Please use the recipe table available in Compax3 (also see in the configuration wizard).

### 5.1.3. Languages supported

- ◆ IL (Instruction List)
- ◆ ST (Structured Text)
- ◆ FBD (Function block diagram)
- ◆ CFC (continuous function chart editor)
- ◆ LD (Ladder diagram)

### 5.1.4. Function range supported

#### In this chapter you can read about:

Operators supported.....	154
Standard functions supported .....	155
Standard function modules supported.....	156

#### 5.1.4.1 Operators supported

IL	FBP / CFC / SFC	ST
LD(N)		
ST(N)		
R		
S		
AND(N)	AND	AND(N)
OR(N)	OR	OR(N)
XOR(N)	XOR	XOR(N)
NOT	NOT	NOT
ADD	ADD	+
SUB	SUB	-
MUL	MUL	*
DIV	DIV	/
GT	GT	>
GE	GE	>=
EQ	EQ	=
NE	NE	<>
LE	LE	<=
LT	LT	<
RET	RET	RETURN
	MOVE	
		:=

CAL(C/N)		
JMP(C/N)		
		CASE
		DO
		ELSE
		ELSIF
		END_CASE
		END_FOR
		END_IF
		END_REPEAT
		END_WHILE
		EXIT
		FOR
		IF
		REPEAT
		THEN
		TO
		UNTIL
		WHILE

#### 5.1.4.2 Standard functions supported

##### Bit manipulation functions

SHL, SHR, ROL, ROR

##### Numeric functions

ABS, SQRT, SIN, COS

##### Functions for type conversion

Type conversions x_TO_y	X=Source data type, Y=Target data type
TRUNC	

##### Functions for selection

MIN	Not for BOOL /WORD / DWORD
MAX	Not for BOOL /WORD / DWORD
LIMIT	Not for BOOL /WORD / DWORD
SEL	Not for BOOL /WORD / DWORD

**5.1.4.3 Standard function modules supported****FlipFlops**

RS, SR,

**Trigger**

R\_TRIG, F\_TRIG,

**Numerator**

CTU, CTD, CTUD,

**Timer**

TON, TOF, TP,  
max. 8 pcs., time resolution 0.5ms  
(the number of timers required is displayed in the CoDeSys output window during compilation)

**PID Controller function block**



### 5.1.5. Data types supported

The following data types are available for IEC61131-3 programming:

Name	Division	Format
BOOL	Status values: TRUE or FALSE	Logical variable.
INT	-32768...32767	16-bit integer: Fixed point number without places after the decimal
DINT	-2147483648...2147483647	32-bit integer: Fixed point number without places after the decimal
REAL		32-bit floating point: 16 bits before the decimal and 16 bits after the decimal
WORD	0...65535	16-bit bit sequence (no range of values)
DWORD	0...4294967295	32-bit bit sequence (no range of values)
TIME	0...4194,3035s	32 Bit - Format (resolution: 0.5 ms)
ENUM	User-defined type of enumeration (local enumerations are not supported)	

Altogether 500 16-bit variables are available. These include BOOL, INT, and WORD.

Altogether 150 32-bit variables are available. These include DINT,DWORD,TIME,REAL.

The number of the required variables is displayed in the CoDeSys output window during compilation.

### 5.1.6. Retain Variables

6 retain variables (variables that are safe from power failure) are available

- ◆ 3x16-bit retain-variables
- ◆ 3x32-bit retain-variables

### 5.1.7. Recipe table with 9 columns and 32 lines

An array, i.e. a table with 9 columns and 32 rows, is available to store values.

This table is freely assignable and can be used for example to store position sets or for recipe management.

In addition, this table can be used to exchange data with an external control system or a POP, for example.

The layout of the table is as follows:

Column 1 Type: REAL Objects O1901	Column 2 Type: REAL Objects O1902	Column 3 Type: INT Objects O1903	Column 4 Type: INT Objects O1904	Column 5 Type: INT Objects O1905	Column 6 Type: DINT Objects O1906	Column 7 Type: DINT Objects O1907	Column 8 Type: DINT Objects O1908	Column 9 Type: DINT Objects O1909
Row 1 "C3Array_Col 1_Row1" (1901.1)	Row 1 "C3Array_Col 2_Row1" (1902.1)	Row 1 "C3Array_Col 3_Row1" (1903.1)	Row 1 "C3Array_C ol4_Row1" (1904.1)	Row1 "C3Array_C ol5_Row1" (1905.1)	Row 1 "C3Array_C ol6_Row1" (1906.1)	Row 1 "C3Array_C ol7_Row1" (1907.1)	Row 1 "C3Array_C ol8_Row1" (1908.1)	Row 1 "C3Array_C ol9_Row1" (1909.1)
...	...	...	...	...	...	...	...	...
...	...	...	...	...	...	...	...	...
...	...	...	...	...	...	...	...	...
Row 32 "C3Array_Col 1_Row32" (1901.32)	Row 32 "C3Array_Col 2_Row32" (1902.32)	Row 32 "C3Array_Col 3_Row32" (1903.32)	Row 32 "C3Array_C ol4_Row32" (1904.32)	Row 32 "C3Array_C ol5_Row32" (1905.32)	Row 32 "C3Array_C ol6_Row32" (1906.32)	Row 32 "C3Array_C ol7_Row32" (1907.32)	Row 32 "C3Array_C ol8_Row32" (1908.32)	Row 32 "C3Array_C ol9_Row32" (1909.32)

In addition to direct access to every individual field in the table, direct access is also possible through pointer addressing.

To do this, the table pointer "C3ArrayPointer\_Row" (Object 1900.1) must be set to the desired rows.

This makes access to Columns 1 through 9 of the referenced rows possible through "C3Array\_Indirect\_Col1" to "C3Array\_Indirect\_Col9" (objects 1910.1 to 1910.9).

### 5.1.8. Maximum program size

Up to 6000 (IL) instructions are possible

**Note!** Please note, that integrated function modules do also require program memory. The required program memory can therefore increase due to a Targets update, even without any program changes.

The number of instructions generated is displayed in the CoDeSys output window by the Compax3 compiler during interpretation.

### 5.1.9. Cycle time

Minimal cycle time: 1ms.


The cycle time can be adjusted with the Compax3 ServoManager when downloading IEC61131-3 programs.

It is possible to optimize later in the optimization display of the Compax3 Servomanager. The cycle time is displayed there in increments of 500  $\mu$ s (2 = 1 ms; 3 = 1.5 ms; etc.).

The IEC61131-3 program is stopped cycle time of 0.

### 5.1.10. Access to the Compax3 object directory

All Compax3 objects are encapsulated in the "C3" program module. Access to **Compax3 Objects** (see page 414) in CoDeSys:



Compax3 objects are divided into groups:

C3.	Compax3 - Objects
C3Array.	Variable (Recipe) List
C3Pop.	Objects for the Parker Operator Panel Pop.
C3Cam.	Objects for the T40 cam control. <b>Do only use the objects described in this help; the additional objects are for internal use only!</b>
C3Plus.	Additional objects that are generally not required.
C3Scope.	Objects for programming the oscilloscope function. <b>For internal use only!</b>

The object name reveals the group assignment.

In general, it applies:

**Objects that are not described here are reserved objects!**

### 5.1.11. Compilation, debugging and down/upload of IEC61131 programs

- ◆ Compiling IEC61131-3 programs in CoDeSys
- ◆ Downloading or uploading of IEC61131-3 programs with the Compax3 ServoManager.
- ◆ The debugger is called up from the C3 ServoManager under "Programming: IEC61131-3 debugger" called up.

**Note:**

Before compiling you have to enter for which Compax3 versions the compilation is to be executed.

Please note that when selecting "all versions" not all functions are available, only the minimal range of functions is supported.

Only if the latest firmware version was selected (and the corresponding firmware is loaded in the target Compax3) all functions described here are supported.

## 5.1.12. General rules / timing

### General rules

<b>Positioning</b>	<p>Within an IEC cycle, only one positioning module may be activated! If 2 positioning modules are activated within one IEC cycle, it is not defined which one is executed.</p>
<b>Status of the outputs</b>	<ul style="list-style-type: none"> <li>◆ The outputs "Done", "InVelocity", "Error", "ErrorID" and "CommandAborted" reset with the falling edge of the "Execute" input.</li> <li>◆ If the "Execute" input goes back to FALSE again before the module action (for example positioning) has been completed ("pulse to Execute"), the corresponding outputs (for example "Done") will still be set for exactly ONE cycle upon termination.</li> <li>◆ The outputs "Done" and "Error" are never simultaneously TRUE.</li> <li>◆ If the instance of a function module receives a new "Execute" signal before the function ends, the module will not show any response (no "Done" and no "Command Aborted") in reference to the previous action.</li> </ul>
<b>Input parameters</b>	<ul style="list-style-type: none"> <li>◆ Parameters are accepted with the rising edge of the "Execute" signal.</li> <li>◆ To be able to accept modified parameters, the module must be triggered again with an "Execute" signal.</li> </ul>
<b>Missing input parameters</b>	<ul style="list-style-type: none"> <li>◆ If an input parameter is missing, the previous value of this instance will be used in accordance with IEC61131-3.</li> <li>◆ The default value is used the first time a call is made.</li> </ul>
<b>Position and distance</b>	<ul style="list-style-type: none"> <li>◆ "Position" is a value that is defined for a reference system, i.e. a specific position value is a fixed location in the reference system.</li> <li>◆ "Distance" is the difference between 2 positions.</li> </ul>
<b>Sign</b>	<ul style="list-style-type: none"> <li>◆ "Velocity", "Acceleration", "Deceleration" and "Jerk" are always positive variables.</li> <li>◆ "Position" and "Distance" may be positive or negative.</li> </ul>
<b>Error handling</b>	<ul style="list-style-type: none"> <li>◆ All function modules have an "Error" output that can be activated by a module during a module sequence.</li> <li>◆ The ErrorID (error number) can be read by an axis error with the "MC_ReadAxisError" module.</li> </ul>
<b>Behavior of the "Done" - output</b>	<p>The "Done" output is set if the function module has been successfully executed. If one positioning process is interrupted by a second before it is complete, the first function module will not set "Done".</p>
<b>Behavior of the "CommandAborted" output</b>	<p>"CommandAborted" is set if a positioning process is interrupted by a second positioning process, by "MC_Stop" or MC_Power. The reset behavior of "CommandAborted" is the same as "Done". If "CommandAborted" occurs, the other outputs will be reset.</p>
<b>Value range of the movement parameters</b>	<p>Please note that the limits are specified in revolutions. To convert to the configured unit, multiply the min/max values by the "travel distance per motor revolution".</p>
<b>Linear motors</b>	<p>With a configured linear motor, all revolution data must be replaced by pitch. To convert to the configured unit, the min/max values must be multiplied by the pitch length (see the technical data for the motor).</p>

### 5.1.13. Library constants

The following global constants are declared in the PLCopen function module library:

Name	Table Style	Description
<b>For power supply of the axis inputs/outputs of modules:</b>		
Axis_Ref_LocalAxis	INT	Local axis for Compax3F: Main axis
Axis_Ref_LocalAxisAux	INT	Only for Compax3F: Local auxiliary axis
Axis_Ref_Virtual	INT	virtual Master (only with T40)
AXIS_REF_LocalCam	INT	Local Cam axis (physically present axis)


<b>For the selection of the master signal source:</b>		
AXIS_REF_Physical	INT	for +/-10V analog input, step / direction input 5V or Encoder A/B input 5V (depending on the configuration of the physical source under signal source)
Axis_Ref_Virtual	INT	virtual Master
Axis_Ref_HEDA	INT	HEDA
Axis_Ref_Additional	INT	reserved (additional sources)
Axis_Ref_CAN	INT	reserved (CAN)
<b>General constants</b>		
MC_Direction_Positive	INT	For supply of the Direction input of the MC_MoveVelocity module (for positive rotational direction)
MC_Direction_Negative	INT	For supply of the Direction input of the MC_MoveVelocity module (for negative rotational direction)
MC_Direction_Current	INT	For supply of the Direction input of the MC_MoveVelocity module (retaining the last rotational direction to be selected)
Direction_Memory	INT (Variable)	The MC_MoveVelocity modules instances store the last direction parameter in this variable. This variable can only be used by Motion Control modules and must not be overwritten!
OutputSelect_C3Output	INT	for the C3_OutputSelect module: Assignment of the source for the respective output to module "C3_Output".
OutputSelect_FastCam	INT	for the C3_OutputSelect module: Assignment of the source for the respective output to the respective fast cam.
<b>Reset positioning mode</b>		
All directions	INT	C3_all_direction
Positive direction	INT	MC_positive_direction
Shortest path	INT	MC_shortest_way
Negative direction	INT	MC_negative_direction
Actual direction	INT	MC_current_direction

## 5.2 Status diagrams

**In this chapter you can read about:**


Status diagram of Compax3F main axis ..... 162  
 Status diagram of Compax3F auxiliary axis ..... 163  
 Status diagram of the virtual master ..... 164

### 5.2.1. Status diagram of Compax3F main axis




- \* C3\_PressureForceStop is valid for axes that are entirely pressure/force controlled, where no position control is configured.
- ◆ T30 Functions: Transitions and states as continuous line, text not in italics
- ◆ T40 Functions: complete status diagram, all functions
- ◆ Special T40 functions are displayed in italics and in dashed line
- ◆ MC\_Power.Enable = FALSE changes to "not powered" from any state (apart from ErrorStop).

**5.2.2. Status diagram of Compax3F auxiliary axis**



- \* C3\_PressureForceStop is valid for axes that are entirely pressure/force controlled, where no position control is configured.
- ◆ T30 Functions: Transitions and states as continuous line, text not in italics
- ◆ T40 Functions: complete status diagram, all functions
- ◆ Special T40 functions are displayed in italics and in dashed line
- ◆ MC\_Power.Enable = FALSE changes to "not powered" from any state (apart from ErrorStop).

**5.2.3. Status diagram of the virtual master**



Create a program for the virtual axis.  
 The virtual axis supports the function modules listed in the status diagram.  
 To do so, the input/output variable "Axis" is assigned to the constant "AXIS\_REF\_Virtual".  
 The position value of the virtual axis can be used as master signal source.

**Note:** Please note that the virtual axis is only available for function modules listed in the status diagram.

Please note:

**The "virtual master" function is only possible, if no auxiliary axis was configured.**




## 5.3 Control functions

**In this chapter you can read about:**

Activation of the drive (MC\_Power) ..... 165  
 Stop (MC\_Stop) ..... 166  
 C3\_SetControlMode ..... 169

### 5.3.1. Activation of the drive (MC\_Power)

<b>FB name</b>	<b>MC_Power</b>	
Transition into the status "Standstill: disable" or "Standstill: powered"		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activates the module; as long as Enable=TRUE, the drive is activated. With Enable=FALSE, the drive stops with the <b>ramp defined for the error</b> (see page 74).  <b>Please observe:</b> The configured error ramp is limited. The error ramp will not be smaller than the deceleration set in the last motion set.
<b>VAR_OUTPUT</b>		
<b>Status</b>	BOOL	State of the power output stage (TRUE=drive activated, FALSE=drive deactivated)
<b>Error</b>	BOOL	Error when deactivating the drive
Notes:		
<ul style="list-style-type: none"> <li>◆ If the input parameter "Enable" = TRUE, all enables of the drive will be set.</li> <li>◆ All enables will be reset if the input parameter "Enable" = FALSE, the axis decelerates with the configured error ramp to speed = 0.</li> <li>◆ Note on Compax3 Servo: During automatic commutation, the output "Status" is not set to TRUE for activation, but rather not until after automatic commutation has been successfully completed.</li> <li>◆ An enable is denied until the intermediate circuit is loaded, this may take up to 2s when switching on Compax3H for the first time.</li> <li>◆ If the drive is in <b>error state</b> (see page 302) (error reaction 1: controller active) and the enable of the MC_Power is deactivated, the drive is deactivated (error reaction 2).</li> <li>◆ C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group.</li> </ul>		




### 5.3.2. Stop (MC\_Stop)

**In this chapter you can read about:**

- MC\_Stop at pressure/force control..... 167
- MC\_Stop: Example 1..... 167
- MC\_Stop: Example 2..... 168

<b>FB name</b>		<b>MC_Stop</b>
Stops the current movement		
<b>Please note:</b> Only one instance of MC_Stop is permitted per axis!		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Stops the movement
<b>Deceleration</b>	DINT	The value of deceleration (always positive) [units/s <sup>2</sup> ] Value range: 0.24 rev/s <sup>2</sup> ... 1000000 rev/s <sup>2</sup>  <b>Please observe:</b> The configured STOP ramp is limited. The STOP ramp will not be smaller than the deceleration set in the last motion set.
<b>Jerk</b>	DINT	Value of the deceleration jerk [units/s <sup>3</sup> ] (always positive) Value range: 30 rev/s <sup>3</sup> ... 125,000,000 rev/s <sup>3</sup>
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Stop move
<b>Error</b>	BOOL	Error while stopping positioning
<b>Note:</b>		
<p>As long as the "Execute" input is set, the axis remains in the "Stopping" status (as long the axis is activated) and is unable to execute any additional movement commands!</p> <p>If the axis is deactivated by setting the Enable signal of the "MC_Power" module to FALSE, the Stopping state will then be exited.</p> <p>If the enable signal of the "MC_Power" module is set to TRUE again, the axis goes back to the "Stopping" state again if the Execute input of the "MC_Stop" module is still TRUE.</p> <p>C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group.</p>		



**5.3.2.1 MC\_Stop at pressure/force control**

If a position control is configured, the MC\_Stop.Execute = TRUE switches to position control (pQ). The axis is stopped (with a ramp defined via Deceleration and Jerk).


If no position control is defined, MC\_Stop does not have any function. Set the axis into a Stop state by specifying a defined force (or pressure difference) in a Stop state.

**5.3.2.2 MC\_Stop: Example 1**


The following illustration shows an example of how the MC\_Stop module interrupts and stops a movement that is in progress.

If a positioning module is interrupted by the MC\_Stop module, it reports "Command Aborted" and can no longer be executed as long as the MC\_Stop module is active. If the MC\_Stop module is inactive (no "Execute" signal), the function module can be executed again.


Timing Diagram:



**Note:** If a positioning is to follow immediately after the stop, this can take place with the falling edge of the done output at the earliest:




5.3.2.3 MC\_Stop: Example 2



### 5.3.3. C3\_SetControlMode

<b>FB name</b>		<b>C3_SetControlMode</b>
Switching between open loop and closed loop.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis ID (Library constants) AXIS_REF_LocalAxis: Main axis AXIS_REF_LocalAxisAux: Auxiliary axis
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>ClosedLoop</b>	BOOL	TRUE: Sets closed loop operation for the selected axis FALSE: Sets open loop operation for the selected axis
<b>VAR_OUTPUT</b>		
<b>ClosedLoop_IsActive</b>	BOOL	TRUE, when closed loop operation has been set
<b>Error</b>	BOOL	Error while executing module. The axis may not be in the "operational" or a higher state for the change!
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ A change can only be executed if the axis is in pre-operational state (Standstill: not powered).</li> <li>◆ In open loop mode, the axis may drift!</li> <li>◆ For safe operation in the closed loop mode, the controller must be aligned!</li> </ul>		




## 5.4 Reading values

**In this chapter you can read about:**


Reading the current position (MC\_ReadActualPosition) ..... 170  
 Read access to the (C3\_ReadArray) array ..... 172  
 Reading the device status (MC\_ReadStatus) ..... 173

### 5.4.1. Reading the current position (MC\_ReadActualPosition)

<b>FB name</b>	<b>MC_ReadActualPosition</b>	
Reading the current axis position		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activates the module, continuous reading of the axis position as long as Enable=TRUE
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Position value available
<b>Error</b>	BOOL	Error while reading the position
<b>Position</b>	REAL	Axis position
Note: -		




You can read the current position of the axis with this module.  
 As long as the input parameter "Enable" = TRUE, the current parameter value will be supplied **cyclically** (see page 317) to the output parameter "Position".  
 The status of the input parameter must be present for at least one module call.  
 The following illustration shows the behavior of parameters in the MC\_ReadActualPosition function module.



**5.4.2. Read access to the (C3\_ReadArray) array**


<b>FB name</b>		<b>C3_ReadArray</b>
This module is used for simplified read access to the array (recipe table).		
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	The desired rows can be read with the Enable input (after selecting "Row").
<b>Row</b>	INT	The desired row in the table must be created at the end of the Row module input. this input works with object 1900.1; please take this into consideration, if you directly access the object 1900.1 in addition.
<b>VAR_OUTPUT</b>		
<b>Error</b>	BOOL	Error as an output indicates that an error was encountered while reading the array (a row that does not exist selected on the Row input).
<b>Col1 – Col9</b>	REAL INT DINT	The individual columns of the array can be accessed through outputs Col1 through Col9.
Notes: Rows will be read cyclically as long as Enable = TRUE.		





### 5.4.3. Reading the device status (MC\_ReadStatus)

<b>FB name</b>	<b>MC_ReadStatus</b>	
Specifies the current status according to the PLCopen status machine		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activates the module; continuous outputs of output parameters as long as Enable=TRUE
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Status values available
<b>Error</b>	BOOL	Error while executing module
<b>Errorstop</b>	BOOL	Error stop function. The motor brakes as specified by the stop ramp and is de-energized;
<b>Stopping</b>	BOOL	The motor is stopped;
<b>Standstill</b>	BOOL	The motor is stopped;
<b>DiscreteMotion</b>	BOOL	Individual movement;
<b>ContinuousMotion</b>	BOOL	Continuous positioning;
<b>Homing</b>	BOOL	Machine home is approached;
<b>SynchronizedMotion</b>	BOOL	Synchronous motion
Note: See also in the status diagram.		



## 5.5 Determine valve/range parameters (C3\_GetSystemFingerPrint)

**In this chapter you can read about:**

Important notes..... 176  
 Procedure when working with the C3\_getSystemFingerPrint ..... 177

The characteristic line known as "SystemFingerPrint" contains besides the behavior of the valve (valve characteristic line) all static non-linearities of the hydraulic system.  
 The "SystemFingerPrint" is valid in the working point, where it has been determined. If the parameters such as system pressure, load, friction or oil temperature change significantly, this may affect the usability of the "SystemFingerPrint".


<b>FB name</b>	<b>C3_GetSystemFingerPrint</b>	
This module is used for measuring and memorizing the "SystemFingerPrint" (Signal/Flow characteristic)		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis ID (Library constants) AXIS_REF_LocalAxis: Main axis AXIS_REF_LocalAxisAux: Auxiliary axis
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Stop</b>		Stops the measurement sequence with a positive edge
<b>Number_of_Measuring_Points</b>	INT	Number of measuring points (max. 300). Defines the setpoint accuracy.
<b>min_Position</b>	REAL	Position window, where the measurement takes place
<b>max_Position</b>	REAL	
<b>max_Velocity</b>	REAL	Highest speed to be measured
<b>Acceleration</b>	DINT	Maximum acceleration during the measurement
<b>Jerk</b>	DINT	Maximum jerk during the measurement
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Measurement terminated successfully
<b>Error</b>	BOOL	A fault has occurred. Measurement was terminated (by error or by stop).
<b>ErrorID</b>	Word	Indicates, which error caused the abort: 0 = no Error 1 = measurement was terminated with stop (measurement is immediately terminated) 2 = Compax3F is in error state (measurement is immediately terminated) 3 = The given adjusting range could not be entirely identified. (Measurement is continued in the opposite direction and the result is memorized in the Flash). Possible causes: <ul style="list-style-type: none"> <li>◆ In the set travel range, the end speed (maxVelocity) could not be reached: =&gt;reduce max_Velocity</li> <li>◆ The demanded accuracy could not be achieved: Reduce (ax_Error=max_Velocity / Number_of_Measuring_Points) =&gt; Number_of_Measuring_Points</li> </ul> 4 = error when memorizing the characteristic line in the flash memory, no CurveID free 5 = The axis was energized at the start of the identification 6 = Input parameters of the measurement are outside the permissible range (Number_of_Measuring_Points or max_Velocity)

<b>Status</b>	INT	Indicates how advanced the measurement is yet. 0 = waits for the start of the measurement with "Execute" 1 = Initialization of the measurement 2 = determination of the offset (at which valve position does the axis no longer move) 3 = Execution of the measurement 4 = Recovering of different settings 5 = Interpolation of the measurement values 6 = Memorizing the characteristic line in the flash 7 = Setting the Conditioning Chain Parameter to a new characteristic line 8 = Measurement terminated successfully, waiting for "Execute"
<b>CurveID</b>	INT	States, under which ID the characteristic line was memorized. The ID of the characteristic line is in object 24x3.2* If you wish to switch back to characteristic lines set before, you should read the ID of the characteristic line before activating the module. Switching back of a characteristic line: <ul style="list-style-type: none"> <li>◆ Select characteristic line (for all connected Conditioning Chains) 24x3.2* = number of the characteristic line</li> <li>◆ Select characteristic line (for all connected Conditioning Chains) 24x3.1=1*</li> </ul>

**Note:**

- ◆ After successful measurement of the characteristic line, it is memorized in the same way and at the same place as up to now the valve characteristic lines. As the memory utilized provides space for up to 8 characteristic lines, existing characteristic lines must not be deleted.
- ◆ In order to activate the characteristic line for the control, the characteristic lines are activated by this module with 24x3.1=1\* at the conditioning chains which are connected to the measured axis.

\* (x stands for the respective Conditioning Chain: x=0 for Chain 0, x=1 for Chain 1,...)



### 5.5.1. Important notes

**Requirements:**

- ◆ Stable control (even though slow)
- ◆ Following error window set relatively wide => unless abortion due to following error is possible.
- ◆ The controller may not be active when the identification is started (State "**Standstill disable**").
- ◆ The measurement is in part executed in open loop operation. This means that the function is, for example with z-axes, only possible to a limited extent. (the load could for example be lowered due to leakages)
- ◆ The entire hydraulic system should be well damped.  
Unless the measurement could be strongly influenced by resonance frequencies present.
- ◆ There must be enough travel space in order to perform the identification.
- ◆ Enough memory space in the characteristics memory  
Altogether 8 characteristic lines can be stored in the memory of the controller, if these all are taken up by the identification, the identification will be terminated with a corresponding error.  
Check before the start of the identification, if there is enough memory space available.  
If there is no space available, the entire characteristics memory can be deleted by writing a value  $\neq 0$  into object 2439.3 C3 "Plus.CurveMemory\_Erase. Attention! all characteristics present are deleted.
- ◆ The loop gain of the speed control should be set at least approximately. If the loop gain is much too small, the preset speed range might not be entirely measured. If the loop gain is too high, the resolution of the measurement will be too low.

**Please respect the following for the measurement:**


- ◆ The axis to be measured may not be used for an action in the IEC.  
(for example MC\_Power, MC\_Stop, MC\_MoveRelative,...)
- ◆ The software oscilloscope cannot be used during the measurement.

**State after the end of the measurement:**

- ◆ Axis is not active (State "Standstill disable").
- ◆ After MC\_Power, the axis is in closed loop operation.

## 5.5.2. Procedure when working with the C3\_getSystemFingerPrint

Example of a valve characteristic line (volume current via control signal):



### Procedure:

- ◆ Specification of the travel range available for the measurement with min\_Position and max\_Position.
- ◆ Setting max\_Velocity (is valid symmetrically for positive and negative values). With max\_Velocity, you make 2 settings at once: the max. velocity during the measurement and the measurement range.

Connection between velocity (max\_Velocity) and the relative volume current:

$$\max\_Velocity = \frac{\text{relative\_volume\_current}[\%] \cdot \text{Valve\_nominal\_volume\_current}}{\text{Cylinder\_surfaceA} \cdot 100\%}$$

(Value\_nominal\_volume\_current Valve-nominal-volume-current;

Cylinder\_surfaceA: Cylinder\_surface-A

max\_Velocity should be set at least so high that the measurement exceeds the non-linearity shown above, as the characteristic line is continued at the same slope outside the measured velocity range.

- ◆ the Number\_of\_Measuring\_Points should be set high enough so that the non-linearity to be emulated can be exactly detected (typically N=100).
- ◆ Start of the measurement by positive edge at the Execute input.
- ◆ The state of the measurement can be monitored via the Status, Done, Error and ErrorID outputs.
- ◆ A positive edge at the Done output shows the successful termination of the identification:
  - ◆ Measurement terminated successfully
  - ◆ The characteristic line was inverted and written into the FLASH memory.
  - ◆ In the conditioning chain responsible for the measured system, the curve ID was already set to the new characteristic line and the characteristic line compensation was activated.

## 5.6 Positioning functions (standard)

### In this chapter you can read about:

Value range for positioning parameters .....	178
Absolute positioning (MC_MoveAbsolute) .....	179
Relative positioning (MC_MoveRelative) .....	184
Additive positioning (MC_MoveAdditive) .....	186
Continuous positioning (MC_MoveVelocity) .....	188
Manual operation (C3_Jog) .....	190
Homing (MC_Home) .....	192
Electronic gearbox (MC_GearIn) .....	195

### 5.6.1. Value range for positioning parameters


Target position:	Min: -4000000 rev	Max: 4000000 rev
Speed for positioning:	Min: 0.00001157 rev/s	Max: 2000 rev/s
Acceleration for positioning	Min: 0.24 rev/s <sup>2</sup>	Max: 100000 rev/s <sup>2</sup>
Acceleration jerk for positioning:	Min: 30 rev/s <sup>3</sup>	Max: 125,000,000 rev/s <sup>3</sup>
Deceleration for positioning:	Min: 0.24 rev/s <sup>2</sup>	Max: 1000000 rev/s <sup>2</sup>
Deceleration jerk for positioning:	Min: 30 rev/s <sup>3</sup>	Max: 125,000,000 rev/s <sup>3</sup>

**The unit "increments" is valid only for position values!**

speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s<sup>2</sup> and revolutions/s<sup>3</sup> (resp. pitch/s, pitch/s<sup>2</sup>, pitch/s<sup>3</sup>).

## 5.6.2. Absolute positioning (MC\_MoveAbsolute)


<b>FB name</b>	<b>MC_MoveAbsolute</b>	
Absolute positioning to a specified position.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Position</b>	REAL	Absolute target position of the movement to be executed (configured unit [Units] ) (positive and negative direction) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Velocity</b>	REAL	Value of the maximum speed (always positive) (not necessarily reached) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> ) [Units/s]
<b>Acceleration</b>	DINT	Value of acceleration (always positive) [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Deceleration</b>	DINT	Value of deceleration (always positive) [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Jerk</b>	DINT	Value of the acceleration <b>jerk</b> (see page 183) [Units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>JerkDecel</b>	DINT	Value of deceleration <b>jerk</b> [Units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Specified setpoint position on the setpoint generator output is reached
<b>CommandAborted</b>	BOOL	Positioning aborted
<b>Error</b>	BOOL	Error while executing module
<p>Note: -</p> <ul style="list-style-type: none"> <li>◆ If a SuperImposed movement is started during an absolute movement, the absolute position is not accessed, but the absolute position plus the position entered in the SuperImposed.</li> <li>◆ The same applies if a SuperImposed movement is already being executed and an absolute movement is started, then the absolute position is not accessed but the sum of both values.</li> <li>◆ After the SuperImposed movement has been finished, the absolute position is accessed with the next absolute movement.</li> <li>◆ Continuous operation can be selected via object 1111.8 "C3Plus.Position_restposition_mode" &lt;&gt; 0; setpoint value and actual value are then set to 0 before each positioning.</li> <li>◆ You can optimize the motion profile data with the <b>"ProfilViewer"</b> (see page 150) software tool!</li> </ul>		





The following illustration shows two examples of the combination of two MC\_MoveAbsolute modules.

- ◆ The left part (a) of the time diagram shows a case in which the second function module (FB) is executed after the first function module..  
When the first function module has reached Position 60, the "Done" output gives the execution command to the second function module, which then moves to Position 100.
- ◆ The right part (b) of the diagram shows a case in which the second function module is activated while the first function module is being executed. The first function module is automatically interrupted..  
The second function module moves directly to position 100 whether or not position 60 of the first function module has already been reached.



### 5.6.2.1 Position mode in reset operation

#### In this chapter you can read about:

Setting the positioning mode in reset mode.....	182
Examples in the help file.....	182

In reset operation (activated by the configured reset distance), additional positioning functions are possible for absolute positionings:

All directions	Standard positioning mode
Positive direction	Positioning only in positive direction
Shortest path	Positioning on the shortest path
Negative direction	Positioning only in negative direction
Actual direction	Positioning by keeping the actual direction of travel

#### **Dynamic positioning**

In dynamic positioning, a decision concerning the positioning travel is not taken on the basis of the actual position, but on the basis of the braking position resulting from the motion parameters.

#### **Please observe:**

- ◆ In the event of positioning specifications below zero and higher than or equal to the reset distance, this function is deactivated.
- ◆ The positioning functions are neither effective in test movements nor in a positioning after homing travel.
- ◆ In the event of "shortest path" the motion is not defined for a positioning by half the reset distance.

#### **Setting the positioning mode in reset mode**

The positioning modes in reset operation are configured via object 1111.13 [=C3Plus.POSITION\_direction:=MC\_Direction\_Positive]:

Mode	Value	IEC constant
All directions	0	C3_all_direction
Positive direction	1	MC_positive_direction
Shortest path	2	MC_shortest_way
Negative direction	3	MC_negative_direction
Actual direction	4	MC_current_direction

Setting the desired value must take place in the IEC initialization routine, as a configuration download by the C3 ServoManager would reset the value to 0 (due to downwards compatibility).

#### **Examples in the help file**

In the help file you can find here examples for the functioning of the individual positioning modes.

### 5.6.2.2 Description of jerk

#### Jerk

The jerk (marked with "4" in the drawing below) describes the change in acceleration (derivation of the acceleration)

The maximum change in acceleration is limited via the jerk limitation. A motion process generally starts from a standstill, accelerates constantly at the specified acceleration to then move at the selected speed to the target position. The drive is brought to a stop before the target position with the delay that has been set in such a manner as to come to a complete stop at the target position. To reach the set acceleration and deceleration, the drive must change the acceleration (from 0 to the set value or from the set value to 0).


This change in speed is limited by the maximum jerk.

Without jerk  
according to  
VDI2143

According to VDI2143 the jerk is defined (other than here) as the jump in acceleration (infinite value of the jerk function).

This means that positionings with Compax3 are without jerk according to VDI2143, as the value of the jerk function is limited.

#### Motion sequence




- 1: Position
- 2: Velocity
- 3: Acceleration
- 4: Jerk

High changes in acceleration (high jerks) often have negative effects on the mechanical systems involved. There is a danger that mechanical resonance points will be excited or that impacts will be caused by existing mechanical slack points. You can reduce these problems to a minimum by specifying the maximum jerk.


### 5.6.3. Relative positioning (MC\_MoveRelative)

<b>FB name</b>	<b>MC_MoveRelative</b>	
Relative positioning by a specified distance.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Distance</b>	REAL	Relative distance of the movement to be executed (configured unit [Units] ) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>MoveVelocity</b>	REAL	Value of maximum speed (always positive) (not necessarily reached) [Units/s] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Acceleration</b>	DINT	Value of acceleration (always positive) [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Deceleration</b>	DINT	Value of deceleration (always positive) [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Jerk</b>	DINT	Value of the acceleration <b>jerk</b> (see page 183) [Units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>JerkDecel</b>	DINT	Value of deceleration <b>jerk</b> [Units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Specified setpoint distance on the setpoint generator output is reached
<b>CommandAborted</b>	BOOL	Positioning aborted
<b>Error</b>	BOOL	Error while executing module
<p>Note:</p> <ul style="list-style-type: none"> <li>◆ In the case of dynamic positioning (module is called during a positioning process) the specified position is added to the current actual position.</li> <li>◆ Continuous operation can be selected via object 1111.8 "C3Plus.Position_restposition_mode" &lt;&gt; 0; setpoint value and actual value are then set to 0 before each positioning.</li> <li>◆ You can optimize the motion profile data with the <b>"ProfilViewer"</b> (see page 150) software tool!</li> </ul>		




The following illustration shows two examples of the combination of two MC\_MoveRelative modules.

- ◆ The left part (a) of the time diagram shows a case in which the second function module is executed after the first function module..  
If the first function module has reached 60 units, the "Done" output gives the execution command to the second function module, which then moves an addition 40 units.
- ◆ The right part (b) of the diagram shows a case in which the second function module is activated while the first function module is being executed. Because the second module is started during the execution of the first function module, the first function module is automatically interrupted.  
The second function module immediately moves an additional 40 units whether or not the 60 units of the first function were already reached.




**5.6.4. Additive positioning (MC\_MoveAdditive)**

<b>FB name</b>	<b>MC_MoveAdditive</b>	
Adds a relative distance to the target position of a positioning process in progress.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Distance</b>	REAL	Relative distance <Value range> (see page Fehler! Textmarke nicht definiert.)
<b>MoveVelocity</b>	REAL	Value of maximum speed (always positive) (not necessarily reached) [Units/s] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Acceleration</b>	DINT	Value of acceleration (always positive) [Units/s <sup>2</sup> ] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Deceleration</b>	DINT	Value of deceleration (always positive) [Units/s <sup>2</sup> ] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Jerk</b>	DINT	Value of the acceleration jerk (see page 183) [Units/s <sup>3</sup> ] (always positive) <value range> (see page Fehler! Textmarke nicht definiert.)
<b>JerkDecel</b>	DINT	Value of deceleration jerk [Units/s <sup>3</sup> ] (always positive) <value range> (see page Fehler! Textmarke nicht definiert.)
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Specified distance has been reached
<b>CommandAborted</b>	BOOL	Positioning aborted
<b>Error</b>	BOOL	Error during positioning
<p>Note:</p> <p>In the case of dynamic positioning (module is called during a positioning process) the specified position is added to the current target position.</p>		




The following illustration shows two examples of the combination of a MC\_MoveAbsolute and an MC\_MoveAdditive module.

- ◆ The left part (a) of the time diagram shows a case in which the second function module is executed after the first function module. After the first function module has traveled to Position 60, the "Done" output gives the execution command to the second FB, which then moves on another 40 units
- ◆ The right part (b) of the diagram shows a case in which the second function module is activated while the first FB is being executed. Because the second module is started during the execution of the first FB, the first FB is automatically interrupted. The second function module adds the missing units that are still lacking for the first module and the moves an additional 40 units with the new predefined settings.



**5.6.5. Continuous positioning (MC\_MoveVelocity)**

<b>FB name</b>		<b>MC_MoveVelocity</b>
Continuous controlled positioning with adjustable speed		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>MoveVelocity</b>	REAL	Value of maximum speed (always positive) (not necessarily reached) [Units/s] Value range: 0 rev/s ... 2000 rev/s
<b>Acceleration</b>	DINT	Value of the acceleration and deceleration (always positive) [Units/s <sup>2</sup> ] Value range: 0.24 rev/s <sup>2</sup> ... 1000000 rev/s <sup>2</sup>
<b>Direction</b>	INT	Selection: positive direction, negative direction, current direction; <b>library constants</b> (see page 161)
<b>VAR_OUTPUT</b>		
<b>InVelocity</b>	BOOL	Specified target speed on the setpoint output is reached
<b>CommandAborted</b>	BOOL	Execution interrupted
<b>Error</b>	BOOL	Error during positioning
<b>Note:</b>		
<ul style="list-style-type: none"> <li>◆ To be able to stop the drive, the function module must be interrupted by another positioning function module or positioning must be stopped by calling the MC_Stop function module.</li> <li>◆ A positioning to the end limit follows.</li> </ul>		






**Example**


The following illustration shows two examples of the combination of two MC\_MoveVelocity modules.

- ◆ The left part (a) of the time diagram shows a case in which the second function module is executed after the first function module. After the first function module has accelerated to a speed of 3000, the "InVelocity" output, AND-linked with the "Next" signal gives the execution command to the second FB, which then slows to a speed of 2000.
- ◆ The right part (b) of the diagram shows a case in which the second FB is activated while the first function module is being executed. Because the second module is started during the execution of the first FB, the first FB is automatically interrupted. During the acceleration of the first module, the second module slows again similarly to a speed of 2000 without the speed of the first module having been reached.




**5.6.6. Manual operation (C3\_Jog)**

<b>FB name</b>	<b>C3_Jog</b>	
Traveling along the axis in manual mode (in the "standstill" state)		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>JogForward</b>	BOOL	JogForward = TRUE makes the axis move in positive direction.
<b>JogBackward</b>	BOOL	JogBackward = TRUE makes the axis move in negative direction. <b>&lt;Value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Velocity</b>	REAL	Speed value [Units/s] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Acceleration</b>	DINT	Value of the acceleration [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Deceleration</b>	DINT	Value of deceleration during stop[Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Jerk</b>	DINT	Value of the acceleration and deceleration <b>jerk</b> (see page 183) [Units/s <sup>3</sup> ] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>VAR_OUTPUT</b>		
<b>Busy</b>	BOOL	Module is active (manual operation in progress)
<b>Error</b>	BOOL	Error during manual operation or faulty parameter when starting manual operation
<b>Note:</b>		
<ul style="list-style-type: none"> <li>◆ The axis must be in the "standstill" state in order to start manual operation (Jogging Mode).</li> <li>◆ Start: When starting manual operation, the output "Busy" is set to TRUE.</li> <li>◆ Stop: The axis is brought to a standstill if the respective input (JogForward or JogBackward) is set to FALSE again</li> <li>◆ As soon as manual operation is stopped, the output "Busy" is set to FALSE. Further commands can only be executed after this feedback.</li> </ul>		




Example: Manual movement via digital inputs.



### 5.6.7. Homing (MC\_Home)

<b>FB name</b>	<b>MC_Home</b>	
Predefined search for the machine reference point		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Position</b>	REAL	Position on the machine zero point (configured unit [units] ) = Machine zero Offset
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Referencing process completed
<b>CommandAborted</b>	BOOL	Referencing process aborted
<b>Error</b>	BOOL	Error while searching for machine reference point
<p><b>Note:</b></p> <p>This module gives the command to search for the machine reference point; not for "zero" position. The type of search function (machine reference mode) can be adjusted with the configuration or with the object "HOMING_mode" (Object 1130.4).</p> <p>Objects that are connected with the machine reference point:</p> <ul style="list-style-type: none"> <li>◆ C3Plus.HOMING_speed (Object 1130.3)</li> <li>◆ C3Plus.HOMING_accel (Object 1130.1)</li> <li>C3Plus.HOMING_mode (Object 1130.4)</li> <li>◆ C3Plus.HOMING_edge_sensor_distance (Object 1130.7)</li> </ul>		



The Compax3 machine zero modes are adapted to the CANopen profile for Motion Control CiADS402.

### Position reference point

Essentially, you can select between operation with or without machine reference. The reference point for positioning is determined by using the machine reference and the machine reference offset.

#### Machine reference run

In a homing run the drive normally moves to the position value 0 immediately after finding the home switch. The position value 0 is defined via the homing offset.


A machine reference run is required each time after turning on the system for operation with machine reference.



**Please note:**

**During homing run the software end limits are not monitored.**

#### Machine reference offset



1: machine zero point

The machine reference offset is used to determine the actual reference point for positioning.

The rule for this is: Machine zero point = - Machine zero Offset

**A change in the machine reference offset does not take effect until the next machine reference run.**

**Please note:**

**In controlled operation (open loop) no machine zero run is possible!**

**The home of the auxiliary axis is automatically set, by coupling the auxiliary axis to the main axis for the homing run!**

**Homing run for 2 axes**

- ◆ Axis 2 is coupled to axis 1 and moves along
- ◆ Axis 1 and axis 2 set the home at the same time after axis 1 has detected the homing switch

Therefore you should bring the auxiliary axis to a defined start position before the homing run.

**Or use absolute feedback systems:**


**Absolute feedback system**

**For positioning operation of two axes with a Compax3F, we recommend an absolute feedback system**


Thus the homing run after switching on, which is only possible in coupled state for 2 axes and may lead to difficulties with definedly referencing the auxiliary axis is not necessary.

### 5.6.8. Electronic gearbox (MC\_GearIn)

<b>FB name</b>		<b>MC_GearIn</b>
Controlled speed and position synchronicity with adjustable transmission ratio		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Constant for the <b>master signal source</b> (see page 161) <b>Configuration</b> (see page 82) of the signal sources Please note: The auxiliary axis can only be coupled to the position setpoint value of the main axis => if Slave = auxiliary axis, the main axis must be the Master. The reduction ratio is then fixed to 1:1.
<b>Slave</b>	INT	
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>RatioNumerator</b>	REAL	Reduction ratio numerator Field is only valid, if Slave=AXIS_REF_LocalAxis (main axis).
<b>RatioDenominator</b>	INT	Reduction ratio denominator Field is only valid, if Slave=AXIS_REF_LocalAxis (main axis).
<b>Acceleration</b>	DINT	Value of acceleration / deceleration (always positive) until the synchronism is reached [Units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
<b>VAR_OUTPUT</b>		
<b>InGear</b>	BOOL	Synchronicity achieved
<b>CommandAborted</b>	BOOL	Command aborted
<b>Error</b>	BOOL	Error while executing module
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ Behaviour: the drive accelerates (with Acceleration) until the master speed is reached - the module will report synchronicity with "InGear". Position losses during acceleration to master speed are not made up.</li> <li>◆ The transmission ratio can be changed at any time with a positive edge on Execute. InGear is reset until synchronicity is achieved again.</li> <li>◆ For example, if speed synchronicity is not achieved because of limiting effects, the position difference that arises will be made up (by the active position controller).</li> <li>◆ Acceleration / deceleration to the set transmission ratio takes place without a jerk limit.</li> <li>◆ If the master and slave units do not correspond, this fact must be considered for the transmission ratio.</li> <li>◆ <b>Example</b> (see page 83)</li> </ul>		



**Structure of the "electronic cam" function**




**Gearing structure**

D: / E: **additional structure** (see page 102)

- Note:**
- ◆ Direction -1 / +1: with direction reversal (under configuration of signal sources) factor -1 is applied.
  - ◆ The "virtual master" source is not available with Compax3 T30.



Example:



## 5.7 Superimposed motion

### In this chapter you can read about:

Dynamic positioning .....	198
Superimposed positioning (MC_MoveSuperImposed) .....	199
Zero point shift caused by superimposed positioning (C3_ShiftPosition) .....	201

### 5.7.1. Dynamic positioning

Dynamic positioning processes can be performed with the modules MC\_MoveAbsolute, MC\_MoveRelative and MC\_MoveAdditive. The speed can be altered dynamically with MC\_MoveVelocity.

#### **In the state: "Discrete Motion"**

If another, second positioning process is activated in the "Discrete Motion" state, the 1st positioning process will be interrupted. The transition to the new destination occurs dynamically, i.e. without any intervening stop.

#### **In "Continuous Motion" state**

If a positioning process (MC\_MoveAbsolute, MC\_MoveRelative or MC\_MoveAdditive) or a MC\_MoveVelocity is activated in the "Continuous Motion" state, the active function module will then be interrupted. All input variables of the new positioning process will then be taken over.

#### **Superimposed positioning**

Please note also the difference to **superimposed positioning** (see page 199) with MC\_MoveSuperImposed.

Here, the movement of the active function module is executed until the end.

Autoryzowany dystrybutor Parker:

# ARA

PNEUMATIK



53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)





## 5.7.2. Superimposed positioning (MC\_MoveSuperImposed)

FB name	MC_MoveSuperImposed	
Superimposing of an active positioning with an additional relative distance. The positioning process that is currently underway is not interrupted by MC_MoveSuperImposed; it is superimposed instead		
<b>VAR_IN_OUT</b>		
Axis	INT	Axis ID; constant: AXIS_REF_LocalAxis
<b>VAR_INPUT</b>		
Execute	BOOL	Starts the sequences of the module with positive edge
Distance	REAL	Additional distance for superimposed positioning (configured unit [Units] ) (positive and negative direction) <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
MoveVelocity	REAL	Value of the maximum speed difference compared to the speed of the current positioning (always positive) (not necessarily reached) [units/s] <b>&lt;Value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
Acceleration	DINT	Value of acceleration (always positive) [units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
Deceleration	DINT	The value of deceleration (always positive) [units/s <sup>2</sup> ] <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
Jerk	DINT	Value of the acceleration <b>jerk</b> (see page 183) [Units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
JerkDecel	DINT	Value of the deceleration jerk [units/s <sup>3</sup> ] (always positive) <b>&lt;value range&gt;</b> (see page Fehler! Textmarke nicht definiert.)
<b>VAR_OUTPUT</b>		
Done	BOOL	Additional distance was added to the current positioning
Busy	BOOL	Superimposed motion is performed
CommandAborted	BOOL	Positioning aborted
Error	BOOL	Error while executing module
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ The values Distance, Velocity, Acceleration, Deceleration, Jerk JerkDecel are no absolute values, they are added to the current movement.</li> <li>◆ A stop of the axis will interrupt the current as well as the superimposed movement.</li> <li>◆ In the PLCopen state "Standstill" the MC_MoveSuperImposed module acts like the MC_MoveRelative module.</li> <li>◆ MC_MoveSuperImposed does not interrupt an active command.</li> <li>◆ "Position reached" (Object 420.6) is not influenced by the additional movement triggered by MC_MoveSuperImposed.</li> <li>◆ This module cannot be operated with C3_ShiftPosition and MC_Phasing at a time.</li> <li>◆ The position of the module in the <b>structure image</b> (see page 412).</li> </ul>		




### 5.7.3. Zero point shift caused by superimposed positioning (C3\_ShiftPosition)

FB name	C3_ShiftPosition	
Shifting the reference point, i.e. the zero point of the system is shifted by the stated relative distance. The drive performs a physical movement which is, however, not displayed. The positioning being executed at that time is not interrupted by C3_ShiftPosition. Application: Slave reg synchronization.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis ID; constant: AXIS_REF_LocalAxis
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>Distance</b>	REAL	Distance of the offset (configured unit [units] ) (positive and negative direction) <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Velocity</b>	REAL	Value of the maximum speed difference (always positive) (not necessarily reached) [Units/s] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Acceleration</b>	DINT	Value of acceleration (always positive) [units/s <sup>2</sup> ] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Deceleration</b>	DINT	The value of deceleration (always positive) [units/s <sup>2</sup> ] <value range> (see page Fehler! Textmarke nicht definiert.)
<b>Jerk</b>	DINT	Value of the acceleration jerk (see page 183) [Units/s <sup>3</sup> ] (always positive) <value range> (see page Fehler! Textmarke nicht definiert.)
<b>JerkDecel</b>	DINT	Value of the deceleration jerk [units/s <sup>3</sup> ] (always positive) <value range> (see page Fehler! Textmarke nicht definiert.)
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Relative distance was reached
<b>Busy</b>	BOOL	Shift is being executed
<b>CommandAborted</b>	BOOL	Positioning aborted
<b>Error</b>	BOOL	Error while executing module
<b>Note:</b> <ul style="list-style-type: none"> <li>◆ The values Distance, Velocity, Acceleration, Deceleration, Jerk JerkDecel are no absolute values, they are added to the current movement.</li> <li>◆ In the PLCopen "Standstill" state, the axis performs a relative movement, during which the axis moves, but the displayed position is not changed.</li> <li>◆ In the PLCopen "Discrete Motion" state, the speed and the position of the active movement are superimposed, but the displayed speed and position are not changed.</li> <li>◆ In the case of a stop command on the axis, the current movement is interrupted as well as the shift.</li> <li>◆ C3_ShiftPosition does not interrupt any active command.</li> <li>◆ This module cannot be operated with MC_MoveSuperImposed and MC_Phasing at a time.</li> <li>◆ The position of the module in the <b>structure image</b> (see page 412).</li> </ul>		



## 5.8 Adjust force / pressure (C3\_PressureForceAbsolute)

<b>FB name</b>		<b>C3_PressureForceAbsolute</b>
Control absolute force or differential pressure (depending on the physical system selected in the <b>configuration</b> (see page 46).		
$\frac{F_A - F_B}{A_A} = p_A - \frac{A_B}{A_A} \cdot p_B = p_A - \alpha \cdot p_B$		
Differential pressure:		
Force: $F = F_A - F_B$		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis ID (Library constants) AXIS_REF_LocalAxis: Main axis AXIS_REF_LocalAxisAux: Auxiliary axis
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>PressureForce</b>	DINT	Setpoint differential pressure [mbar, psi] or setpoint force [N].
<b>Gradient</b>	DINT	Change speed for pressure or force in [bar/s, psi/s], [N/s].
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Specified setpoint value on the setpoint output is reached
<b>CommandAborted</b>	BOOL	Command aborted
<b>Error</b>	BOOL	Error while executing module
<b>Note:</b>		
<ul style="list-style-type: none"> <li>◆ the axis must be in controlled operation, so that the module becomes active.</li> <li>◆ After termination of the module, the axis continues to control the differential pressure or the force.</li> <li>◆ Executing a MC_Stop module causes the transition to position control. The current speed of the axis is controlled down to zero and the position reached then is kept with the aid of the position controller.</li> <li>◆ The execution of the C3_PressureForceStop is required, if no position control is configured. It causes the gradient to be reduced to zero and the axis to remain force or pressure controlled.</li> </ul>		



## 5.9 Dynamic switching: Position- on force/pressure - adjustment

### In this chapter you can read about:

Switching: from force to position mode (C3\_pQ).....205

Compax3F supports the so-called pQ operating mode. This function permits condition-dependent switching between position control (pQ mode) and force (for example differential pressure) control and back.

This function can only be executed in connection with the main axis.

The following boundary conditions are to be taken into consideration:


- ◆ The output control operation for the PQ function is always a position control (state "Discrete Motion" or "Standstill: powered").  
The defined switching condition is therefore valid for the switching from the position control to force/pressure control.
- ◆ The condition for the switching from force control back to position control is (current speed  $\geq$  calculated setpoint speed).  
If the countercheck is lost (actual speed  $>$  setpoint speed), the drive will return into position control into the motion profile programmed before.
- ◆ The configuration and activation of the pQ operating mode is made via an IEC module.
- ◆ After the activation of the C3\_pQ module, the C3\_PressureForceAbsolute module can no longer be activated.
- ◆ The setpoint value for the force/pressure controller is read from an object, which is indicated via a pointer.
- ◆ The deactivation of the module and consequently of the pQ operating mode can be initiated with the negative edge at the enable input.  
The deactivation itself is only possible in the "Standstill Powered" state.  
If the pQ operating mode is deactivated during a positioning sequence, the started positioning is finished in pQ mode.  
If the drive is in force control at the time of deactivation, a MC\_Stop is necessary in order to switch back to position control.



### 5.9.1. Switching: from force to position mode (C3\_pQ)

<b>FB name</b>	<b>C3_pQ</b>	
Activate pQ (Volume flow control / position control) – Mode depending on the conditions		
<ul style="list-style-type: none"> <li>◆ Switching to pressure / force control: see in this module description</li> <li>◆ Switching back to position control: <ul style="list-style-type: none"> <li>◆ Actual speed &gt; setpoint speed from the motion profile or</li> <li>◆ Target position from the original positioning reached.</li> </ul> </li> </ul>		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis ID (Library constants) Note: C3_pQ_Force is only possible for the main axis
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Starts the sequence of the module at positive edge and terminates the qQ mode at negative edge
<b>Mode</b>	C3_pQ_MODE	Switching conditions from position to pressure/force control: <b>EVENT_EXTERN</b> External event: Any object (given by "ExtObjectSource") can be configured as source (Index.Sub). via an additional mask (ExtObjMask), an AND-link is established. <b>ABS_FORCE_PRESSURE_THRESHOLD</b> Controller-Actual-Pressure/Force > Value "PressureForceThreshold" <b>ABS_FORCE_PRESSURE_GRADIENT</b> Pressure/Force-Gradient > Value "PressureForceGradientThreshold". The gradient exceeds the parameterized value. <b>ABS_ACTUALPOS_THRESHOLD</b> Value of the actual position > parameterized position value "PosThreshold" AND Value of the actual position < parameterized position value "PosThreshold" + PosWindow <b>ABS_DEMANDPOS_THRESHOLD</b> Value of the setpoint position > parameterized position value "PosThreshold" AND Value of the setpoint position < parameterized position value "PosThreshold" + PosWindow
<b>PressureForceSetpointSource</b>	DWORD	Pointer to the source of the setpoint value of the pressure/force controller Note: The source must have the type INT or DINT
<b>PressureForceThreshold</b>	DINT	The pressure/force threshold in [mbar], [psi] or [N] at which the switching to pressure/force control takes place. Note: This parameter is only relevant in the Mode=ABS_FORCE_PRESSURE_THRESHOLD.
<b>PressureForceGradientThreshold</b>	DINT	The pressure/force change threshold in [mbar], [psi] or [N] at which the switching to pressure/force control takes place. Note: This parameter is only relevant in the Mode=ABS_FORCE_PRESSURE_GRADIENT.
<b>GradientFilterTimeConstant</b>	INT	The filter time constant in [µs] of the filter at which the pressure/force gradient is filtered.
<b>ExtObjectSource</b>	DWORD	Pointer to any object that is intended to be the source of the external event. Note: This parameter is only relevant in the Mode=EVENT_EXTERN.

<b>ExtObjMask</b>	WORD	Bit mask for the relevant bits in "ExtObjectSource". The contents of the ExtObjectSource is AND-linked with the aid of this bit mask. Note: This parameter is only relevant in the Mode=EVENT_EXTERN.
<b>PosThreshold</b>	REAL	Position threshold for switching to pressure/force controller
<b>PosWindows</b>	REAL	Position window in Units, measured from the position threshold (PosThreshold). In this window, the monitoring of the switching condition to force/pressure control is active. If the position exceeds the value: PosThreshold + PosWindows, then the monitoring of the switching condition to force/pressure control is not active. The window should be defined as small as possible. Within this window, the actual speed caused by the pressure/force control must be below the setpoint speed, unless the axis will switch back to position control.
<b>VAR_OUTPUT</b>		
<b>IsActive</b>	BOOL	TRUE: pQ Mode aktive FALSE: pQ Mode not active
<b>F_IsActive</b>	BOOL	Shows that the pressure/force control is activated. Note: Is only updated if the Enable input provides TRUE
<b>Q_IsActive</b>	BOOL	Shows, that the volume flow control (pQ: Position control) is activated. Note: Is only updated if the Enable input provides TRUE
<b>Error</b>	BOOL	Error while executing module
<b>ErrorID</b>	INT	Error description 0: No Error 1: Mode EVENT_EXTERN => source "ExtObjectSource" is missing 2: Invalid MODE set 3: No source entered for the pressure/force controller setpoint 4: Activation of the PQ module is not permitted in this mode 5: pQ mode with mere pressure/force control axis is not possible. 6: The axis ID does not correspond the the ID of the main axis
<b>Note:</b>		
◆ The switching conditions are monitored until the target position of the current positioning sequence is reached; this is not valid in the "ABS_ACTUALPOS_THRESHOLD" and "ABS_DEMANDPOS_THRESHOLD" modes.		



## 5.10 Cam Control

### In this chapter you can read about:

Introduction: Electronic cam control .....	208
Overview.....	210
Basics .....	211
Generating cams .....	214
Cam function structure .....	224
Master signal source .....	235
Alignment of the slave axis.....	246
10 Steps for cam generation .....	261
Cam applications .....	264

## 5.10.1. Introduction: Electronic cam control

### In this chapter you can read about:

Function principle .....209

Rising rationalization pressure and an increasing degree of automation in process engineering demand modern and flexible drive concepts.

The introduction of digital and communicating control devices was an important step towards the decentralization of control and regulation tasks. An increasing number of mechanical construction components can be replaced by programmable servo drives.

In particular mechanical cam switching mechanisms and discontinuous shafts maintained until today their fields of application in many areas of machine construction.

Mechanical cam switching mechanisms offer, besides complex motion profiles, a high positioning accuracy and rigid coupling between master and slave drive.

Their drawbacks are, however, the long changeover times and the limitation to a defined profile.


In this respect the Compax3 T40 electronic cam offers considerable time advantages, above all when changing between small batch sizes or with a wide range of products.

The decentralization of the drive performance can reduce size, costs and maintenance effort considerably.

Compax3 allows to implement in an axis module all control and drive functions for a flexible and cost-effective solution of complex motion sequences and synchronization tasks with the aid of powerful IEC61131-3 modules.

The switching command between different motion profiles takes only seconds – no fitter or wrench is required.

Large, mechanically coupled drive systems can be divided into small, independent drives. The dynamic and stationary behavior of every drive can be individually set and optimized.



Compax3 is able to simulate mechanical cams as well as cam switching mechanisms electronically.

This helps to realize discontinuous material supply, flying knife and similar drive applications with distributed drive performance.


The compact servo controller processes the position signals of a master axis and controls a servo motor, torque motor or a direct-drive linear actuator via the desired motion profile, which is defined in the form of an interpolation point memory. The combination of drive, control and power unit in one device offers many advantages:

- ◆ Fast and easy commissioning.
- ◆ fast and stable control.
- ◆ feedforward control measures result in reduced need for peak torque and improved response behavior - therefore following errors are avoided.
- ◆ central digital control from the setpoint generator to the power output stage.
- ◆ lower wiring overhead and thus substantially reduced fault liability.

### 5.10.1.1 Function principle

#### In this chapter you can read about:

Coupling and decoupling .....	209
Mark synchronization .....	210



Depending on the angle setting of a leading axis (master), the following axis (slave) is moved according to a user-defined motion profile. The master position moves within a defined value range; the master clock distance, and moves through it cyclically. Each cycle corresponds to a revolution of the cam or a repetition cycle of any complex movement. Via the master position, a sequence of interpolation points with up to 10000 non-equidistant interpolation points is addressed. Compax3 interpolates linearly between the interpolation points. Those position setpoint values are used to form the feedforward signals for the subordinate controller cascades of the following axis. This feedforward of speed and acceleration is used to reduce the following error of the following axis as far as possible.

### Coupling and decoupling

An important function for complex plants is the coupling and decoupling of individual drives, triggered by an external control signal. During the coupling, the following axis (slave) is synchronized via a defined motion profile to the position of the leading axis (master). This can take place from any start position with a continuous, jump free speed course. Upon decoupling, the slave leaves the synchronous operation and is brought definedly to a standstill. The coupling or decoupling can take place with a running or stationary master axis.

### Mark synchronization

In the packaging and print industry, a synchronization of following slave axes to print marks is required, for example in order to balance material slip or for an alignment according to existing prints. The error is compensated up to the next mark by correcting the master position acquired in the slave or by correcting the slave position by the determined slip between the product and the print mark button.

## 5.10.2. Overview

### T40 Functions: Cam

<b>General</b>	<ul style="list-style-type: none"> <li>◆ Cam control function</li> <li>◆ Programmable based on IEC61131-3</li> <li>◆ Position of selected master signal source via: <ul style="list-style-type: none"> <li>◆ Encoder, Step / direction or +/-10V analog</li> <li>◆ HEDA</li> <li>◆ Virtual Master</li> </ul> </li> </ul>
<b>Cam memory</b>	<ul style="list-style-type: none"> <li>◆ 10.000 interpolation points (master / slave in 24 bit format) saved failure save.</li> <li>◆ Distance of interpolation points can be adapted to curve (non equidistant interpolation points)</li> <li>◆ Linear interpolation between points</li> </ul>
<b>Linking curve segments</b>	<ul style="list-style-type: none"> <li>◆ Up to 20 cam segments can be produced.</li> <li>◆ Virtually random cam links (forwards and backwards)</li> <li>◆ Freely programmable, event-triggered curve branching.</li> <li>◆ Scalable cam segments and complete cam profiles</li> </ul>
<b>Coupling and decoupling functions</b>	<ul style="list-style-type: none"> <li>◆ With the aid of a quadratic function.</li> <li>◆ By means of a change-over function</li> <li>◆ Without overspeeding by coupling over several master cycles.</li> <li>◆ Virtually free set-up of the coupling and decoupling movement</li> <li>◆ master-guided coupling movement.</li> <li>◆ Random standstill position</li> </ul>
<b>Mark synchronization</b>	<ul style="list-style-type: none"> <li>◆ Master or slave oriented (simultaneous, cam-independent).</li> <li>◆ highly precise mark recognition (accuracy &lt; 1 µs)</li> </ul>
<b>Cam generation with renowned Nolte tool.</b>	<ul style="list-style-type: none"> <li>◆ Standard or extended range of functions</li> <li>◆ evaluation of the motion profiles.</li> </ul>

### 5.10.3. Basics

**In this chapter you can read about:**


Cam types .....	211
Cam parameters / terms .....	212
Basic procedure.....	213

#### 5.10.3.1 Cam types

There are two principal curve types:

##### Closed curve


The start and end positions of the Slave are identical. I.e. the Slave moves always within the same position range.



ST: Slave clock distance  
 MT: Master clock distance

##### Open curve


The start and the end position of the Slave are not identical. I.e. the Slave moves in one direction, as at the end of the curve the actual position of the Slave is compared to the start position of the curve.



ST: Slave clock distance  
 MT: Master clock distance

### 5.10.3.2 Cam parameters / terms

Example:



- ST: Slave clock distance
- MT: Master clock distance
- ME: Coupling position
- MS: Synchronous position
- MA: Decoupling position
- MB: Braking position
- S0: Standstill position of the Slave

#### Master clock distance (MT)

The Master clock distance is the distance which the master runs, i.e. after which the cycle is repeated. This distance is stated in the physical unit of the Master. After this distance, the curve is repeated.

#### Slave clock distance (ST)

The Slave clock distance is the distance which the Slave runs, stated in the physical unit of the Slave.

#### Coupling position (ME)

Master position, where the coupling sequence starts.

#### Synchronous position (MS)

The coupling sequence is finished, if the master has reached the synchronous position MS, i.e. at the master position MS the slave is synchronous to the curve (MS > MT possible).

#### Decoupling position (MA)

Via the decoupling position MA the decoupling sequence can be started in a defined fashion from a certain master position (MA) on (dependent on the decoupling operating mode selected).



### Braking position (MB)

At this master position, the slave comes to a standstill after decoupling (MB > MT possible).

### Standstill position Slave (S0)


Target position of the slave axis after decoupling.

### Back stop

The back stop can be enabled if required (IEC module **C3\_MasterControl** (see page 237)).

It ensures that a backwards movement of the master will not incite an axis movement of the slave.

#### Example:



- 1: Master signal after back stop
- 2: Master signal before back stop
- 3: Backwards movement of the master
- 4: Forwards movement of the master corresponding to the backwards movement.

**Note:** The negative distance difference caused by the backwards movement of the master (3) must be traveled in positive direction (4), before it can be effective as a movement.

### 5.10.3.3 Basic procedure

When implementing a standard cam application, the following steps are necessary:

- ◆ Create curve and load into Compax3.
- ◆ Setting the master position detection
- ◆ Establish relationship between master position read in and curve.
- ◆ Select curve.
- ◆ Start curve operation in a defined fashion.
- ◆ Establish relationship with slave position (coupling).
- ◆ Finish curve operation in a defined fashion (decoupling).

## 5.10.4. Generating cams

### In this chapter you can read about:

Introduction to the CamDesigner (example).....	215
Cam functions of the Compax3 ServoManager / motion laws .....	220

The curve creation software "C3 CamDesigner" is a separate program and must therefore be installed separately.

You will find the program on the Compax3 CD.

Please note:

The CamDesigner must be installed in a folder, whose name does not contain any blanks.

This problem occurs above all when working with english Windows versions (...\\Program Files\\...).

### 5.10.4.1 Introduction to the CamDesigner (example)

**Prerequisite:**

Compax3 is configured

Compax3 ServoManager is installed (can be found on the Compax3 CD).

C3 CamDesigner is installed (can be found on the Compax3 CD).

**Settings:**

◆ Travel distance per motor revolution = 360°

◆ Reset distance = 360°

In the "Configuration" wizard in the "reference system" window

◆ Travel path per revolution of the physical source: Numerator = 360, Denominator = 1

in the "signal sources" wizard windows: "Physical source"

◆ Signal source: Encoder A/B; 5V

**Procedure:**

Starting the CamDesigner: Navigation tree of the Compax3 ServoManager under "cam": "Modify cam with CamDesigner"

The transfer window from Compax3 ServoManager to CamDesigner will open:

**CamDesigner**
✕



**Parker**

Parameter axis 1

Axis name

Master axis

Reset distance

Numerator

Denominator

Alternative master reset distance [M\_Units]

Signal source

Max. speed [M\_Units/s]

Cam Parameter

ADVANCED Level

Point reduction

Interpolation tolerance

Number of points per curve

Dwell-to-dwell motion law

Always calculate motion diagrams

Modular grid for graphic cam input

Step angle

Travel coordinate

Click to Start CamDesigner

Cancel

Here you can enter:


- ◆ Axis name
  - ◆ Number of interpolation points to be calculated per curve,
  - ◆ Signal source "Encoder A/B 5V" and
  - ◆ "Dwell-to-dwell motion law".
- Do not change the default settings:
- ◆ 180 points and
  - ◆ the "modified sine line according to Neklutin" (russian mathematician)

At first the display is empty; the motion sequence can be entered.

This is made via the menu: File: New sequence.




In the dialog box you can select the the axis name of your choice, here "axis"

The display looks as follows:



**Now the curve can be created:**

The BASIC version of the CamDesigner offers three tools:


- ◆ Drawing -> Dwell 
- ◆ Drawing -> straight 
- ◆ Drawing -> point 


With the aid of these tools the known sections of a motion sequence, in general dwells or sections with constant speed, are entered. Please select a tool.


Now you can position the respective section per mouse click or enter it with the keyboard. Click into the "enter" field. In the dialog box you can make the following entries depending on the tool selected:

- ◆ Tool dwell:
  - ◆ a. Path coordinate 0 Degrees
  - ◆ b. Clock angle beginning 0 Degrees
  - ◆ c. Clock angle end 30 Degrees
- ◆ Tool dwell:
  - ◆ a. Path coordinate 150 Degrees
  - ◆ b. Clock angle beginning 110 Degrees
  - ◆ c. Clock angle end 120 Degrees
- ◆ Tool straight line:
  - ◆ a. Path coordinate beginning 110 Degrees
  - ◆ b. Clock angle beginning 190 Degrees
  - ◆ c. Path coordinate end 30 Degrees
  - ◆ d. Clock angle end 270 Degrees
- ◆ Tool interpolation point:
  - ◆ a. Path coordinate 0 Degrees
  - ◆ b. Clock angle 3600 Degrees
- ◆ and as an option
  - ◆ c. speed 0 rad/s
  - ◆ d. Acceleration 0 rad/s<sup>2</sup>

The display looks as follows



The dashed sections are now calculated by the CamDesigner.  
 The transitions from dwell to motion are always calculated via a polynomial 5th order (in the BASIC version).  
 For the transitions dwell-to-dwell, the preselected motion law is used. This can also be changed retrospectively in the header data (menu: edit: Header data). The header data mask also states the cycle time (cycles per minute).  
 The result is displayed  via the "show motion diagram" icon:



Displayed are the sequences for position, speed and acceleration, in physical units and with respect to the cycle time entered.

This window can be left via the X Icon.

If necessary, you can make modifications (motion laws, cycle time, etc.)

After the optimization of the curve progression you can leave the CamDesigner via "file": "Exit"

The following dialog queries if the Cam Download is to take place immediately. The download can also be executed later via "Download": "Cam - curve data".

**5.10.4.2 Cam functions of the Compax3 ServoManager / motion laws**

In this chapter you can read about:

Description of the cam wizard..... 221  
 Motion laws:..... 223



## Description of the cam wizard

The screenshot shows the 'CamDesigner' window with the following elements and callouts:

- 1**: Axis name field (value: Axis)
- 2**: Reset distance field
- 3**: Alternative master reset distance [M\_Units] field (value: 360)
- 4**: Signal source dropdown menu (value: Encoder A/B 5V)
- 5**: Max. speed [M\_Units/s] field (value: 1200.000)
- 6**: ADVANCED Level checkbox
- 7**: Point reduction checkbox
- 8**: Interpolation tolerance field (value: 0.0001)
- 9**: Number of points per curve field (value: 180)
- 10**: Dwell-to-dwell motion law dropdown menu (value: Modified Sine Line according to Neklutin)
- 11**: Always calculate motion diagrams checkbox
- 12**: Step angle field (value: 10)
- 13**: Travel coordinate field (value: 1)
- 14**: Click to Start CamDesigner button
- 15**: Cancel button

- 1 Name of the cam project being used in the CamDesigner.
- 2 Reset distance (=clock distance) of the master = length of the X axis in the CamDesigner.  
The entry fields are inactive, if motion sequences were already created in the CamDesigner.  
The values can, however, be modified in the header data of the CamDesigner.  
ATTENTION:  
Cam interpolation points may need to be adapted or deleted, if they are redundant due to a smaller clock distance!.  
Decimal numbers must be converted into integers as numerator and denominator values. Please note, that max. 3 decimal places are considered for numerator/denominator. (see on page 3)
- 3 If the master clock distance has more than 3 decimal places, a drift is created.  
If the Compax3 ServoManager states this, you can avoid this drift by using an alternative master clock distance.  
Use another unit for the alternative master clock distance, instead of [mm] or [degrees] rather use [product cycles] or [%], so that you have an integer.  
This unit is then valid for all master-related values (ME, MS, status values, ...) as well as for the curve.

Create the curve for this alternative master clock distance and you will get a drift free curve operation.

the input field will become inactive, if motion sequences were already created in the CamDesigner. The alternative clock distance can also be manipulated in the header data mask of the CamDesigner.

**Example:**

**Master:** Direct-driven indexing table with 7 work stations;

Path/revolution = 360°

Reset distance = 360°

**Slave:** One of the work stations

Path/revolution = 360/7° master degree; cannot be displayed as clock resp. master reset distance (drift)!

Better: alternative clock distance e.g. 360 slave degrees.

- 4 Selection of the signal source which is used as default value for the master source (Input AXIS\_REF\_Local\_Cam on the IEC block C3\_MasterControl). An entry is required.  
You can choose between configured signal sources.  
The source can be changed afterwards with the input master of the IEC block C3\_MasterControl.
- 5 The maximum speed is used as axis dimensioning for the display of the motion profile as well as a limit value for the motion sequence..  
At +/-10V as signal source, the value 10V is used (the entry field is deactivated).  
This value can also be manipulated in the header data mask of the CamDesigner.  
Please note: The value is converted into steps/min by the CamDesigner; therefore a slight difference in this value caused by rounding is possible after the return from the CamDesigner.
- 6 If the licence file is installed: Switching between Advanced and Basic version of the CamDesigner.
- 7 Interpolation point reduction  
deactivated: The curve is stored in equidistant interpolation points (corresponding to the stated number of interpolation points)  
Activation: The equidistant interpolation points are reduced (resulting in the creation of not equidistant interpolation points).  
The interpolation points are removed so that the resulting error is smaller than the interpolation tolerance stated (linear interpolation is respected).
- 8 Interpolation tolerance (see 7).
- 9 Maximum number of interpolation points per curve. Value range 18..3600.  
Without activated interpolation point reduction, a curve has this number of interpolation points.  
If the reduction is activated, the actual number of interpolation points may (depending on the tolerance selected) be smaller. Please respect that this value also constitutes the "basic grid" for the interpolation point reduction.  
The number of interpolation points can also be manipulated in the header data mask of the CamDesigner.
- 10 Here the dwell-to-dwell interpolation method is selected. The following motion laws are possible in the BasicVersion of the CamDesigner:
  - 3 Sloping Sine Line according to Helling-Bestehorn
  - 4 5th order polynomial
  - 5 Modified acceleration trapezoid
  - 6 Modified Sine Line according to Neklutin
  - 7 Simple sine (disadvantageous jerk)
  - 11 11th order polynomial
  - 12 Squared parabola (disadvantageous jerk)
  - 28 8th order polynomial (disadvantageous jerk)
  - 30 low-noise cosine combination
  - 31 3th order polynomial (disadvantageous jerk)
  - 32 4th order polynomial
  - 33 6th order polynomial (disadvantageous jerk)
  - 34 7th order polynomial
  - 38 mirrored sine

- 47 harmonic combination

For all other interpolations, the 5th order polynomial is used in the basic version. In the "Advanced Version", all methods of interpolation (also in combination) are possible in general. A detailed description of the methods not mentioned here, can be found in the CamDesigner help.

The dwell-to-dwell motion law can also be specified in the header data mask of the CamDesigner.

**11** if the option "always calculate motion diagrams" is activated, the CamDesigner will calculate the interpolated motion sequence and the acceleration sequence after each change.

This option can also be de-/activated in the header data mask of the CamDesigner.

**12** Modular grid for graphic cam input.

These values determine to which master/slave grid the curve elements placed with the aid of the mouse are brought ("caught"). The grid of the master (x)-axis must be smaller than the configured clock distance.

These values can also be de-/activated in the input mask of the CamDesigner for curve points.

**13** Here are displayed status resp. error messages and notes.

**14** Starting the CamDesigner.

This must be installed from the Compax3 CD before.

After the return from the CamDesigner it is necessary to perform a curve data download in order to load the changes into Compax3 (even if the curves themselves were not modified).

**15** Cancel. Closing the window, the changes are discarded.

#### **Motion laws:**


Detailed information on the topic of "motion laws" can be found in the online help of the device.

## 5.10.5. Cam function structure

### In this chapter you can read about:

Function modules of the cam .....	224
Signal image .....	225
Cam reference systems .....	229

### 5.10.5.1 Function modules of the cam



### Functions of the individual modules:

#### Master Position:

- ◆ Detection of the master position
- ◆ Alignment / adjustment of the master position signal  
For this the following IEC modules are available
- ◆ C3\_MasterControl:
  - ◆ Select source
  - ◆ activate detection
  - ◆ activate master back stop (only rising master signals are accepted)
- ◆ C3\_SetMaster: Define start position for the master signal.
- ◆ C3\_MasterConfig: Define master reset distance (independent of the curve reset distance).
- ◆ MC\_Phasing: Additional master distance which is added to the master signal and which causes a slave movement.

#### Cam: Curve generation and control

- ◆ Selection of the curve
- ◆ Settings: run through curve once or cyclically
- ◆ Enable the master signal to the curve
- ◆ Definition of the master reference: relative or absolute.
- ◆ Specification of the master and slave segment distance.
- ◆ Specification of another MasterOffset with absolute reference or a starting delay with relative reference.

This is made via the "C3\_CamTableSelect2 IEC module.

**Setpoint generator: Coupling and decoupling curves**

- ◆ Enable the curve slave position.
- ◆ Alignment / adjustment of the curve slave position to the actual slave position.  
For this the following IEC modules are available
- ◆ MC\_CamIn: Coupling with relative slave reference.
- ◆ C3\_CamIn: Coupling with absolute slave reference with coupling function, master coupling position and master synchronous position
- ◆ C3\_CamOut: Decoupling with absolute slave reference with coupling function, master decoupling position, master braking position and slave standstill position.

**5.10.5.2 Signal image**

Displayed are 2 different signal plans, which differ in their master reference:

- ◆ absolute master reference
- ◆ relative master reference


Displayed are:

- ◆ the master signal processing,
- ◆ the function of the individual IEC function modules as well as
- ◆ the status objects made available for the commissioning or processing.

**Symbols** Please make yourself familiar with the **Symbols of the signal image** (see page 228).

<b>Abbreviations:</b>	<b>RV:</b>	Reset distance of the virtual master (from C3 ServoManager wizard "signal source")
	<b>RM Cam:</b>	Reset distance of the master from curve
	<b>RS:</b>	Reset distance of the slave (from C3 ServoManger Wizard "configuration: Reference system)
	<b>MD:</b>	Feed of the master axis
	<b>SD:</b>	Feed of the slave axis

**Signal image with absolute master reference**



**Cam structure absolute**

D / E: additional structure (see page 102)

**Note:** Direction -1 / +1: with direction reversal (under configuration of signal sources) factor -1 is applied.

**Switches S1 & S2:**


**S1: Enable master acquisition; status switch in object 3030.7**

- O3030.7 = 0: switch open
- O3030.7 = -2: switch closed, stop at the end of the cycle
- O3030.7 = 2: switch closed, stop at the end of the cycle - single operation (run through curve once)
- O3030.7 = 4: switch closed, periodic operation (run through curve cyclically)

**S2: Enable cam input; status switch in object 3030.17**

- O3030.17 = 0: switch open
- O3030.17 = 3: switch closed, single operation (run through curve once)
- O3030.17 = 4: switch closed, periodic operation (run through curve cyclically)

Signal image with relative master reference



Cam structure relative

D / E: additional structure (see page 102)

**Note:** Direction -1 / +1: with direction reversal (under configuration of signal sources) factor -1 is applied.

**Switches S1 & S2:**

**S1: Enable master acquisition; status switch in object 3030.7**

- O3030.7 = 0: switch open
- O3030.7 = -2: switch closed, stop at the end of the cycle
- O3030.7 = 2: switch closed, stop at the end of the cycle - single operation (run through curve once)
- O3030.7 = 4: switch closed, periodic operation (run through curve cyclically)

**S2: Enable cam input; status switch in object 3030.17**

- O3030.17 = 0: switch open
- O3030.17 = 3: switch closed, single operation (run through curve once)
- O3030.17 = 4: switch closed, periodic operation (run through curve cyclically)

**Symbols of the signal image**

Symbol	Description
	<p><b>Point of addition:</b>  <math>d = a + b + c</math></p>
	<p><b>Point of multiplication:</b>  <math>c = a * b</math></p>
	<p><b>Comparison:</b>              If <math>b \geq a</math>, then output active</p>
	<p><b>Integrator</b>              Output signal = <math>\int(\text{Input signal}) * dt</math>              The output signal is the integral (sum over time) of the input signal              "Start value=0" will set the output to 0; this is triggered by activating "Execute" of an IEC module.</p>
	<p><b>Differentiator</b>              Output signal = <math>d(\text{input signal}) / dt</math>              The output signal is the derivation (gradient) of the input signal</p>
	<p><b>non-linear curve function</b> Slave / Master              Slave-Position = <math>f(\text{Master-Position})</math></p>
	<p><b>Closed control loop</b>              Input: Setpoint Position              Output: Actual position</p>
	<p><b>Reset function</b>              Output signal is reset to 0 after value "R".              Value R can be taken in the signal image.</p>
	<p><b>Command value generator</b>              Generates the desired setpoint process (e.g. when coupling into a curve)</p>
	<p><b>IEC function module</b>              with module name and input values</p>
	<p><b>Back stop</b>              Prevents a declining master signal              (Functions of <b>C3_MasterControl</b> (see page 237))</p>
	<p><b>Sampling-holding-function (SH: Sample &amp; Hold)</b>              The input value of the SH member is written to the output with trigger signal t.</p>



**5.10.5.3 Cam reference systems**

In this chapter you can read about:

Relative master reference without offset .....	229
Relative master reference with 180° offset .....	230
Absolute master reference without offset .....	231
Absolute master reference with 180° offset .....	232
Relative slave reference .....	232
Absolute slave reference .....	235

For a cam application it is necessary to adapt the curve values (positions) to the master and slave positions.


There are different possibilities to do this:

- ◆ relative master reference
  - ◆ without offset
  - ◆ with offset
- ◆ absolute master reference
  - ◆ without offset
  - ◆ with offset

The "Slave Cam output" setpoint signal from the curve is only related to the current physical slave position by the selected coupling function. A distinction is made between:

- ◆ relative slave reference and
- ◆ absolute slave reference


**Relative master reference without offset**



Master Cam input: Master signal at the curve input  
 (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position  
 o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits  
 o3032.24)

**Note:** ♦ With a relative master reference, a given curve is processed generally from the beginning, independent of the start delay (=offset).

**Relative master reference with 180° offset**




Master Cam input: Master signal at the curve input  
 (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position  
 o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits  
 o3032.24)

**Note:**

- ♦ With a relative master reference, a given curve is processed generally from the beginning, independent of the start delay (=offset).
- ♦ The offset is here used as start delay.
- ♦ The start of the C3\_CamTableSelect can be at any position; it must however be before the start offset is reached.


**Absolute master reference without offset**



Master Cam input: Master signal at the curve input  
 (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position  
 o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits  
 o3032.24)

- Hint** ♦ Only with absolute master reference, a given curve can be started at any position. This position corresponds to the offset value if the events "Start Source C3\_MasterControl" and "Start C3\_CamTableSelect" take place at the same point in time. Alternatively, you can preset the start value of the master position acquisition with the C3\_SetMaster.  
 Typical application: Shifting an open, s-shaped curve in the master reference system.

**Absolute master reference with 180° offset**



Master Cam input: Master signal at the curve input (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits o3032.24)


- Hint**
- ◆ Only with absolute master reference, a given curve can be started at any position. This position corresponds to the offset value if the events "Start Source C3\_MasterControl" and "Start C3\_CamTableSelect" take place at the same point in time. Alternatively, you can preset the start value of the master position acquisition with the C3\_SetMaster.  
 Typical application: Shifting an open, s-shaped curve in the master reference system.
  - ◆ The offset is added to the current value of the master signal at the start time of CamTableSelect.

**Relative slave reference**

Relative slave reference can be established with MC\_CamIn.  
 See also **application example 1** (see page 264)

**Relative slave reference example 1**


**Example 1: MC CamIn is started before or upon the curve start and the master position acquisition:**



Master Cam input: Master signal at the curve input (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits o3032.24)

**Relative slave reference example 2**

**Example 1: MC\_CamIn is started after the curve start and the master position acquisition:**



1: Alignment of the current slave setpoint position from the curve with the current setpoint position from the history of the Execute of the MC\_CamIn

Master Cam input: Master signal at the curve input  
(C3Cam.StatusMaster\_PositionCamUnits o3030.24)


Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position o3030.1)

Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits o3032.24)

**Note:** If a closed curve is combined with absolute master reference, an entry with MC\_CamIn at a master position > 0 will lead to a backwards movement of the axis with reference to the start point.

**Absolute slave reference**

Absolute reference can be established by coupling in with a coupling movement (Mode 1 or 2)



Master Cam input: Master signal at the curve input (C3Cam.StatusMaster\_PositionCamUnits o3030.24)  
 Master signal: Master signal of the acquisition (C3Cam.StatusMaster\_Position o3030.1)  
 Slave: Signal at the curve output (C3Cam.StatusOutput\_CurvePositionUnits o3032.24)

**Note:** The reference point and the curve zero point are always identical for absolute slave reference with C3\_CamIn.


**5.10.6. Master signal source**

In this chapter you can read about:


Setting the position of the selected master source (C3_SetMaster) .....	236
Recording the position of the selected master source (C3_MasterControl).....	237
Control of the cam generator (C3_CamTableSelect) .....	240
C3_MasterConfig.....	243
Master signal phase shift (MC_Phasing).....	244

**5.10.6.1 Setting the position of the selected master source (C3\_SetMaster)**

<b>FB name</b>	<b>C3_SetMaster</b>	
Setting the master position		
<b>VAR_IN_OUT</b>		
<b>Slave</b>	INT	
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Start setting sequence
<b>Value</b>	REAL	Start value
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Setting sequence finished successfully
<b>Error</b>	BOOL	Setting the master failed
<p>Note:</p> <ul style="list-style-type: none"> <li>◆ Setting the value is possible:                             <ul style="list-style-type: none"> <li>◆ without having selected a curve</li> <li>◆ during master position acquisition.</li> </ul> </li> <li>◆ The SetMaster function can only be executed, if the axis is not synchronized (not in "Synchronized Motion")</li> <li>◆ SetMaster interrupts the connection with the curve generator (see in the <b>signal image</b> (see page 225)).</li> <li>◆ If the "Value" is greater than the current reset distance, the value is allowed for in the reset distance.</li> </ul>		



Timing for Execute / Done:




"Done" comes immediately after the execution of the module.





### 5.10.6.2 Recording the position of the selected master source (C3\_MasterControl)


FB name	C3_MasterControl	
Start and Stop of the master detection		
<b>VAR_IN_OUT</b>		
<b>Slave</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Starting the module. Acquisition is started or stopped in accordance with the Mode
<b>StartMode</b>	INT	Selection of the Start mode 1: Start of the detection with rising edge of the enable 2: Fast start after external event (Impulse). Defined by "StartSource" and "StartMask", , does start within 0.5ms. 3: Start of the acquisition with the next encoder zero pulse, after the start of the modules (Enable = TRUE)
<b>StartSource</b>	DWORD	Specification of an object (see example) for starting the detection. Only relevant with StartMode 2. The address operator ADR () must be used for the selection of an object.
<b>StartMask</b>	WORD	Binary mask for and-linking the source in order to select a bit from the source object. Only relevant with StartMode 2.
<b>StopMode</b>	INT	Selection of the Stop mode 1: Stops the acquisition with falling edge of the Enable 2: Stops the detection at the end of the master clock distance. Defined via the curve or via <b>C3_MasterConfig</b> (see page 243).
<b>Periodic</b>	BOOL	False: run trough once True: cyclic run
<b>BackStop</b>	BOOL	False: Backstop not active True: Back stop active
<b>Master</b>	INT	<b>Axis- ID of theMaster signal source</b> (see page 161) AXIS_REF_HEDA: HEDA AXIS_REF_Physical: +/-10V, step/direction/ Encoder AXIS_REF_Virtual: virtual Master
<b>VAR_OUTPUT</b>		
<b>Status</b>	BOOL	Shows that the master position acquisition is running
<b>EndOfProfile</b>	BOOL	Impulse at the end of the configured master cycle
<b>Busy</b>	BOOL	Waiting for an external event
<b>Error</b>	BOOL	Command was aborted; error when starting the detection
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ Witht the active enable, the "Periodic" and "Master" inputs are always accepted.</li> <li>◆ With the transition Enable low to high the StartMode is evaluated.</li> <li>◆ With the transition Enable high to low the StopMode is evaluated.</li> <li>◆ Only one module controlling the detection is allowed in the project.</li> <li>◆ Enable and StartSource must have different sources.</li> </ul>		



- Example 1:**
- ◆ Enable of the master position acquisition with input I0.
  - ◆ Start of the detection with an external event = rising edge at the I1 input. Input I1 is selected via the object "C3.DigitalInput\_Value". The input I1 is placed on Bit 1 (counting from 0), as a result the input "StartMask" receives the value 2.
  - ◆ Detection runs in single mode.



- Example 2:**
- ◆ StopMode=2: Acquisition stops at the end of the master clock distance
  - ◆ If "Enable" is deactivated within the master clock distance and is re-activated before the end of the master clock distance, the acquisition will continue undisturbed.



**Cam operation with STOP or Error**


The master position and the curve are not influenced by a STOP or an error of the axis.  
 The detection and the curve generation continue; this means that the curve output is also available in the case of an error.

### 5.10.6.3 Control of the cam generator (C3\_CamTableSelect)


<b>FB name</b>	<b>C3_CamTableSelect</b>	
Control of the curve generator		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Axis ID; constant: AXIS_REF_LocalCam
<b>Slave</b>	INT	
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Curve selection with positive edge
<b>CamTable</b>	INT	Curve number (beginning with 1)
<b>Periodic</b>	BOOL	=FALSE: run through curve once (Single operation) =TRUE: cyclic run trough curve (periodic operation)
<b>MasterAbsolute</b>	BOOL	Select master reference of the curve FALSE = relative TRUE = absolute
<b>Mastercycle</b>	REAL	Value of the master segment distance [physical units] 3 decimal places are considered.
<b>Slavecycle</b>	REAL	Value of the slave segment distance [physical units] 3 decimal places are considered.
<b>MasterOffset</b>	REAL	<b>Absolute mode:</b> Offset at the start of the master position aquisition <b>relative mode:</b> Start delay, the master position acquisition starts if the master signal reaches this value, see in the <b>signal image</b> (see page 225). If the input is open the curve starts with Execute (without delay)
<b>LastSegment</b>	BOOL	Resets the display, see in the <b>signal image</b> (see page 225) and is used as reference signal for coupling.
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Change of curves finished
<b>Busy</b>	BOOL	Waiting for change of cams
<b>EndOfSegment</b>	BOOL	Impulse at the end of a curve even if no Execute is present
<b>Error</b>	BOOL	Command aborted Error in cam selection or master connection

**Note:**

- ◆ If the inputs "Mastercycle" and "Slavecycle" are not assigned, the master cycle is accepted by the configuration and the highest feed of the selected curve is taken as slave cycle (see **curve types** (see page 211)).
- ◆ If the MasterAbsolute input stands on TRUE (absolute), the switch to the curve generator is closed with the CamTableSelect and the curve adapts to the master position detection.  
The MasterOffset functions as Offset for the master position acquisition; Input not assigned means MasterOffset = 0.
- ◆ If the MasterAbsolute input stands on FALSE (relative), the switch to the curve generator is closed with the CamTableSelect and the curve does not adapt but begins on the master side at 0.  
The MasterOffset works as start delay; the curve starts only when the master has traveled further than this value in the positive direction.
- ◆ If the curve runs in single mode, only direct coupling with MC\_CamIn is sensible.
- ◆ If the curve runs in single mode and the master runs periodically, it is only sensible to have the curve run relative to the master.
- ◆ After running through the curve in single mode, the drive changes from the "Synchronized Motion" state back to the "Standstill" state, i.e. after a SingleStart a positioning is possible.
- ◆ An Execute during a curve cycle leads to a curve change at the end of the curve cycle. The "MasterAbsolute" and "MasterOffset" inputs are not evaluated.  
Please note: If an Execute signal follows an Execute (by bouncing), another change of curve is already triggered.
- ◆ With relative master reference (MasterAbsoute=FALSE) with start delay, the change of curve is already executed (Done=TRUE), if the master signal has not yet reached the Masteroffset (start delay).
- ◆ In the event of error message 0xFFE2: Er ror in the IEC61131-3 program sequence. Function module was called with incorrect parameters.  
CamTable<1 or CamTable>C3Cam.StatusData\_SegmentsInFlash



**Example / Timing diagram**




**Cam operation with STOP or Error**


The master position and the curve are not influenced by a STOP or an error of the axis.  
 The detection and the curve generation continue; this means that the curve output is also available in the case of an error.

**5.10.6.4 C3\_MasterConfig**

<b>FB name</b>		<b>C3_MasterConfig</b>
Configure reset distance of the position of selected master (does not influence the curve, only in the display object)		
<b>VAR_IN_OUT</b>		
<b>Slave</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Start configuration
<b>Numerator</b>	DINT	Numerator of the reset distance to master position acquisition
<b>Denominator</b>	DINT	Numerator of the reset distance for the position of selected master source (automatically 1 with alternative master clock distance)
The reset distance is disabled with: Numerator = 0 and Denominator = 1 thus the display is no longer reset		
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Configuration finished successfully.
<b>Error</b>	BOOL	Configuration of the master failed
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ Module can be executed with running master.</li> <li>◆ Write Flash is not executed, the changed values of the reset distance are lost when switching off.</li> <li>◆ The reset distance defined via the module deactivates the previously valid reset distance of the curve, see in the <b>signal image</b> (see page 225).</li> <li>◆ For linked <b>curves</b> (see page 271) the sum of all master segments (Numerator / Denominator) is entered as reset distance.</li> </ul>		



Timing for Execute / Done:





"Done" comes immediately after the execution of the module.

### 5.10.6.5 Master signal phase shift (MC\_Phasing)

FB name	MC_Phasing	
<p>A phase equalization between Master and Slave can be performed with a position offset. Only the Master signal in the Slave is affected in this case. The Master itself remains unaffected.</p> <p>PhaseShift influences the master signal before the curve; the slave moves by the resulting distance after the curve.</p> <p>Calling MC_Phasing a second time causes an additional offset of the Master signal by the value specified in PhaseShift</p>		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Axis ID; constant: AXIS_REF_LocalCam
<b>Slave</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Starts the sequences of the module with positive edge
<b>PhaseShift</b>	REAL	The relative distance that will be added to the Master signal (configured unit [units] ) (positive and negative direction) <b>&lt;Value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>MoveVelocity</b>	REAL	Speed when adjusting the Master signal (always positive) (not necessarily reached) [units/s] <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Acceleration</b>	DINT	Acceleration when adjusting the Master signal (always positive) [units/s <sup>2</sup> ] <b>&lt;Value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Deceleration</b>	DINT	Deceleration when adjusting the Master signal (always positive) [Units/s <sup>2</sup> ] <b>&lt;Value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>Jerk</b>	DINT	Acceleration <b>jerk</b> (see page 183) [Units/s <sup>3</sup> ] when changing the master signal (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>JerkDecel</b>	DINT	Deceleration <b>jerk</b> [Units/s <sup>3</sup> ] when adjusting the Master signal (always positive) <b>&lt;value range&gt;</b> (see page <b>Fehler! Textmarke nicht definiert.</b> )
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Phase offset achieved
<b>CommandAborted</b>	BOOL	Command aborted
<b>Error</b>	BOOL	Error while executing module
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ The values PhaseShift, Velocity, Acceleration, Deceleration, Jerk JerkDecel are no absolute values, they are added to the current movement of the master signal.</li> <li>◆ MC_Phasing is not stopped by a stop of the axis.</li> <li>◆ This module cannot be operated with C3_ShiftPosition and MC_MoveSuperImposed at a time.</li> <li>◆ This function is only possible in cam operation.</li> </ul>		





## 5.10.7. Alignment of the slave axis

### In this chapter you can read about:

Start cam / coupling .....	246
Exiting the active curve with coupling movement (C3_CamOut) .....	257

### 5.10.7.1 Start cam / coupling

#### In this chapter you can read about:


Starting a selected curve (MC_CamIn).....	247
Starting a selected curve with coupling movement (C3_CamIn).....	249

**Starting a selected curve (MC\_CamIn)**


<b>FB name</b>	<b>MC_CamIn</b>	
Synchronization of the axis with the output of the curve generator without coupling movement		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Axis ID; constant: AXIS_REF_LocalCam
<b>Slave</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Curve start with positive edge
<b>VAR_OUTPUT</b>		
<b>InSync</b>	BOOL	Synchronous operation active
<b>CommandAborted</b>	BOOL	Command aborted
<b>Error</b>	BOOL	Command aborted Error in the cam operation
<b>EndOfProfile</b>	BOOL	End of a cam cycle. A pulse with the length of an IEC cycle indicates the end of each cam cycle. Suitable for setting up a loop counter.

**Note:**

- ◆ Curve alignment:
  - ◆ Execute is followed by immediate coupling; the current curve setpoint value is adapted to the current slave setpoint value. This adapts the curve to the current position.
  - ◆ In order to avoid velocity jumps, the master should be at a standstill or the curve should have an initial gradient (slope) of 0.
- ◆ MC\_CamIn can also be started by a C3\_CamTableSelect, if the curve setpoint value does not jump after the start of the C3\_CamTableSelect **example 6: Operation with curve segments and standstill area** (see page 276).



**Direct coupling with MC\_CamIn**



Sa: current slave position  
 MT: Master clock distance  
 ST: Slave clock distance

**Starting a selected curve with coupling movement (C3\_CamIn)**



**In this chapter you can read about:**

Quadratic coupling (CouplingMode = 1) ..... 251  
 Direct coupling (CouplingMode = 0) ..... 253  
 Change-over (CouplingMode = 2) ..... 254

FB name		C3_CamIn
Synchronization of the axis to the output of the curve generator with adjustable coupling movement		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Axis ID; constant: AXIS_REF_LocalCam
<b>Slave</b>	INT	
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Curve start with positive edge
<b>CouplingMode</b>	INT	0 = coupling without coupling movement, after the master having traveled over the coupling position (ME) in positive direction. 1 = coupling via quadratic function; the master coupling position (ME) is calculated. 2 = coupling via changeover function.
<b>CouplingPosition</b>	REAL	Master coupling position (ME) in master units (is taken into consideration with CouplingMode = 0 and 2 with CouplingMode = 1, the coupling position is calculated) Value range: 0 ... n*MT
<b>SyncPosition</b>	REAL	Master synchronous position (MS) in master units (not relevant with CouplingMode = 0) Value range: CouplingMode 1: 0 ... MT CouplingMode 2: 0 ... n*MT
<b>VAR_OUTPUT</b>		
<b>InSync</b>	BOOL	Synchronous operation active
<b>CommandAborted</b>	BOOL	Command aborted
<b>Error</b>	BOOL	Command aborted Error in the cam operation
<b>EndOfProfile</b>	BOOL	End of a slave cam cycle. A pulse with the length of a IEC cycle indicates the end of each master cam cycle . Suitable for setting up a loop counter.

**Note:**

- ◆ Master coupling position (ME) and master synchronized position (MS):
  - ◆ With CouplingMode = 0: ME is taken into consideration, MS not relevant.
  - ◆ With CouplingMode = 1: ME is calculated internally, MS is taken into consideration.
  - ◆ With CouplingMode = 2: ME is taken into consideration, MS is taken into consideration.
- ◆ With CouplingMode = 1 the curve must be constantly rising at the Master synchronous position (MS).
- ◆ If the master runs backwards after the beginning of the coupling movement, the slave will be at its original position after reaching the coupling position.
- ◆ With changeover, the coupling function depends on the current curve.
- ◆ The relevant master position for coupling position and synchronized position is object 3030.24.
- ◆ Before C3\_CamIn is executed, a curve must be selected with C3\_CamTableSelect.



Example with CouplingMode = 1 and C3\_CamTableSelect: Periodic = TRUE.

Autoryzowany dystrybutor Parker:

**ARA**

**PNEUMATIK**

53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83

[www.arapneumatik.pl](http://www.arapneumatik.pl)



**Quadratic coupling (CouplingMode = 1)**

The quadratic coupling results in a quadratic position course of the slave axis without velocity superlevation:

The synchronous position with master reference (MS) is ideally stated within the hind range of the master clock distance, so that the coupling movement takes place within one single cycle.


For this, the start position (activating the coupling sequence with C3\_CamIn: Execute) must also be near the curve zero point.

The master-related coupling position (ME) is calculated from the slope of the curve in the synchronization point and the actual slave position (Sa) so that it results in a quadratic position course.

For this, there must be a positive slope (gradient) at the synchronization position.

The master speed must be positive, i.e. the master position must be rising.


**Coupling via a slave clock distance**



- SS: Slave synchronization position
- Sa: current slave position before start of curve
- ME: Master coupling position calculated from MS, slope in MS/SS and Sa
- MS: Master synchronous position
- MT: Master clock distance
- ST: Slave clock distance
- e(M): quadratic coupling function
- 1: gradient triangle: determines the duration of the coupling sequence (the steeper, the faster is the coupling sequence)

**Coupling over several slave clock distances**


If the curve has a very flat slope in the synchronization point (MS/SS), or if the current Slave Sa is behind the Slave synchronization position, the coupling sequence takes place over several master cycles.



- SS: Slave synchronization position
- Sa: current slave position before start of curve
- ME: Master coupling position calculated from MS, slope in MS/SS and Sa
- MS: Master synchronous position
- MT: Master clock distance
- ST: Slave clock distance
- e(M): quadratic coupling function
- 1: The slave setpoint value is reset at this position in the display.



**Direct coupling (CouplingMode = 0)**



Sa: current slave position  
 MT: Master clock distance  
 ST: Slave clock distance

After Execute of C3\_CamIn the slave will only couple in from the master coupling position ME.

In order to avoid velocity jumps, the curve should have an initial gradient (slope) of 0.

### Change-over (CouplingMode = 2)

When using the change-over-function, the curve setpoint value is permanently displayed during coupling, while the current slave position is permanently hidden. Overspeeding and pull-out movement are possible.

By specifying the master-related coupling and synchronization position in master units, the coupling curve is mapped to a range of any length of the curve. This means that it is no longer fixedly coupled to the curve cycle.

### Algorithm of the change-over function

The normalized coupling function begins at the value 0 and ends at the value 1 and rises continually in between. It is a 5th order function.

The coupling curve does not produce a direct slave setpoint value but produces a factor KE for the weighting of the current curve setpoint value resp. the current slave position Sa (position at the start of the coupling sequence).

The course of the coupling curve depends on the slave position Sa and the course of the curve in synchronized operation.

The master speed must be positive, i.e. the master position must be rising.

The weighting is made according to the following function:

$$\text{coupling curve} = SK * KE + S0 * (1 - KE)$$


with:

S0 = standstill position

SK = current curve setpoint value

KA = control variable between 0 ... 1.0 (between ME and MS)

### Example: Change-over function over a curve cycle



SS: Slave synchronization position

Sa: current slave position before start of curve

ME: Master coupling position = 30°


MS: Master synchronized position = 340°

MT: Master clock distance = 360°

ST: Slave clock distance


The slope (speed) of the coupling sequence shows a clear overspeeding in comparison with the synchronized run.

**Example: Change-over function over several curve cycles**



- SS: Slave synchronization position
- Sa: current slave position before start of curve
- ME: Master coupling position = 60°
- MS: Master synchronized position = 700°
- MT: Master clock distance = 360°
- ST: Slave clock distance
- 1: The slave setpoint value is reset at this position in the display.

**Change-over function KE:**





**5.10.7.2 Exiting the active curve with coupling movement (C3\_CamOut)**

**In this chapter you can read about:**

Direct decoupling (CouplingMode = 0) ..... 258  
 Quadratic decoupling (CouplingMode = 1) ..... 259  
 Decoupling with change-over function (CouplingMode = 2) ..... 260

<b>FB name</b>		<b>C3_CamOut</b>
Decouple the active curve with adjustable coupling movement		
<b>VAR_IN_OUT</b>		
<b>Master</b>	INT	Axis ID; constant: AXIS_REF_LocalCam
<b>Slave</b>	INT	
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activate the decoupling process with a positive edge
<b>DecouplingMode</b>	INT	0 = decoupling without coupling movement, after the master having traveled over the decoupling position MA in positive direction. (MB and S0 not relevant) 1 = decoupling via quadratic function; the master braking position (MB) is calculated 2 = decoupling via changeover function
<b>DecouplingPosition</b>	REAL	Master decoupling position in Master units (MA) Value range: 0 ... MT
<b>BrakingPosition</b>	REAL	Master braking position in master units (MB) (is taken into consideration with CouplingMode = 2 with CouplingMode = 1, the braking position is calculated). MB must be > than MA. Value range: 0 ... n*MT
<b>StandstillPosition</b>	REAL	Slave standstill position in Slave units (S0)
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Decoupling complete
<b>InSync</b>	BOOL	Wait for decoupling position
<b>Error</b>	BOOL	Command aborted Error in the cam operation
<b>EndOfProfile</b>	BOOL	End of the curve cycle.
<p>Note:</p> <ul style="list-style-type: none"> <li>◆ Decoupling is not possible during coupling.</li> <li>◆ Master decoupling position (MA) and Master braking position (MB)                             <ul style="list-style-type: none"> <li>◆ With DecouplingMode 0: MA is taken into consideration, MB not relevant.</li> <li>◆ With DecouplingMode 1: MA is taken into consideration; MB is calculated.</li> <li>◆ With DecouplingMode 2: MA is taken into consideration; MB is taken into consideration.</li> </ul> </li> <li>◆ The Slave standstill position is not taken into consideration with DecouplingMode = 0.</li> <li>◆ With DecouplingMode =1 the curve must be constantly rising at the Master decoupling position (MA).</li> <li>◆ if the master runs backwards after the beginning of the decoupling movement, the curve is accessed again after reaching the decoupling position.</li> <li>◆ With changeover, the decoupling function depends on the current curve.</li> <li>◆ The relevant master position for ecoupling position and braking position is object 3030.24.</li> <li>◆ In the event of error message 0xFFE2: Error in the IEC61131-3 program sequence. Function module was called with incorrect parameters. DecouplingMode=2 and BrakingPosition &lt;= DecouplingPosition</li> </ul>		



Example with DecouplingMode = 1 and C3\_CamTableSelect: Periodic = TRUE.

### Direct decoupling (CouplingMode = 0)

With direct decoupling, the curve operation is immediately terminated with the Execute.

In order to avoid speed jumps, the master should be at a standstill during direct decoupling or should be decoupled at a point, where the slope is 0 (constant slave position).

### Quadratic decoupling (CouplingMode = 1)


The quadratic decoupling results in a quadratic position course of the slave axis without velocity superlevation:

The braking position (MB) is calculated from the slope of the curve at the decoupling point and the standstill position (S0) so that a quadratic position course is the result.

If the standstill position is smaller than the slave position at the beginning of the decoupling, the decoupling movement will only be terminated in the following cycle. For this, there **must** be a positive slope (gradient) at the decoupling position. The master speed must be positive, i.e. the master position must be rising.

### Decoupling over several master clock distances

If the slope (gradient) of the curve in the decoupling point is very flat, the decoupling sequence will take several master clock distances.



S0: Slave standstill position

Sa: Slave position at the master decoupling position

MA: Master decoupling position

MB: Master braking position

MT: Master clock distance

ST: Slave clock distance

a(M): quadratic decoupling function

1: gradient triangle: determines the duration of the decoupling sequence (the steeper, the faster is the coupling sequence)

### Decoupling with change-over function (CouplingMode = 2)

The standstill position is continually displayed during decoupling, while the curve is continually hidden.

Overspeeding and pull-out movement are possible.

By the specification of the master-related decoupling and braking position in master units, the decoupling curve is mapped on any length of the curve.

### Algorithm of the change-over function

The normalized coupling function corresponds to the coupling function, but it is run through in inverse direction during decoupling. It provides factor KA, which is used for the weighting.

The course of the decoupling curve depends on the standstill position and the course of the curve in synchronized operation.

The weighting is made according to the following function:

$$\text{decoupling curve} = SK * KA + S0 * (1 - KA)$$


with:

S0 = standstill position

SK = current curve setpoint value

KA = control variable between 1.0 ... 0 (between MA and MB)

### Example: Decoupling with the changeover-function



S0: Slave standstill position

MA: Master decoupling position = 60°

MB: Master braking position 680°

MT: Master clock distance = 360°

ST: Slave clock distance



## 5.10.8. 10 Steps for cam generation

### In this chapter you can read about:

Step 1: C3 ServoManager .....	261
Step 2: Connect motor.....	261
Step 3: Supply & I/O wiring.....	261
Step 4: RS232 connection & C3 ServoManager .....	261
Step 5: Set Compax3 device type .....	262
Step 6: Configuration.....	262
Step 7: Selecting Master signal source .....	262
Step 8: Generating the cam .....	262
Step 9: Create IEC program .....	263
Step 10: Starting and monitoring cam .....	263

### **Example:**

- ◆ Electronic Cam with 2 standstill areas,
- ◆ Master signal is the internal virtual master.

### **5.10.8.1 Step 1: C3 ServoManager**

- ◆ Install Compax3 ServoManager (Compax3-CD 840-100005) on your PC (it is recommended to un-install all previous versions beforehand).
- ◆ Install CamDesigner (Compax3-CD 840-100005).
- ◆ You need a RS232 cable (SSK1/xx) for the connection PC - Compax3 X10.

### **5.10.8.2 Step 2: Connect motor.**

- ◆ Motor cable to Compax3 X3
- ◆ Feedback cable to Compax3 X13.

### **5.10.8.3 Step 3: Supply & I/O wiring**

- ◆ AC supply (1 or 3 phase) to X1
- ◆ DC supply to X4
- ◆ Device enable by 24VDC on X4/Pin3
- ◆ The following digital inputs must be assigned:
 

Input 0 - Pin X12/6	24V = Enable of the power output stage
Input 1 - Pin X12/7	24V = Start machine zero
Input 2 - Pin X12/8	24V = Start virtual master
	0V = Stop virtual master
Input 4 - Pin X12/10	24V = select and start curve
Input 5 - Pin X12/12	24V = curve coupling
Input 6 - Pin X12/13	24V = curve decoupling
Input 7 - Pin X12/14	24V = Reset (ackn.)

### **5.10.8.4 Step 4: RS232 connection & C3 ServoManager**

- ◆ Establish RS232 connection (cable SSK1/xx) between PC and C3 X10.
- ◆ Start C3 ServoManager

### 5.10.8.5 Step 5: Set Compax3 device type

- ◆ Compax3 device selection wizard, select type
- or
- ◆ Type online identification

### 5.10.8.6 Step 6: Configuration

Start configuration in the C3 ServoManager and configure Compax3.

- ◆ Set motor
- ◆ Braking Resistor
- ◆ External moment of inertia
- ◆ Reference System
  - ◆ Unit: Degrees
    - ◆ Travel distance per motor revolution numerator = 360°
    - ◆ Travel distance per revolution – Denominator = 1
    - ◆ Reset distance numerator = 360°
    - ◆ Reset distance denominator = 1
- ◆ Machine zero = mode 34
- ◆ Limit switch
- ◆ Jerk / Ramps
- ◆ Monitoring / Limits: Following error to 5°
- ◆ Encoder Simulation
- ◆ Variable (Recipe) List

### 5.10.8.7 Step 7: Selecting Master signal source

- ◆ Open entry of signal source (left side of the tree)
- ◆ Select master signal source: virtual Master
- ◆ Enter units and reset distance (360°)
- ◆ Rs485 settings

**load configuration into Compax3.**

### 5.10.8.8 Step 8: Generating the cam

Call up/process curve with the aid of the CamEditor

- ◆ Enter axis name
- ◆ Select signal source of virtual master
- ◆ Enter number of interpolation points: 360
- ◆ Enter motion law: dwell-to-dwell: "Modified Sine Line according to Neklutin"
- ◆ Start CamDesigner
- ◆ Under Menu File: New sequence. Select axis name
- ◆ Add 2 standstill areas: 0/360; 0/310; 50/360 (Path coordinate/clock angle)
- ◆ View path-time-diagram and optimize curve if needs be
- ◆ End CamDesigner via Menu:File:End
- ◆ Download of the curve into Compax3

**5.10.8.9 Step 9: Create IEC program**

- ◆ Start IEC development environment (in the tree on the left side under Programming: IEC61131-3 development environment)
- ◆ File, enter new project name
- ◆ Set target system: CoDeSys for C3 T40
- ◆ Open program example "cd\examples\10StepsToCam" in CFC.
- ◆ Save project
- ◆ Project translate everything
- ◆ Download of the IEC program into Compax3 (in the C3 ServoManager in the tree on the left side under Download: IEC61131-3)

**5.10.8.10 Step 10: Starting and monitoring cam**

Input 0 - Pin X12/6	24V = energize Compax3
Input 1 - Pin X12/7	24V = Starting the homing run
Input 2 - Pin X12/8	24V = Start virtual master 0V = Stop virtual master
Input 4 - Pin X12/10	24V = select and start curve
Input 5 - Pin X12/12	24V = curve coupling
Input 6 - Pin X12/13	24V = curve decoupling
Input 7 - Pin X12/14	24V = Reset (ackn.)

Control status values in the IEC61131-3 - Debugger or in the oscilloscope (optimization window) (e. g. C3Cam.STATUSMASTER\_Position, ...)

## 5.10.9. Cam applications

### In this chapter you can read about:

Example 1: Single start of a closed cam .....	264
Example 2: Change between single start of an open cam and POSA .....	267
Example 3: Single Start for run through curve 5 times .....	269
Example 4: Composing curves .....	271
Example 5: Cyclic operation with event-triggered change of curve .....	274
Example 6: Operation with curve segments and standstill area .....	276
Example 7: Curve operation with slave reg synchronization .....	279
Example 8: Curve operation with master reg synchronization .....	281
Example case of damage .....	284
Application note: Drift .....	286

You will find the applications described below as CoDeSys project on the Compax3 CD in the "\Examples" file.

The following application descriptions can also be found on the CD in the "\Examples" file:

C3T40_A1003	Cutting on the fly with Start/Stop operating mode, registration mark reference, separation function, phase correction
C3T40_A1004	Flying knife with fixed blade circumference and variable product length
C3T40_A1005	Sync gate, registration mark reference, synchronous motion, automatic or manual travel back to start position.
C3T40_A1007	PID controller for IEC61131-3; operating P, PD, PI, PID are possible
C3T40_A1015	Gearing with Stop/Start and Phase correction

The ZIP files contain the german and english description as well as the related projects.

### 5.10.9.1 Example 1: Single start of a closed cam

#### Task:


- ◆ Closed cam (forwards and backwards) with standstill area at the beginning and at the end.
- ◆ Digital input starts run through curve once.
- ◆ Connection to virtual master.

**Corresponding files:** CamExample01.C3P (Compax3 project on the Compax3 CD:\Examples\Example1)  
CamExample01.pro (CoDeSys project on the Compax3 CD:\Examples\Example1)

#### Control interface:


Input	Function
I0	Energize axis, homing, curve generator, starting and coupling axis
I1	Enable master detection
I2	Starting detection in single mode
I3	Start of the virtual master
I4	Free
I5	Free
I6	Free
I7	Free

**Solution:**



- ◆ The curve is activated after the homing run (Home.Done to CTS1).
- ◆ After that the axis is synchronized via CS1.Done at CI1. Now the master detection can be started.
- ◆ Input I1 enables the master acquisition, which will wait for the external event (Input I2)  
 In order to do this, the C3\_MasterControl module: is assigned to following value: ADR(C3.DigitalInput\_Value).  
 In order to select the 3rd bit from this value the input StartMask receives the value 4.
- ◆ The master acquisition runs in Single Mode and the curve generator (C3\_CamTableSelect) in the Periodic, this means that the switch between the curve generator and detection is always closed, see in the **signal image** (see page 225). With the external event (input I2) a curve cycle is run through.

**Signal image:**



**5.10.9.2 Example 2: Change between single start of an open cam and POSA****Task:**


- ◆ Open curve with standstill range at the beginning and at the end
- ◆ Digital input starts run through curve once
- ◆ Digital input starts positioning movement on slave cycle
- ◆ Connection to encoder

**Corresponding files:** CamExample02.C3P (Compax3 project on the Compax3 CD:\Examples\Example2)  
CamExample02.pro (CoDeSys project on the Compax3 CD:\Examples\Example2)

**Control interface:**

Input	Function
I0	Energize axis, homing, curve generator, starting and coupling axis
I1	Starting detection in single mode
I2	Start of the absolute movement
I3	Free
I4	Free
I5	Free
I6	Free
I7	Free

**Solution:**





**Explanation:**

- ◆ The repeated turning up of the single start during the run through curve must not disturb the operation.
- ◆ Single start during positioning must not disturb, curve must not start:  
This is prevented by the fact that the enable of the master position detection is only started, if the drive is in the "Synchronized Motion" state.
- ◆ If a positioning is executed, the axis is in the "discrete Motion" state. When MC-CamIn is executed, the axis will switch into the "Synchronized Motion" state; the axis is now synchronous with the curve generator.
- ◆ Master detection is started with an external event (input I1).  
In order to do this the C3\_MasterControl module: is assigned to following value: ADR(C3.DigitalInput\_Value = object for the digital inputs).  
In order to select the 2nd bit from this value the input StartMask receives the value 2.
- ◆ The axis is coupled after Homing (MC\_CamIn), then the curve generator (C3\_CamTableSelect) starts, after that the master position acquisition is started via the external input (C3\_MasterControl).  
As the output Home.Done is permanently present, this output must be put to C11 with an edge module. This ensures that C11 (MC\_CamIn) can be activated again.
- ◆ The absolute movement is not executed in the "Synchronized Motion" status (MC\_MoveAbsolut reports an error), so this is automatically blocked.

**5.10.9.3****Example 3: Single Start for run through curve 5 times****Task:**


- ◆ Open curve without standstill area
- ◆ Coupling / decoupling with change-over function
- ◆ Digital input for the start of 5 curve cycles (incl coupling and decoupling cycle)

**Corresponding files:** CamExample03.C3P (Compax3 project on the Compax3 CD:\Examples\Example3)  
CamExample03.pro (CoDeSys project on the Compax3 CD:\Examples\Example3)

**Control interface:**

Input	Function
I0	Energize axis, Homing
I1	Enable and start of the master position detection
I2	Start of the curve cycle
I3	Free
I4	Free
I5	Free
I6	Free
I7	Start of the virtual master

**Solution:**



**Explanation:**

- ◆ Coupling from 0 on (CamIn.CouplingPosition = 0), decoupling on 360° (CamOut.StandstillPosition = 360°).
- ◆ The curve generator (C3\_CamTableSelect) is started in relative Mode with the Input I2.
- ◆ with MasterOffset = 0, the next zero crossing is waited for if the master is already running.
- ◆ The busy output of CTS1 starts the coupling sequence before the selected curve is active. Only if the master position has exceeded the value 0 (CTS1.MasterOffset = 0, CTS1.MasterAbsolute = TRUE), the curve starts to run and CTS1.Done will become TRUE.
- ◆ After the 3rd impulse "EndOfSegment" of the C3\_CamTableSelect module, the 4th curve is already running. The change of cam to the single mode is then triggered with the counter module. This will become active at the end of the 4th curve, so that the curve is run through 5 times.
- ◆ If the change to the 5th curve cycle has been executed, the Done output will come to this module (CTS2), which will trigger the decoupling sequence.

**5.10.9.4 Example 4: Composing curves**


- ◆ 3 curves (ramp-up curve, straight line, ramp-down curve) with the same master clock distance
- ◆ digital input for single start of a curve sequence, after that standstill until the repeated start of the 3-curve sequence.

**Corresponding files:** CamExample04.C3P (Compax3 project on the Compax3 CD:\Examples\Example4)  
CamExample04.pro (CoDeSys project on the Compax3 CD:\Examples\Example4)

**Control interface:**

Input	Function
I0	Energize axis, Homing
I1	Enable and start of the master position detection
I2	Coupling and curve start
I3	Free
I4	Free
I5	Free
I6	Free
I7	Start of the virtual master


**Solution:**



**Explanation:**

- ◆ The entire curve line is 720° long, the reset distance in the slave axis configuration stands on 720° (Configuration: Reference system).
- ◆ The change of cams is triggered with the Done of the curve activated before (CTS1 ... CTS3). The Done output follows, if the change into the respective curve has been executed.
- ◆ The axis is synchronized with input I2 (CamIn) and at the same time the curve generator (CTS1) is started.1  
This ensures that no increments are lost with running master.

**Design of a curve:**



Position Reset Distance Slave: Reset distance slave

Position Reset Distance Master: Reset distance Master = time axis in the Cam Designer

### 5.10.9.5 Example 5: Cyclic operation with event-triggered change of curve


- ◆ 2 curves with the same clock distances: S-curve without standstill area and straight line
- ◆ digital input for quadratic coupling and decoupling
- ◆ digital input for switching of curve
- ◆ Master reference must be kept with exactly the same increments during the change
- ◆ The master position acquisition must continue in decoupled state

**Corresponding files:** CamExample05.C3P (Compax3 project on the Compax3 CD:\Examples\Example5)  
CamExample05.pro (CoDeSys project on the Compax3 CD:\Examples\Example5)

#### Control interface:

Input	Function
I0	Energize axis, Homing
I1	Enable and start of the master position detection
I2	Selection of cam
I3	Coupling / Decoupling
I4	Free
I5	Free
I6	Free
I7	Start of the virtual master

**Solution:**



**Explanations:**

- ◆ Via Input I2 either curve 1 (CTS1) or curve 2 (CTS2) is activated, both in the absolute mode (MasterAbsolute=TRUE).
- ◆ The detection starts with I1 (MasterControl).
- ◆ Coupling in takes place with rising edge of I3, decoupling takes place with falling edge of I3.

**5.10.9.6 Example 6: Operation with curve segments and standstill area**

- ◆ Via a master cycle, a slave feed with following standstill is to take place from a master position of 30° on; from a master position of 230° on, the slave is to return. This sequence is to be repeated cyclically.


**Corresponding files:** CamExample06.C3P (Compax3 project on the Compax3 CD:\Examples\Example6)  
CamExample06.pro (CoDeSys project on the Compax3 CD:\Examples\Example6)

**Control interface:**

Input	Function
I0	Energize axis, Homing
I1	Enable and start of the master position detection
I2	Start of the curve cycle
I3	Free
I4	Free
I5	Free
I6	Free
I7	Start of the virtual master



**Solution:**




**Boundary conditions:**

- ◆ After the coupling of the axis, the curve generator (CST1) is started in relative mode with an offset of 30°. The start of the curve takes only place, if a master position of 30° is reached.
- ◆ The feed takes place via 100 master degrees (C3\_CamTableSelect module): Mastercycle = 100).
- ◆ With the falling edge of EndofSegment of the CamTableSelect module (CTS1), the next movement will be triggered via CamIn2.
- ◆ CamIn2 will start via "InSynch" the 2nd C3\_CamTableSelect (CTS2), whose curve will reset the slave to its previous position via the master position range between 100° and 230°.
- ◆ The sequence can be repeated with "EndofSegment" of this module.

**Special feature:**

- ◆ In this example, the curve shall be run through entirely, therefore MC\_CamIn is started before C3\_CamTableSelect. This is only possible with MC\_CamIn.

**Signal image:**




**5.10.9.7 Example 7: Curve operation with slave reg synchronization**

The slave position in the curve mode is to be corrected in dependence of a registration mark: Slave-oriented reg synchronization.

**Corresponding files:** Slave\_Markenkorrektur\_Example.C3P (Compax3 Project auf Compax3  
CD:\Examples\Example7)  
Slave\_Markenkorrektur\_Example.pro (CoDeSys Project on the Compax3  
CD:\Examples\Example7)

<b>Control interface:</b>	<b>Input</b>	<b>Function</b>
	I0	Energize axis, homing, select curve, starting and coupling axis (static)
	I1	Enable and start of the master position acquisition (static)
	I2	Start virtual master
	I3	Reg enable (static)
	I4	Reg input (edge)
	I5	Free
	I6	Free
	I7	Free


**Solution:**



**Boundary conditions:**

- ◆ Setpoint position of the registration mark: 90°
- ◆ Ignore zone of the reg detection: 180° - 360°

**curve**




**5.10.9.8 Example 8: Curve operation with master reg synchronization**

The master position in the curve mode is to be corrected in dependence of a registration mark: Master oriented reg synchronization.

**Corresponding files:** Master\_Markenkorrektur.C3P (Compax3 Project auf Compax3  
 CD:\Examples\Example8)  
 Master\_Markenkorrektur.pro (CoDeSys Project on the Compax3  
 CD:\Examples\Example8)

Control interface:	Input	Function
	I0	Energize axis, homing, select curve, starting and coupling axis (static)
	I1	Enable master acquisition (static)
	I2	Start virtual master
	I3	Reg enable (static)
	I4	Reg input (edge)
	I5	Free
	I6	Free
	I7	Free


**Solution:**



**Boundary conditions:**

- ◆ Setpoint position of the registration mark: 90°.
- ◆ Slave standstill at 180°.
- ◆ The object C3Cam.StatusMaster\_PositionCamUnits (o3030.24) is used as source for the C3\_Touchprobe module and is set against the reg setpoint position.
- ◆ The adjustment movement is made via MC\_Phasing (see the **signal image** (see page 225) of the cam).

**curve**



**5.10.9.9 Example case of damage**

The axis should work in curve mode.

The master should be stopped in the case of an axis error. After the elimination and acknowledgement of the error, the axis shall synchronize and normal operation shall be resumed.


**Corresponding files:** CamExampleHav.C3P (Compax3 Project on the Compax3  
CD:\Examples\Examples\_Haverie)  
CamExampleHav.pro (CoDeSys Project on the Compax3  
CD:\Examples\Examples\_Haverie)

**Control interface:**

Input	Function
I0	Energize axis
I1	Enable and start of the master position detection
I2	Start of the curve cycle
I3	Coupling / Decoupling
I4	Free
I5	Clear Error
I6	Homing
I7	Start of the virtual master



**Solution:**




**Boundary conditions:**

- ◆ The ReadStatus module helps detect, if the axis is in the error state.  
An error will trigger the stop of the virtual axis, the curve cycle will stop, the curve generator (C3\_CamTableSelect) will continue.
- ◆ After the stop of the master, the axis will also be at a standstill.
- ◆ The error is acknowledged via input I5; the axis will be energized again (see also the "AND" module at the input of MC\_Power).
- ◆ If the axis is energized again and input I5 is present, the axis is moved to the current position of the curve output (MC\_moveAbsolute) and at the end of the movement it is coupled again with MC\_CamIn.
- ◆ The output "InSync" of the MC\_CamIn (camin2) will re-start the virtual master and the cycle is continued.

**5.10.9.10 Application note: Drift**

Correct scaling of the reference values helps prevent drift.

For this, it is necessary to consider the conversions of the position signal:



Master / Slave / Load revolution: Master / Slave / Load revolutions:

Master / Slave units: Master / Slave - revolutions

Gear box: Gearbox

The rule for this is:

$$Z1 = \frac{\text{Travel distance per revolution master axis}}{\text{numerator}}$$

$$N1 = \frac{\text{Travel distance per motor revolution master axis}}{\text{denominator}}$$

(configured in the Compax3 ServoManager under "signal source")

$$Z2 = \frac{\text{Travel distance per revolution slave axis}}{\text{numerator}}$$

$$N2 = \frac{\text{Travel distance per revolution - Slave axis}}{\text{Denominator}}$$

(configured in the Compax3 ServoManager under "configuration")

$$\frac{Z3}{N3} = \frac{\text{transmission ratio}}{\text{Motor Load}}$$

MT: Master clock distance

"Position Reset" Distance - Master Axis (M\_Units)

"Position Reset" Distance - Master Axis (Denominator)

MT is rounded to 3 decimal places.

ST: Slave clock distance

**Numerical Example:**

Product: 314,871 long

14 products are to be transported per load revolution via a curve.

Gearbox: Motor/Load = 6949673 / 43890 => i = 158.3429...

**1. Variant (with drift)**

Load revolutions = (number of the products) \* (length of a product) \* (reciprocal of the travel path per motor revolution slave axis) \* (gearbox load / motor)

$$\text{Load revolutions} = 14 * 314.871\text{mm} * \frac{N2}{Z2} * \frac{43890}{6949673}$$

$$14 * 314,871\text{mm} * \frac{43890}{6949673} = \frac{Z2}{N2} = \frac{193475634,66}{6949673}$$

This factor can not be expressed exactly in Compax3; the max. entry allowed in the Compax3 ServoManager:

1934756

---

69496

which causes drift.

**2. Variant (without drift)**

Slave clock distance = 1 product cycle

For this, the curve is created scaled to 1.

$$\text{Load revolutions} = 14 * 1\text{mm} * \frac{N2}{Z2} * \frac{43890}{6949673}$$

$$14 * 1\text{mm} * \frac{43890}{6949673} = \frac{Z2}{N2} = \frac{614460}{6949673}$$

This factor for the path per motor revolution can be expressed, no drift is generated!

## 5.11 Cam switching mechanism

### In this chapter you can read about:

Cam switching mechanism function overview .....	288
Redirect the fast cams directly to the physical output (C3_OutputSelect) .....	291
Objects of the cam switching mechanism .....	292
Behavior of the switch-on/switch-off anticipation.....	293
Hysteresis.....	296
CoDeSys-Project for the configuration of the cams .....	297
Example: Working with fast cams .....	298

Please observe:

In the C3 powerPLmC, the "cam switching mechanism" function can only be programmed for a Compax3 slave axis with the T40 technology function.

### 5.11.1. Cam switching mechanism function overview

#### In this chapter you can read about:

Example of cam function .....	289
Examples of a cam cycle.....	289

Up to 36 cams can be programmed. They are divided into 2 cam types:

#### **Serial cams**

- ◆ 32 serial cams (Cam 0 ... 31) of which a cam is brought up once every 0.5 ms. The **cycle time** of the cams is: **((Highest active serial cam +1) \* 0.5ms..**  
Example: if cam 17 is the highest cam enabled, this results in a cycle time of:  $18 * 0.5\text{ms} = 9\text{ms}$
- ◆ If no fast cams are used, the number of the serial cams per cycle (0.5ms) can be increased up to 4:  
The setting is made via object 3701.6. It applies:  
Cycle time = number of the serial cams \* 0.5ms / O3701.6 with the value range O3701.6 = 1, 2, 3, 4.

#### **Fast cams**


- ◆ 4 fast cams with a cycle time of 500µs (125µs per cam).
- ◆ When using fast cams, there is a cycle time of 0.5ms per cam for serial cams.
- ◆ With the **C3\_OutputSelect** (see page 291) module the fast cams can be put directly and without delay, independently of the cycle time of the IEC program, on the digital outputs O0 ...O3.

#### **Cam functions**

- ◆ Switching-on and switching-off position of each cam individually.
- ◆ Cams with compensation for dead time, with switching-on and switching-off anticipation for each cam.
- ◆ Individually adjustable cam source.
- ◆ Enable for each individual cam.
- ◆ Adjustable switching hysteresis for actual position value as a cam source.
- ◆ The outputs of the cams are objects.

**5.11.1.1 Example of cam function**


**Example of cam function (without switching-on and switching-off anticipation)**



**5.11.1.2 Examples of a cam cycle**

**Example 1: Working cycles for:**


- ◆ 3 fast cams and
- ◆ 3 serial cams



- 1: Serial cams
- 2: Fast cams


**Example 2: Working cycles for:**

- ◆ no fast cams,
- ◆ 8 serial cams and
- ◆ reduced cycle time (object O3701.6 = 3)



**Example 3: Working cycles for:**


- ◆ no fast cams,
- ◆ 8 serial cams and
- ◆ reduced cycle time (object O3701.6 = 4)



### 5.11.2. Redirect the fast cams directly to the physical output (C3\_OutputSelect)

<b>FB name</b>	<b>C3_OutputSelect</b>	
Select source for digital outputs		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activates the module with a rising edge
<b>O0</b>	INT	Constant for source for the digital output 0
<b>O1</b>	INT	Constant for source for the digital output 1
<b>O2</b>	INT	Constant for source for the digital output 2
<b>O3</b>	INT	Constant for source for the digital output 3
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Source selection executed
<b>Note:</b>		
<ul style="list-style-type: none"> <li>◆ The source selection for the outputs is executed with a rising edge of Execute.</li> <li>◆ <b>Application for fast cams:</b> the fast cams are put directly and without delay to the digital outputs, independent of the cycle time of the IEC program.</li> <li>◆ OutputSelect_C3Output allows to access the respective output directly via the IEC program (e.g. with the aid of C3_Output).</li> <li>◆ OutputSelect_FastCamSwitch puts the respective fast cam to the output. The assignment is fixed, i.e. cam 0 would be put on O0, cam 1 would be put on output O1, etc.</li> </ul>		

**Example:**



- ◆ Source: output 0: C3\_Output
- ◆ Source output 1: Fast cam 1
- ◆ Source output 2: Fast cam 2
- ◆ Source output 3: C3\_Output

### 5.11.3. Objects of the cam switching mechanism

Object designations	Units	Objects for serial cams	Objects for fast cams	Valid after:
<b>Source</b> ="1": Actual position ="2": Setpoint position ="3": virtual Master ="5": Master position (3030.1)		Cam 0: O3730.1 ... Cam 31: O3761.1	Cam 0: O3710.1 ... Cam 3: O3713.1	VP*
<b>Switching-on position</b>	defined unit for positions	Cam 0: O3730.2 ... Cam 31: O3761.2	Cam 0: O3710.2 ... Cam 3: O3713.2	VP*
<b>Switching-off position</b>	defined unit for positions	Cam 0: O3730.3 ... Cam 31: O3761.3	Cam 0: O3710.3 ... Cam 3: O3713.3	VP*
<b>Switch-on anticipation</b>	1 ≙ 500µs	Cam 0: O3730.4 ... Cam 31: O3761.4	Cam 0: O3710.4 ... Cam 3: O3713.4	Immediately
<b>Switch-off anticipation</b>	1 ≙ 500µs	Cam 0: O3730.5 ... Cam 31: O3761.5	Cam 0: O3710.5 ... Cam 3: O3713.5	Immediately
<b>Output</b> (the given object bit contains the cam switch status for further use)		Cam 0: O3701.3 Bit 0 ... Cam 15 O3701.3 Bit15 Cam 16 O3701.5 Bit 0 ... Cam 31: O3701.5 Bit15	Cam 0: O3700.3 Bit 0 ... Cam 3: O3700.3 Bit 3	Immediately
<b>Enable</b>		Cam 0: O3701.2 Bit 0 ... Cam 15 O3701.2 Bit15 Cam 16 O3701.4 Bit 0 ... Cam 31: O3701.4 Bit15	Cam 0: O3700.2 Bit 0 ... Cam 3: O3700.2 Bit 3	Immediately
<b>Hysteresis</b>	defined unit for positions	With source = actual position: O3705.1 With source = Master position: O3705.5		VP*

The exact description of the objects can be found in the **object directory** (see page 414).

The command VP (set objects to valid) can be executed as


- ◆ global VP – for all objects or
- ◆ selective VP – only objects of the cam switching mechanism -

- ◆ Global VP: Write into object 210.11 with value <> 0
- ◆ Selective VP: Write into object 210.9 with value <> 0  
(C3Plus.ValidParameter\_CamControlledSwitches:=True)

The selective VP is executed faster and constitutes a smaller temporal strain!

#### Scheme of the object assignment example of the serial cam 0






**Notes:**

- ◆ You can write directly into a serial cam switch output that is not enabled (e.g. cam 0 => object3701.3 bit 0).
- ◆ After deactivating the cam, the last output status is kept. You can then define the status by directly writing into the object.

**5.11.4. Behavior of the switch-on/switch-off anticipation**


The switching-on and switching-off behavior of the actuating elements (delayed switching, reaction time) can be compensated via a reaction time (switching-on/off anticipation) that can be parametered for each individual cam. Compax3 will calculate a corrected switching-on/ or –off position by multiplying the reaction time with the current speed, so that the actuating element will switch at the actual switching position due to its delay; the actuating element delay is compensated.

**5.11.4.1 Behavior depending on the travel direction**




For the switching behavior depending on the position applies therefore:

**Example: switching behavior at positive speed (speed>0)**



- SwitchOn: Switching-on position
- SwitchOn\*: corrected switching-on position
- SwitchOff: Switching-off position
- SwitchOff\*: corrected switching-off position
- Pos\_tOn: position difference calculated from the switch-on anticipation
- Pos\_tOff: position difference calculated from the switch-off anticipation

**Example: switching behavior at negative speed (speed<0)**




- SwitchOn: Switching-on position
- SwitchOn\*: corrected switching-on position
- SwitchOff: Switching-off position
- SwitchOff\*: corrected switching-off position
- Pos\_tOn: position difference calculated from the switch-on anticipation
- Pos\_tOff: position difference calculated from the switch-off anticipation

- N.B.!** The switching-on resp. switching-off anticipation are exchanged with negative speed, as the cam
- ◆ switches on at the switching-off position and
  - ◆ switches off at the switching-on position!

**5.11.4.2 Switching behavior with reset operation**

When leaving the positioning area, the positions are corrected accordingly. The switching-off position may be smaller than the switching-on position:




- SwitchOn: Switching-on position
- SwitchOn\*: corrected switching-on position
- SwitchOff: Switching-off position
- SwitchOff\*: corrected switching-off position
- tOn: Switch-on anticipation
- tOff: Switch-off anticipation

**Note:** With reset mode of the selected source, the switching position is limited to the area:  
 $0 \leq \text{switching position} < \text{reset path}$

That means that values below zero will become 0, values higher than the reset distance will become the reset distance-1LSB.


**5.11.4.3 Switch-on anticipation is corrected via reset distance**



SwitchOn: Switching-on position  
 SwitchOn\*: corrected switching-on position  
 SwitchOff: Switching-off position  
 SwitchOff\*: corrected switching-off position  
 tOn: Switch-on anticipation  
 tOff: Switch-off anticipation  
 For cam\_1 and \_2

**5.11.4.4 Note: No switching operation with overlapping cams**

If it occurs that for example the switching-off position is smaller than the switching-on position due to a movement caused by the reaction time compensation, no switching will take place. This case must be eliminated by choosing appropriate cam positions.




SwitchOn: Switching-on position  
 SwitchOn\*: corrected switching-on position  
 SwitchOff: Switching-off position  
 SwitchOff\*: corrected switching-off position  
 Pos\_tOn: position difference calculated from the switch-on anticipation  
 Pos\_tOff: position difference calculated from the switch-off anticipation

**Please observe:**

The position difference for the compensation of the switching delay rises with the speed.

**5.11.5. Hysteresis**

In order to avoid jitter of cams at the limits of the switching area (only relevant as source of cam with actual values) a switching hysteresis (the same for all cams) can be defined.



SwitchOn: Switching-on position  
SwitchOn\*: switching-on position corrected by the hysteresis  
SwitchOff: Switching-off position  
SwitchOff\*: switching-off position corrected by the hysteresis  
The hysteresis is preset as a position value.

**Please observe:** The hysteresis influences the switching-on and switching-off anticipation  
You should therefore set this value at the lowest possible level.

### 5.11.6. CoDeSys-Project for the configuration of the cams

You will find a CoDeSys project for the configuration of the cams with the following functions on the Compax3 CD under  
..\Examples\CamSwitch\CamSwitch\_Template.pro:  
Configuration of the cam switching mechanism via IEC61131-3 in ST (structured text):

#### 1.) Initializing some "example cams" (Module "Init Cam Switch")

- ◆ Configuration of sequential cams,
- ◆ Configuration of fast cams,
- ◆ Configuration of the hystereses,
- ◆ Activation of (fast) cams,
- ◆ Resetting outputs,
- ◆ Triggering selective VP

**Global variables determine, which functions are used or are relevant:**

CAMsourceActual - True: Actual position is used as master source  
CAMfast - True: fast cams are being used  
CAMnumber\_per\_cycle - 1..4: Number of cams implemented/500µs)

#### 2.) Use of the cams in the IEC (Module "PLC PRG")

- ◆ Execute module "Init\_Cam\_Switch" once,
- ◆ logic query with cams,
- ◆ logic combination with cams,
- ◆ Output of cams via digital outputs,
- ◆ Deactivating individual cams,
- ◆ Manipulating deactivated cams


### 5.11.7. Example: Working with fast cams

Setting 2 fast cams to the Compax3 outputs O2 and O3.

- Related programs:**
- ◆ ..\Examples\CamSwitch\2\_schnelle\_Nocken.C3P
  - ◆ \Examples\CamSwitch\2\_schnelle\_Nocken.pro

- Assignment:**
- O0 = 1: Drive energized
  - O1 = 1: Machine zero approached
  - O2 = 1 fast cam 2 (170° ... 190°)
  - O3 = 1 fast cam 3 (290° ... 310°)
  - I0: Energize Drive
  - I1: Start searching machine zero
  - I2: Start of a 360° positioning (reset distance = 360°)

**Solution:**



## ST Part

```

0001 FUNCTION_BLOCK Konfig_Fast_Nocken
0002 VAR_INPUT
0003 END_VAR
0004 VAR_OUTPUT
0005 END_VAR
0006 VAR
0007     vari1: BOOL;
0008 END_VAR
0009
0001 (* Settings for 2 Fast CAM_switches CAM_Fast 2 and 3 set to Output O2 and O3 *)
0002
0003 IF vari1=FALSE THEN
0004     C3Cam.ControlledSwitchesFast_Enable:=12; (*enable Cam_switch2 and 3*)
0005
0006     C3Cam.ControlledSwitchFast2_Source:=1; (* actual position *)
0007     C3Cam.ControlledSwitchFast2_PositionOn:=170;
0008     C3Cam.ControlledSwitchFast2_PositionOff:=190;
0009     C3Cam.ControlledSwitchFast2_TimeOn:=T#0s; (* without TimeOn time *)
0010     C3Cam.ControlledSwitchFast2_TimeOff:=T#0s; (* without TimeOff time *)
0011
0012     C3Cam.ControlledSwitchFast3_Source:=1; (* actual position *)
0013     C3Cam.ControlledSwitchFast3_PositionOn:=290;
0014     C3Cam.ControlledSwitchFast3_PositionOff:=310;
0015     C3Cam.ControlledSwitchFast3_TimeOn:=T#0s; (* without TimeOn time *)
0016     C3Cam.ControlledSwitchFast3_TimeOff:=T#0s; (* without TimeOff time *)
0017
0018     C3Cam.ControlledSwitchesHysteresis_ActualPosition:=1;
0019
0020     C3Plus.ValidParameter_CamControlledSwitches:=1; (* one time, after Power ON *)
0021     vari1:=TRUE;
0022 END_IF

```

**Note:**

- ◆ With C3\_OutputSelect the outputs O2 and O3 are assigned to the fast cams. Compax3 puts automatically the fast cams 2 and 3 to the outputs O2 and O3.
- ◆ The cam objects are set once after switching-on.


## 5.12 Error handling

**In this chapter you can read about:**

Acknowledging errors (MC\_Reset)..... 300  
 Reading axis errors (MC\_ReadAxisError)..... 301  
 Set error reaction (C3\_SetErrorReaction)..... 302

### 5.12.1. Acknowledging errors (MC\_Reset)

<b>FB name</b>	<b>MC_Reset</b>	
Acknowledges errors (transition from "Errorstop" status to "Standstill" status).		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activates the module if there is a positive edge
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Error successfully acknowledged, axis is in the "Standstill" state again
<b>Error</b>	BOOL	Acknowledge failed /not possible
<b>ErrorID</b>	WORD	Error description, according to error history
<p><b>Note:</b>                  After the error is successfully acknowledged, the power must be supplied to the power output stage again by a rising edge on the enable input of the MC_Power power module.                  C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group.</p>		



Autoryzowany dystrybutor Parker:


**ARA**  
**PNEUMATIK**  
 53-012 Wrocław tel. 71 364 72 82  
 ul. Wyścigowa 38 fax 71 364 72 83  
[www.arapneumatik.pl](http://www.arapneumatik.pl)






**5.12.2. Reading axis errors (MC\_ReadAxisError)**

<b>FB name</b>	<b>MC_ReadAxisError</b>	
This function module displays axis errors.		
<b>VAR_IN_OUT</b>		
<b>Axis</b>	INT	Axis-ID (library constants)
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activates the module
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Output values available
<b>Error</b>	BOOL	Compax3 in error state
<b>ErrorID</b>	WORD	Current error description
Note: -		



**5.12.3. Set error reaction (C3\_SetErrorReaction)**

<b>FB name</b>	<b>C3_SetErrorReaction</b>	
This module is used to define the error reaction. Note: The error reaction cannot be changed for errors with standard reaction 5 (switch immediately to currentless (without ramp), close brake).		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	The defined error reaction is set for the selected error
<b>ErrorID</b>	WORD	Error number [hexadecimal] for which the error reaction should be set, e.g. 0x6281
<b>Reaction</b>	INT	Error response: 0: no reaction, error is deactivated. 1: Downramp actual speed; remain in position control state 2: Downramp the actual speed; then switch off controller
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	The defined error reaction was set
<b>Error</b>	BOOL	Error while executing module
<b>Note:</b> <b>Error list</b> <ul style="list-style-type: none"> <li>◆ The error reaction settings from the configuration wizard are overwritten.</li> <li>◆ The setting of the error mask is made internally via a C3 object. If the objects are saved permanently, the setting is memorised after Power off.</li> </ul> <b>Please note:</b> <ul style="list-style-type: none"> <li>◆ The C3_ErrorMask overwrites (depending on the calling-up order) the settings.</li> <li>◆ The corresponding error reaction is valid for both axes (of Compax3F) as the case may be.</li> <li>◆ The module will overwrite the settings made via the C3 ServoManager.</li> <li>◆ If the ErrorID has an invalid error number, no change is effected.</li> </ul>		




## 5.13 Process image

**In this chapter you can read about:**

Reading digital inputs (C3_Input).....	303
Write digital outputs (C3_Output).....	303
Reading/writing optional inputs/outputs.....	304
Memorizing the signals with the trigger event (C3_TouchProbe).....	306
Integration of Parker I/Os (PIOs).....	309


### 5.13.1. Reading digital inputs (C3\_Input)

<b>FB name</b>	<b>C3_Input</b>	
Used to generate a process image of the digital inputs.		
<b>VAR_INPUT</b>		
<b>I0 ... I7</b>	BOOL	Displays the logic status of the respective input (with low active inputs, the physical statuses are negated).
Notes: the module should always be brought up at the beginning of the processing cycle.		



### 5.13.2. Write digital outputs (C3\_Output)

<b>FB name</b>	<b>C3_Output</b>	
Used to generate a process image of the digital outputs.		
<b>VAR_OUTPUT</b>		
<b>O0 ... O3</b>	BOOL	Displays the status of the respective output.
Notes: the module should always be brought up at the end of the processing cycle.		




### 5.13.3. Reading/writing optional inputs/outputs

In this chapter you can read about:

C3_IOAddition_0 .....	304
C3_IOAddition_1 .....	304
C3_IOAddition_2 .....	305


#### 5.13.3.1 C3\_IOAddition\_0

FB name		C3_IOAddition_0
Is used to create a process image of the optional digital inputs/outputs.		
<b>VAR_INPUT</b>		
I0 ... I3	BOOL	Displays the status of the respective input.
O0 ... O3	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned <b>as inputs or as outputs</b> (see page 447). You may only use either inputs or outputs exclusively. Notes: The module should always be brought up at the beginning (inputs) or end (outputs) of the processing cycle.		




#### 5.13.3.2 C3\_IOAddition\_1

FB name		C3_IOAddition_1
Is used to create a process image of the optional digital inputs/outputs.		
<b>VAR_INPUT</b>		
I4 ... I7	BOOL	Displays the status of the respective input.
O4 ... O7	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned <b>as inputs or as outputs</b> (see page 447). You may only use either inputs or outputs exclusively. Notes: the module should always be brought up at the beginning of the processing cycle.		




**5.13.3.3 C3\_IOAddition\_2**

<b>FB name</b>	<b>C3_IOAddition_2</b>	
Is used to create a process image of the optional digital inputs/outputs.		
<b>VAR_INPUT</b>		
<b>I8 ... I11</b>	BOOL	Displays the status of the respective input.
<b>O8 ... O11</b>	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned <b>as inputs or as outputs</b> (see page 447). You may only use either inputs or outputs exclusively. Notes: the module should always be brought up at the beginning of the processing cycle.		




### 5.13.4. Memorizing the signals with the trigger event (C3\_TouchProbe)

FB name	C3_TouchProbe	
Memorizing signals / objects with the trigger event - replaces the MC_TouchProbe module -		
<b>VAR_IN_OUT</b>		
Axis	INT	Axis ID (Library constants)
<b>VAR_INPUT</b>		
Execute	BOOL	Activates the module if there is a rising edge
SignalSource	Pointer	Selects the signal to be scanned. The <address operator> must be used imperatively. The signal scanned must be in the REAL or the INT format.
FallingEdge	BOOL	If TRUE, it is triggered in the falling edge. The logical status after a possible input inversion is respected.
TriggerInput	INT	Selects the trigger input. Constant TouchProbeInputx (see note)
ExpectedValue	REAL	Value at which the trigger event is expected.
Tolerance	REAL	Tolerance interval around ExpectedValue, where the trigger event is accepted (always positive) (with reference to the signal source).
StartIgnore	REAL	The beginning of the range in which the trigger event will not be acknowledged with Done or Error (with reference to the signal source).
StopIgnore	REAL	The end of the range in which the trigger event will not be acknowledged with Done or Error (with reference to the signal source).
EnableIgnoreZone	BOOL	Activate IgnoreZone.
Abort	BOOL	Deactivate module.
<b>VAR_OUTPUT</b>		
Done	BOOL	Trigger event occurred within the tolerance interval and the signal was detected.
RecordedSignal_ Real	REAL	Value scanned at the time of the trigger event, if the source is available in the coDeSys "REAL" format. Please respect the format information of the signal source (SignalSource)
RecordedSignal_ INT	INT	Value scanned at the time of the trigger event, if the source is available in the coDeSys "INT" format. Please respect the format information of the signal source (SignalSource)
Busy	BOOL	Module active and no scanning signal occurred outside the IgnoreZone.
Error	BOOL	Error while executing module.
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>◆ Temporal precision of signal recording: &lt;math&gt;&lt;1\mu\text{s}&lt;/math&gt;</li> <li>◆ TriggerInput Trigger-input: via the constants "TouchProbeInput0" ... "TouchProbeInput7" (X12/6 - X12/14) the trigger signal input is selected.</li> <li>◆ <b>Attention!</b> <b>Max. one entity of the module can be active</b> as the hardware resources are only available once! Several entities being activated one after the other are permitted.</li> </ul>		



Example: Scanning the actual position, triggered via Input I0



- 1: Area where a **module error** is generated.
  - 2: Ignore Zone: Area where **no module error** and **no Done** is generated. The ranges 2 and 3 may not overlap. If they do, the ignore zone in range 3 is not effective.
  - 3: ExpectedValueZone: Trigger signal in the permissible value range; this is confirmed with Done=TRUE.
  - 4: RecordedSignal; is updated with every active edge of the TriggerInput signal upon Execute = TRUE.
- 
- ◆ If the value of the signal (SignalSource) during the Trigger event is in the permissible value range between (ExpectedValue - Tolerance) and (ExpectedValue + Tolerance), this is confirmed with Done = TRUE; the RecordedSignal is updated.
  - ◆ If the value of the signal (SignalSource) during the Trigger Event is between StartIgnore and StopIgnore (Ignore zone), the module will report neither error nor Done, the RecordedSignal is however updated.
  - ◆ If the value of the signal (SignalSource) during the Trigger Event is outside the permissible value range and outside the zone between StartIgnore and StopIgnore (Ignore zone), the module will report an error, the RecordedSignal is updated.
  - ◆ Within this range, the signals are read in with a temporal exactitude of <math><1\mu\text{s}</math> (determined by linear interpolation).
  - ◆ If a Trigger Signal occurs at Execute = False, the RecordedSignal is not updated.
  - ◆ If **no** Trigger Signal comes up, Busy remains active until the module is reset to the original state with Abort.
  - ◆ More examples with C3\_Touchprobe (**example 7** (see page 279) and **example 8** (see page 281)).



### 5.13.5. Integration of Parker I/Os (PIOs)


**In this chapter you can read about:**

Initializing the PIOs (PIO\_Init) ..... 309  
 Reading the PIO inputs 0-15 (PIO\_Inputx...y) ..... 310  
 Writing the PIO outputs 0-15 (PIO\_Outputx...y) ..... 311  
 Example: Compax3 as CANopen Master with PIOs ..... 312

In order to integrate PIOs via CANopen, the CANopen operating mode "**Master for PIOs**" (see page 368, see page 367)" must be configured.


#### 5.13.5.1 Initializing the PIOs (PIO\_Init)

FB name	PIO_Init	
Initialization of the PIOs		
<b>VAR_IN_OUT</b>		
<b>Device</b>	INT	PIO - ID (Address)
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activates the module if there is a positive edge
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Initialization executed
<b>Error</b>	BOOL	An error occurred during initialization
<b>ErrorCode</b>	WORD	1 = no Parker device Additional errors can be found in the error list.
<b>AbortCode</b>	DWORD	<b>SDO abort code</b> (see page 383)
Note: Please execute this module at the beginning of the IEC program.		




**5.13.5.2 Reading the PIO inputs 0-15 (PIO\_Inputx...y)**

<b>FB name</b>	<b>PIO_Input0_15</b>	
Is used for reading the respective inputs		
<b>VAR_INPUT</b>		
<b>I0 ... I15</b>	BOOL	Displays the status of the respective input.
Note: For the additional inputs, the following modules are available PIO_Input16_31 PIO_Input32_47and PIO_Input48_63. Please execute this module at the beginning of the IEC program (After PIO_INIT).		



**5.13.5.3 Writing the PIO outputs 0-15 (PIO\_Outputx...y)**

<b>FB name</b>	<b>PIO_Output0_15</b>	
Is used for writing on the respective outputs		
<b>VAR_INPUT</b>		
<b>O0 ... O15</b>	BOOL	Displays the status of the respective output.
Note: For the additional outputs, the following modules are available PIO_Output16_31 PIO_Output32_47and PIO_Output48_63. Please execute this module at the end of the IEC program.		



### 5.13.5.4 Example: Compax3 as CANopen Master with PIOs

- ◆ Compax3 control via PIOs.
- ◆ Configuration of the PIO connection with the C3 ServoManager.
- ◆ Initializing the PIO connection with the PIO\_Init module
- ◆ Control of Compax3 via the digital PIOs and
- ◆ setpoint assignment via the analog PIOs

#### Related programs:

- ◆ ..\Examples\C3\_mit\_PIOs\T30\_MasterPIO\_ID2.C3P
- ◆ ..\Examples\C3\_mit\_PIOs\C3\_PIO\_CONNECTION\_TEST.pro

#### Test setup:

- A PIO-347 for CANopen with:
- ◆ 1 PIO-602 (24V DC feed)
  - ◆ 2 PIO-402 (8 digital inputs) for operation wired to a switch box
  - ◆ 6 PIO-504 (24 digital outputs)
  - ◆ 1 PIO-468 (4 analog inputs)
  - ◆ 1 PIO-550 (2 analog outputs) analog output 0 is wired with analog input 0 for setpoint definition
  - ◆ 1 PIO-600 (Bus terminal)
  - ◆ a 24V power supply unit
  - ◆ a C3 S025 F10 I21 T30 M11 with power- and 24V-cable
  - ◆ a motor SMH 60 60 1,4...4 with motor- and resolver cable
  - ◆ a CAN-bus cable for the connection of the Compax3 with the PIO coupler.
  - ◆ a serial cable for the connection of the Compax3 with the PC
  - ◆ a switch box for the operation of the 8 digital inputs of the PIOs.

#### Settings:

- ◆ Baud rate = 1Mbit
- ◆ Node address of the PIO = 5 (setting via the address switch on the device)
- ◆ Node address of the C3 = 2 (setting via the address switch on the device)

#### Control interface:


Digital input	Function	Digital output	Function
0	Energize axis	0	Axis is energized
1	Travel to MN (home)	1	MN (home) is accessed
2	Start MoveVelocity	2	Setpoint speed reached
3	Stop	3	Stop is present
4	JOG +	4	Manual function active
5	JOG -	5	MoveVelocity aborted
6	Free	6	Global module error display
7	Error reset	7	Error is present
Analog input		Analog output	
0	Setpoint speed		Setpoint speed specification

#### Additional Compax3 settings:

- ◆ Array\_Col03\_Row01=1; activates the PIO\_Init module
- ◆ Array\_Col03\_Row02=5; address of the PIO
- ◆ Array\_Col03\_Row03=10; Specification for analog output0 => setpoint speed specification

If these values are stored in the Compax3, the PIO will be automatically initialized after Power On and started for PDO data exchange with Compax3.

Solution:



## 5.14 Interface to C3 powerPLmC

### In this chapter you can read about:

Interface module "PLmC_Interface" .....	315
Cyclic data channel for C3T30 and C3T40 .....	317
Example: C3 powerPLmC Program & Compax3 Program.....	319

### 5.14.1. Interface module "PLmC\_Interface"

The interface between a central IEC61131-3 user program on C3 powerPLmC and a local IEC61131-3 user program on a Compax3 servo axis T30 or T40 is created with the program module "PLmC\_interface".

**The " PLmC\_Interface" module must be called up in each Compax3 T30 which is operated as a slave on a C3 powerPLmC.**

**With Compax3 T40 this is only necessary, if the slave axis is programmed directly (not with operating mode: "Slave on C3 powerPLmC (Cam programming on C3 powerPLmC)")**


**The call-up must take place cyclically!**

The module can be found in the "C3\_PLmC\_interface.lib" library, which must be integrated manually via the library manager, if required.

FB name	PLmC_Interface	
Interface module for the control of C3 powerPLmC		
<b>VAR_OUTPUT</b>		
<b>O0</b>	BOOL	Status of the digital output O0 on the C3 powerPLmC side
<b>O1</b>	BOOL	Status of the digital output O1 on the C3 powerPLmC side
<b>O2</b>	BOOL	Status of the digital output O2 on the C3 powerPLmC side
<b>O3</b>	BOOL	Status of the digital output O3 on the C3 powerPLmC side
<b>LocalEnable</b>	BOOL	Enable for the local IEC61131-3 program LocalEnable switches to FALSE for one cycle, if a command for this axis is activated on the C3 powerPLmC. This helps to avoid that the axis will receive different commands at a time.
<b>Event1 ... Event8</b>		Reserved
<b>EventParameter</b>		Reserved
<b>Note:</b>		
<ul style="list-style-type: none"> <li>◆ The execution of all local motion functions should be coupled with the LocalEnable output.</li> <li>◆ Via the outputs O0...O3, the outputs set by C3 powerPLmC can be set out via the physical outputs with the aid of C3_Output.</li> </ul>		

**Recipe array line  
17... 32 assigned**

Please note that the last 16 lines of the recipe array (C3Array.ColXX\_Row17 to C3Array.ColXX\_Row32) are reserved for the communication with C3 powerPLmC.





## 5.14.2. Cyclic data channel for C3T30 and C3T40

An additional communication channel (besides the one established by the Drive Interface which is not freely assignable) can be established between the programs of the C3 powerPLmC and a Compax3 axis via a freely usable cyclic data channel. To do this, the assignment of the channel is defined on the side of the C3 powerPLmC in the controller configuration for the respective axis. The assignment is always bidirectional.

The following options are available for the communication between the two programs.

### 2x INT:

#### Assignment of the cyclic channel with 2 INT variables

##### Mapping to Compax3 objects

C3.PLmCToC3_INT1 / C3.PLmCToC3_INT2	from PLmC to Compax3
C3.C3ToPLmC_INT1 / C3.C3ToPLmC_INT2	from Compax3 to PLmC

##### Mapping to power PLmC variables

"Axis name".PLmCToC3_INT1	from PLmC to Compax3
"Axis name".PLmCToC3_INT2	from PLmC to Compax3
"Axis name".C3ToPLmC_INT1	from Compax3 to PLmC
"Axis name".C3ToPLmC_INT2	from Compax3 to PLmC

### 1x DINT:

#### Assignment of the cyclic channel with one DINT variable

##### Mapping to Compax3 objects

C3.PLmCToC3_DINT	from PLmC to Compax3
C3.C3ToPLmC_DINT	from Compax3 to PLmC

##### Mapping to power PLmC variables

Axis name".PLmCToC3_DINT	from PLmC to Compax3
"Axis name".C3ToPLmC_DINT	from Compax3 to PLmC

### 1x REAL:

#### Assignment of the cyclic channel with one REAL variable

##### Mapping to Compax3 objects


C3.PLmCToC3_REAL	from PLmC to Compax3
C3.C3ToPLmC_REAL	from Compax3 to PLmC

##### Mapping to power PLmC variables

"Axis name".PLmCToC3_REAL	from PLmC to Compax3
"Axis name".C3ToPLmC_REAL	from Compax3 to PLmC

**Note:** The use of INT or DINT variables is especially suitable for implementing a user-defined control word / status word between C3 powerPLmC IEC61131-3 program and Compax3 IEC61131-3 program.

#### Configuration of the data channel



**Note:** If the cyclic data channel is not required, it can also be assigned to the actual position of the axis. This is then provided by the "**MC\_ReadActualPosition** (see page 170)" module. Therefore the value must not be continually read via the acyclic channel if the module is used; this reduces the bus load and the IEC cycle time.


### 5.14.3. Example: C3 powerPLmC Program & Compax3 Program

- Task:**
- ◆ Implementation of a mark synchronization in a Compaxa3 servo axis.
  - ◆ Control of the program via the C3 powerPLmC via a user-defined control word / status word.

#### Main program on Compax3 (module PLC\_PRG)

#### Cyclic call-up of the interface to powerPLmC in the PLC\_PRG module

In CFC:



In ST:

```

0001 PROGRAM PLC_PRG
0002 VAR
0003   Outputs : C3_Output;
0004 END_VAR
0005
0001 PLmC_Interface(O0=>Outputs.O0,O1=>Outputs.O1,O2=>Outputs.O2,O3=>Outputs.O3);
0002 Outputs();
0003 IF PLmC_Interface.LocalEnable THEN
0004   LocalProgram();
0005 END_IF
0006


```

Local Compax3 Program in the LocalProgram module

```

1001 PROGRAM LocalProgram
1002 VAR
1003   TP: C3_TouchProbe;
1004   POSA: MC_MoveAbsolute;
1005 END_VAR

```



## Program on C3 powerPLmC

```

0001 PROGRAM PLC_PRG
0002 VAR
0003     Inputs : C3_Input;
0004     Power : MC_Power;
0005     MoveAbs : MC_MoveAbsolute;
0006     Status : MC_ReadStatus;
0007     TouchProbeDone: BOOL;
0008 END_VAR
0009
0010 DriveExecuteStart(ADR(Compax3_Group));
0011
0012 Inputs(Axis := Axis1);
0013 Status(Axis := Axis1);
0014
0015 IF (Inputs.I0 AND NOT Inputs.I3) THEN
0016     Power.Enable := TRUE;
0017 ELSE
0018     Power.Enable := FALSE;
0019 END_IF
0020
0021 IF (Inputs.I4) THEN
0022     MoveAbs.Position := Position1;
0023     MoveAbs.Velocity := Velocity1;
0024     MoveAbs.Acceleration := 100;
0025     MoveAbs.Deceleration := 100;
0026     MoveAbs.Jerk := 10000;
0027     MoveAbs.JerkDecel := 10000;
0028     MoveAbs.Execute := TRUE;
0029 END_IF
0030
0031 IF (Inputs.I4 AND Status.DiscreteMotion) THEN
0032     (* set control bit to start C3_TouchProbe in local program *)
0033     Axis1.PLmCtoC3_INT1.1 := TRUE;
0034 END_IF
0035
0036 IF (Axis1.C3ToPLmC_INT1.0) THEN
0037     (* C3_TouchProbe in local program is done *)
0038     TouchProbeDone := TRUE;
0039 END_IF
0040
0041 Power(Axis := Axis1);
0042 MoveAbs(Axis := Axis1);
0043
0044 DriveExecuteEnd(ADR(Compax3_Group));
0045

```


## 5.15 IEC examples

**In this chapter you can read about:**

Example in CFC: Using Compax3-specific function modules and Compax3 objects ..... 322  
 Example in CFC: Positioning 1 ..... 323  
 Example in CFC: Positioning 2 ..... 324  
 Example in CFC: Positioning with set selection ..... 325  
 Example in CFC: Cycle mode ..... 326  
 Example in ST: Cycle mode with a Move module ..... 327


### 5.15.1. Example in CFC: Using Compax3-specific function modules and Compax3 objects

- ◆ Read in the process image of the digital inputs with the InputStatus module.
- ◆ Generate a process image of the digital outputs with the OutputStatus module.
- ◆ Digital input I0, used for counting an external event. The event is only detected as an event if
  - ◆ The I0 input is at TRUE for at least 0.5 seconds and
  - ◆ The voltage on analog input 0 exceeds the threshold value of 3.5 volts.
- ◆ When 5 of these events have been counted, the digital output is set to O0. At the same time, the program prevents additional events on the I0 from being counted. The counter state can be reset again with Input I1 as soon as it reaches a value of 5.




### 5.15.2. Example in CFC: Positioning 1

- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts an absolute positioning process with fixed parameters
- ◆ Input I6 is used to stop the movement
- ◆ After positioning is complete, there will be a return to Position 0 as soon as Input I1 has been activated



### 5.15.3. Example in CFC: Positioning 2


- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts an absolute positioning process
- ◆ If an event (I1) occurs during the positioning, the target position will be moved back by 20 ("MoveAdditive")
- ◆ If an event occurs while positioning is not in progress, it has no effect





### 5.15.4. Example in CFC: Positioning with set selection


- ◆ Input I7 enables the power output stage
- ◆ The position, speed and ramps can be stored in the array (table) (for example input with the Compax3 ServoManager)
- ◆ The desired set can be selected with inputs I1 through I5 (binary coded)
- ◆ Input I0 starts the positioning (absolute positioning)
- ◆ Positioning that is in progress can be stopped with Input I6



**5.15.5. Example in CFC: Cycle mode**

**Example a: Cycle mode**

- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts cyclical positioning. During this process, two positions are approached in alternation.
- ◆ Input I6 stops cycle mode



### 5.15.6. Example in ST: Cycle mode with a Move module

Input I2 enables the power output stage.

- ◆ Input I0 starts cycle mode. Two positions are approached alternately.
- ◆ There is a pause of 1 second after the first position is reached.
- ◆ There is a pause of 1.5 seconds after the second position is reached.
- ◆ Input I1 stops cycle mode.

```

CoDeSys - Schrittkette_ST_Englisch.pro* - [PLC_PRG (PRG-ST)]
Datei Bearbeiten Projekt Einfügen Extras Online Fenster Hilfe

0001 PROGRAM PLC_PRG
0002 VAR
0003   Inputs: C3_Input;
0004   Outputs: C3_Output;
0005   StartTrigger: R_TRIG;
0006   POSA: MC_MoveAbsolute;
0007   Timer1: TON;
0008   Stop: MC_Stop;
0009   Power: MC_Power;
0010   State: INT;
0011 END_VAR
0012

0001 Inputs(); (* Read Input process image *)
0002
0003 (* Enable Power stage *)
0004 Power(Enable:=Inputs.I2 , Axis:= AXIS_REF_LocalAxis, Status=>Outputs.O0);
0005
0006 (* State machine Start *)
0007 StartTrigger(CLK:=Inputs.I0); (* detect a rising edge on Input I0 *)
0008 IF(StartTrigger.Q) THEN (* Rising Edge ? *)
0009     State:=1;      (* -> Start State machine *)
0010 END_IF
0011
0012 (* State machine *)
0013 CASE State OF
0014 1: (* Prepare first Move command *)
0015     POSA.Execute:=FALSE;
0016     POSA.Position:=30.0;
0017     POSA.Velocity:=15.0;
0018     State:=2;
0019 2: (* Start first Move command *)
0020     POSA.Execute:=TRUE;
0021     State:=3;
0022 3: (* Wait until position 1 reached *)
0023     IF(POSA.Done) THEN
0024         State:=4;
0025     END_IF

```

Z: 55, Sp.: 46

```

0026 4: (* 1 Sekunde Pause *)
0027   Timer1(IN:=TRUE , PT:=T#1.0s);
0028   IF(Timer1.Q) THEN
0029     Timer1(IN:=FALSE);
0030     Zustand:=5;
0031   END_IF
0032 5: (* Positionierung 2 vorbereiten *)
0033   POSA.Execute:=FALSE;
0034   POSA.Position:=0.0;
0035   POSA.Velocity:=25.0;
0036   Zustand:=6;
0037 6: (* Positionierung 2 Start *)
0038   POSA.Execute:=TRUE;
0039   Zustand:=7;
0040 7: (* Warten bis Position 2 erreicht *)
0041   IF(POSA.Done) THEN
0042     Zustand:=8;
0043   END_IF
0044 8: (* 1.5 Sekunden Pause *)
0045   Timer1(IN:=TRUE , PT:=T#1.5s);
0046   IF(Timer1.Q) THEN
0047     Timer1(IN:=FALSE);
0048     Zustand:=1; (* Schrittkette erneut starten *)
0049   END_IF
0050 END_CASE
0051 (* Positionierbaustein aufrufen *)
0052 POSA(Acceleration:=100, Deceleration:=100, Jerk:=10000, JerkDecel:=10000, Axis:=AXIS_REF_LocalAxis);
0053 (* Stop Eingang *)
0054 Stop(Execute:=Inputs.I1 , Deceleration:=200 , Jerk:=20000 , Axis:=AXIS_REF_LocalAxis);
0055 IF(Inputs.I1) THEN (* Stop Eingang = TRUE *)
0056   Zustand:=0; (* Schrittkette zurücksetzen *)
0057   Timer1(IN:=FALSE); (* Timer zurücksetzen *)
0058   POSA.Execute:=FALSE;
0059 END_IF
0060 Outputs(); (* PA Ausgänge schreiben *)

```

## 5.16 Profibus: Emulating the ProfiDrive profile (C3F\_ProfiDrive\_Statemachine)

The function module can be found in the "C3\_Profiles\_lib" library and must be integrated via the library manager before use.


### Notes on the use:

- ◆ The input values coming from the master control via the Profibus can be changed before they are transmitted to the Statemachine (e.g. I/Os).
- ◆ In the simplest case, the control word and the motion parameters (which may come from the Profibus) are manipulated by the IEC program.
- ◆ If the Statemachine is active, all motions must be executed via the Statemachine. Motions such as for example MoveAbsolut, MoveRelativ; MoveAdditiv; MoveVelocity; Gearing, Reg-related positioning are possible. Or with Compax3F: Force/pressure regulating.
- ◆ With the "control via PLC" bit (CW1 bit 10 = 1), the Statemachine takes the control for the drive (is active). This means that no functions concerning the device status (such as Power, MoveX) by other function/program modules are permitted. If "no control" is selected (CW1 bit 10 = 0), the device status can be changed via function/program modules.
- ◆ The Profidrive Statemachine works independently of the Profibus. I.e. it can also be used in connection with other busses.
- ◆ The Profidrive Statemachine contains states, which cannot be mapped to the PLCopen status machine.

FB name	C3_ProfiDrive_Statemachine	
With the aid of the Profibus function module, the PROFIdrive profile can be simulated. The profile is described in the help of the Compax3 I20T11 technology function (set operation is however not possible). The inputs of the module can be assigned as required.		
<b>VAR_IN_OUT</b>		
--	--	--
<b>VAR_INPUT</b>		
<b>CW1</b>	WORD	Control word according to Profidrive (see below)
<b>STWadd</b>	INT	additional control word: the following functions can be triggered in the positioning mode 0: no action 1: NOP (No Operation) 2: Stop 3: Homing Execution takes place with the "activate motion order" of CW1. The value must be reset to zero after the execution!
<b>OperationMode</b>	INT	Operating mode after Profidrive 1: Speed control 2: Positioning
<b>Position</b>	REAL	Position setpoint value for all positioning commands (MoveAbs, MoveRel, MoveAdd, RegSearch, RegMove preparation)
<b>Velocity</b>	REAL	Setpoint speed in operating mode 1 (speed control) and for MoveVelocity (not for positioning)
<b>VelocityForPosition</b>	REAL	Setpoint travel speed for positioning
<b>VelocityForJog</b>	REAL	Speed for JOG
<b>Acceleration</b>	DINT	Commanded acceleration
<b>Deceleration</b>	DINT	Setpoint deceleration

<b>DecelerationForStop</b>	DINT	Deceleration for Stop
<b>Jerk</b>	DINT	Setpoint jerk
<b>Master</b>	INT	Source for Gearing - AXIS_REF_Physical (T30, T40) [e.g. encoder input X11] - AXIS_REF_HEDA (T30, T40) - AXIS_REF_Virtual (T40)
<b>RatioNumerator</b>	INT	Numerator for Gearing
<b>RatioDenominator</b>	INT	Denominator for Gearing
<b>PositionForRegMove</b>	REAL	Position for RegMove, necessary if RegSearch is executed and registration is detected. Note: The input is connected to the PositionOfRegMove output in the simplest case.
<b>VelocityForRegMove</b>	REAL	Speed for RegMove, necessary if RegSearch is executed and registration is detected. Note: The input is connected to the VelocityOfRegMove output in the simplest case.
<b>CStatus1ForRegMove</b>	WORD	- do not use - Command status 1 for RegMove end; necessary if RegSearch is executed and registration is detected
<b>CStatus2ForRegMove</b>	WORD	reserved!
<b>ShortRampForRegMove</b>	BOOL	Permits the Compax3 to calculate individual parameters for the RegMove positioning, if the set parameters would not reach the target.
<b>RegMoveMode</b>	INT	reserved!
<b>IgnoreZoneStart</b>	REAL	Registration mark-related positioning: Beginning of Registration lock-out zone (StartIgnore)
<b>IgnoreZoneStop</b>	REAL	Registration mark-related positioning: End of Registration lock-out zone (StopIgnore)
<b>PositionReachedMode</b>	BOOL	Mode for the generation of the PositionReached in the status word (CW1.10). TRUE: link to setpoint value
<b>DisablePositiveDirection</b>	BOOL	Block for positive direction
<b>DisableNegativeDirection</b>	BOOL	Block for negative direction
<b>LimitErrorExtern</b>	BOOL	reserved!
<b>Override</b>	REAL	reserved!
<b>CStatus1In</b>	WORDW	reserved!
<b>CStatus2In</b>	WORD	reserved!
<b>PressureForce</b>	DINT	Setpoint differential pressure [mbar, psi] or setpoint force [N]. <b>Description</b> (see page 203)
<b>PressureForce_Gradient</b>	DINT	Change speed for pressure or force in [bar/s, psi/s], [N/s].
<b>ForceReachedMode</b>	BOOL	Mode for the generation of the ForceReached in the status word (SW1.10). TRUE: Link to setpoint value.
<b>AuxAxis</b>	BOOL	Defines, if the auxiliary axis is to be used as a following axis. TRUE: Auxiliary axis runs synchronously to the main axis
<b>VAR_OUTPUT</b>		
<b>ZSW1</b>	WORD	Status word after Profidrive
<b>OperationModeActual</b>	INT	Active operating mode
<b>PositionOfRegMove</b>	REAL	Position transmitted to the RegMove command (cache memory) Note: The output is connected to the PositionForRegMove input in the simplest case.

<b>VelocityOfRegMove</b>	REAL	Velocity transmitted to the RegMove command (cache memory) Note: The input is connected to the VelocityForRegMove output in the simplest case.
<b>CStatus2OfRegMove</b>	WORD	reserved!
<b>StatusMotor_off</b>	BOOL	Motor is currentless (TRUE)
<b>StatusMotor_standstill</b>	BOOL	Status motor is energized at standstill (setpoint value) (TRUE)
<b>CStatus1</b>	WORD	reserved!
<b>CStatus2</b>	WORD	reserved!
<p>Notes:</p> <ul style="list-style-type: none"> <li>◆ You can call up directly the help for the Compax3 Profidrive device (I20T11) via the help intaller (C3 ServoManager "?" Start C3 ServoManager Help Installer...) (select and open in the left window).</li> <li>◆ On the Compax3 DVD you will find an application example with additional explanations for the use of this module: C3 DVD directory .....\Examples\Profidrive with T30T40\</li> </ul>		





# 6. Communication

## In this chapter you can read about:

Compa3 communication variants .....	333
COM port protocol .....	345
Remote diagnosis via Modem .....	350
Profibus .....	354
CANopen - Node Settings .....	367
DeviceNet .....	385
Ethernet Powerlink .....	388
HEDA Bus .....	390

Here you will find the description of the fieldbus interfaces, which can be configured in the Compax3 ServoManager under the tree entry "configuring the communication".

**Please note:** The configuration of the process data (Mapping) is made wizard-guided with the Compax3 ServoManager.  
If you perform the mapping directly via the master, you must go through this fieldbus wizard once; the Compax3 ServoManager will perform the necessary initializations.

## 6.1 Compax3 communication variants

### In this chapter you can read about:

PC <-> Compax3 (RS232) .....	334
PC <-> Compax3 (RS485) .....	335
PC <-> C3M device combination (USB) .....	336
USB-RS485 Moxa Uport 1130 adapter .....	337
ETHERNET-RS485 NetCOM 113 adapter .....	338
Modem Westermo TD-36 485 .....	340
C3 settings for RS485 two wire operation .....	343
C3 settings for RS485 four wire operation .....	344

Overview of all possible communication modes between Compax3 deviecs and a PC.

### 6.1.1. PC <-> Compax3 (RS232)

#### PC <-> Compax3 (RS232): Connections to a device

PC (RS232 COM)



115kb



PC (Virtueller ComPort)




USB/RS232



115kb



PC (Virtueller ComPort)



Ethernet (LAN)

Ethernet/RS232



115kb



PC (RS232 COM)



115kb



Modem

TelefonNetz



Max 33.6kb




Modem

115kb



PC (Virtueller ComPort)



Ethernet (LAN)



WLAN/RS232




115kb




### 6.1.2. PC <-> Compax3 (RS485)

#### PC <-> Compax3 (RS485)



### 6.1.3. PC <-> C3M device combination (USB)


#### PC <-> C3M device combination



**6.1.4. USB-RS485 Moxa Uport 1130 adapter**



Male DB9




PIN	RS-422/4-wire RS-485	2-wire RS-485
1	TxD-(A)	-
2	TxD+(B)	-
3	RxD+(B)	Data+(B)
4	RxD-(A)	Data-(A)

PIN	RS-422/4-wire RS-485	2-wire RS-485
5	GND	GND
6	-	-
7	-	-
8	-	-

The serial UPort 1130 USB adapter offers a simple and comfortable method of connecting an RS-422 or RS-485 device to your laptop or PC. The UPort 1130 is connected to the USB port of your computer and complements your workstation with a DB9 RS-422/485 serial interface. For simple installation and configuration, Windows drivers are already integrated. The UPort 1130 can be used with new or legacy serial devices and supports both 2- and 4-wire RS-485. It is especially suited for mobile, instrumentation and point-of-sale (POS) applications.  
 Herstellerlink: [http://www.moxa.com/product/UPort\\_1130.htm](http://www.moxa.com/product/UPort_1130.htm)  
[http://www.moxa.com/product/UPort\\_1130.htm](http://www.moxa.com/product/UPort_1130.htm)


**Connection plan for Compax3S:**



**6.1.5. ETHERNET-RS485 NetCOM 113 adapter**



Herstellerlink: <http://www.vsc.com.de/666.htm> (<http://www.vsc.com.de/666.htm>)






**DIP Switch settings NetCom 113 for two-wire operation:**

1ON 2ON 3off 4off (Mode: RS485 by ART (2 wire without Echo))


**Communication settings C3S/C3M:**

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

**Connection plan NetCom113-> C3S:**




**Connection plan NetCom113-> C3M X31:**



### 6.1.6. Modem Westermo TD-36 485


#### Modem Westermo TD-36 485 (Remote maintenance C3S /C3M)




#### DIP Switch - settings TD-36 (RS485 two wire)

For operation , all settings must be reset to factory settings!  
All other settings must be made via the DIP switches.

**IMPORTANT: The changes of the DIP switches are only accepted after POWER ON!**







**C3 ServoManager RS485 wizard settings:**  
 download with configuration in RS232 mode!

1/2 RS-485 Einstellungen

RS-485 Einstellungen

Master	allgemein
Multicast-Adresse	98
Geräte-Adresse	1
Baudrate	115200
Kabeltyp	Zweidraht
Parity	Kein
Stopbits	1
Datenbits	8

< Zurück Weiter > Abbrechen Hilfe

**Communication settings C3S/C3M:**

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	


**Connection plan TD-36 / Compax3 S**

**RS-422/485**

Position	Direction*	Description		Product marking
No. 1	In	R+ (A') Receive	RS-422/485 4-wire	R+
No. 2	In	R- (B') Receive	RS-422/485 4-wire	R-
No. 3	Out	T+ (A) Transmit	RS-422/485 4-wire	T/R+
	In/Out	T+ (A/A') Transmit/Receive	RS-485 2-wire	
No. 4	Out	T- (B) Transmit	RS-422/485 4-wire	T/R-
	In/Out	T+ (A/A') Transmit/Receive	RS-485 2-wire	

\* Direction relative to this unit


**TD-36 / RS485**



**Connection plan TD-36 / Compax3 M**

**TD-36/RS485**


**C3M X31**



**6.1.7. C3 settings for RS485 two wire operation**

**C3 ServoManager RS485 wizard settings:**

download with configuration in RS232 mode°!




**Communication settings C3S/C3M:**

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

**6.1.8. C3 settings for RS485 four wire operation**

**C3 ServoManager RS485 wizard settings:**

download with configuration in RS232 mode



**Communication settings C3S/C3M:**

Object	Function	Value
810.1	Protocol	0 (four wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

## 6.2 COM port protocol

### In this chapter you can read about:

RS485 setting values.....	345
ASCII - record.....	346
Binary record.....	347

You can communicate with Compax3 in order to read or write objects via plug X10 ( or X3 on the mains module of Compax3M) on the front via a COM port (max. 32 nodes).

As a rule 2 records are possible:

- ◆ ASCII record simple communication with Compax3
- ◆ Binary record: fast and secure communication with Compax3 by the aid of block securing.

**Switching between the ASCII and the binary record via automatic record detection.**

interface settings (see page 458)

**Wiring** RS232: **SSK1** (see page 441)  
 RS485: like **SSK27** (see page 442) / RS485 is activated by +5V on X10/1.  
 USB: SSK33/03 (only for Compax3M)

### 6.2.1. RS485 setting values

If "Master=Pop" was selected, only the settings compatible with the Pops (Parker Operator Panels) made by Parker are possible.

**Please note that the connected Pop has the same RS485 setting values.**

**You can test this with the "PopDesigner" software.**

- "Master=General" makes all Compax3 settings possible.
- Multicast Address** You can use this address to allow the master to access multiple devices simultaneously.
- Device Address** The device address of the connected Compax3 can be set here.
- Baud rate** Adjust the transfer speed (baud rate) to the master.
- Connection Type** Please choose between **two-wire and four-wire RS485** (see page 27).
- Protocol** Adjust the protocol settings to the settings of your master.

**6.2.2. ASCII - record**

The general layout of a command string for Compax3 is as follows:

**[Adr] command CR**

<b>Adr</b>	RS232: no address RS485: Compax3 address in the range 0 ... 99 Address settings can be made in the C3 ServoManager under "RS485 settings"
<b>Command</b>	valid Compax3 command
<b>CR</b>	End sign (carriage return)

**Command**

A command consists of the representable ASCII characters (0x21 .. 0x7E). Lower cases are converted automatically into capitals and blanks (0x20) are deleted, if they are not placed between two quotation marks. Separator between places before and after the decimal is the decimal point (0x2E). A numeric value can be given in the Hex-format if it is preceded by the "\$" sign. Values can be requested in the Hex-format if the CR is preceded additionally by the "\$" sign.

**Answer strings**

All commands requesting a numeric value from Compax3 are acknowledged with the respective numeric value in the ASCII format followed by a CR without preceding command repetition and following statement of unit. The length of these answer strings differs depending on the value. Commands requesting an Info-string (e.g. software version), are only acknowledged with the respective ASCII character sequence followed by a CR, without preceding command repetition. The length of these answer strings is here constant. Commands transferring a value to Compax3 or triggering a function in Compax3 are acknowledged by:

**>CR**

if the value can be accepted resp. if the function can be executed at that point in time. If this is not the case or if the command syntax was invalid, the command is acknowledged with

**!xxxxCR**

The 4 digit error number **xxxx** is given in the HEX format; you will find the meaning in the appendix.

**RS485 answer string**

When using RS485, each answer string is preceded by a "\*" (ASCII - character: 0x2A).

**Compax3 commands**

**Read object**

**RS232: O [\$] Index , [\$] Subindex [\$]**

**RS485: Address O [\$] Index , [\$] Subindex [\$]**

The optional "\$" after the subindex stands for "hex-output" which means that an object value can also be requested in hex; e.g. "O \$0192,2\$": (Object 402.2)

**Write object**

**RS232: O [\$] Index , [\$] Subindex = [\$] Value [ ; Value2 ; Value3 ; ...]**

**RS485: Address O [\$] Index , [\$] Subindex = [\$] Value [ ; Value2 ; Value3 ; ...]**

The optional "\$" preceding Index, Subindex and value stands for "Hex-input" which means that Index, Subindex and the value to be transferred can also be entered in hex (e.g. O \$0192,2=\$C8).

### 6.2.3. Binary record

The binary record with block securing is based on 5 different telegrams:

- ◆ 2 request telegrams which the control sends to Compax3 and
- ◆ 3 response telegrams which Compax3 returns to the control.

#### Telegram layout

Basic structure:

Start code	address	Number of data bytes - 1	Data				block securing	
SZ	A	L	D0	D1	...	r	Crc(Hi)	Crc(Lo)

The start code defines the frame type and is composed as follows:

Bit	7	6	5	4	3	2	1	0
Frame type	Frame identification				PLC		Gateway	address
RdObj Read object	1	0	1	0	x	1	x	x
WrObj Write object	1	1	0	0	x	1	x	x
Rsp Answer	0	0	0	0	0	1	0	1
Ack Positive command acknowledgement	0	0	0	0	0	1	1	0
Nak Negative command acknowledgement	0	0	0	0	0	1	1	1

Bits 7, 6, 5 and 4 of the start code form the telegram identification; Bit 2 is always "1".

Bits 3, 1 and 0 have different meanings for the request and response telegrams. The address is only necessary for RS484.

#### Request telegrams

##### -> Compax3

- ◆ the address bit (Bit 0 = 1 ) shows if the start code is followed by an address (only for RS485; for RS232 Bit 0 = 0)
- ◆ the gateway bit (Bit 1 = 1) shows if the message is to be passed on. (Please set Bit 1 = 0, as this function is not yet available)
- ◆ the PLC bit (Bit 3 = 1 ) allows access to objects in the PLC/Pop format  
 U16, U32: for integer formats (see bus formats: Ix, Ux, V2)  
 IEEE 32Bit Floating Point: for broken formats (bus formats: E2\_6, C4\_3, Y2, Y4; without scaling)  
 With Bit 3 = 0 the objects are transmitted in the DSP format.  
 DSP formats:  
 24 Bit = 3 Bytes: Integer INT24 or Fractional FRACT24  
 48 Bit = 6 Bytes: Real REAL48 (3 Byte Int, 3 Byte Fract) / Double Integer DINT48 / Double Fractional DFRACT48

**Response telegram Compax3**

- ◆ Bits 0 and 1 are used to identify the response
- ◆ Bit 3 is always 0

The maximum number of data bytes in the request telegram is 256, in the response telegram 253.

The block securing (CRC16) is made via the CCITT table algorithm for all characters.

After receiving the start code, the timeout monitoring is activated in order to avoid that Compax3 waits in vain for further codes (e.g. connection interrupted) The timeout period between 2 codes received is fixed to 5ms (5 times the code time at 9600Baud)

**Write object – WrObj telegram**

SZ	Adr	L	D0	D1	D2	D3 ... Dn	Crc(Hi)	Crc(Lo)
0xCX		n	Index(Hi)	Index(Lo)	Subindex	Value	0x..	0x..

Describing an object by a value.

**Positive acknowledgement – Ack-telegram**

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x06	1	0	0	0x..	0x..

Answer from Compax3 if a writing process was successful, i.e. the function could be executed and is completed in itself.

**Negative acknowledgement – Nak - telegram**

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x07	1	F-No.(Hi)	F-No.(Lo)	0x..	0x..

Answer from Compax3 if access to the object was denied (e.g. function cannot be executed at that point in time or object has no reading access). The error no. is coded according to the DriveCom profile resp. the CiA Device Profile DSP 402.

**Read object – RdObj - telegram**

SZ	Adr	L	D0	D1	D2	D3	D4	D5	...	Dn	Crc(Hi)	Crc(Lo)
0xAX		n	Index1(Hi)	Index1(Lo)	Subindex1	Index2(Hi)	Index2(Lo)	Subindex2	...	...	0x..	0x..

Reading one or several objects

**Answer – Rsp - telegram**

SZ	L	D0 ... Dx-1	Dx ... Dy-1	Dy-D..	D ... D..	D ... Dn	Crc(Hi)	Crc(Lo)
0x05	n	Value1	Value 2	Value 3	Value ..	Value n	0x..	0x..

Answer from Compax3 if the object can be read.

If the object has no reading access, Compax3 answers with the Nak – telegram.

**Example:****Reading object "StatusPositionActual" (o680.5):**

Request: A5 03 02 02 A8 05 E1 46

Response: 05 05 FF FF FF FF FE 2D 07 B4

**Writing into an Array (o1901.1 = 2350)**

Request: C5 02 08 07 6D 01 00 09 2E 00 00 00 95 D5

Response: 06 01 00 00 BA 87



**Block securing: Checksum calculation for the CCITT table algorithm**

The block securing for all codes is performed via the following function and the corresponding table:

The "CRC16" variable is set to "0" before sending a telegram.

**Function call:**

```
CRC16 = UpdateCRC16(CRC16, Character);
```

This function is called up for each Byte (Character) of the telegram.

The result forms the last two bytes of the telegram

Compax3 checks the CRC value on receipt and reports CRC error in the case of a deviation.

```
Function  const unsigned int _P CRC16_table[256] = {
          0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
          0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
          0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
          0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
          0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
          0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
          0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
          0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
          0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
          0xc9cc, 0xd9ed, 0xe98e, 0xf9af, 0x8948, 0x9969, 0xa90a, 0xb92b,
          0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
          0xdbfd, 0xcbdc, 0xfbbf, 0xeb9e, 0x9b79, 0x8b58, 0xbb3b, 0xab1a,
          0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
          0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
          0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
          0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
          0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
          0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
          0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
          0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
          0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
          0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
          0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
          0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
          0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
          0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
          0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
          0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
          0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
          0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
          0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
          0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
        };

unsigned int UpdateCRC16(unsigned int crc,unsigned char value) {
    unsigned int crcl6;

    crcl6 = (CRC16_table[(crc >> 8) & 0x00FF] ^ (crc << 8)
             ^ (unsigned int)(value));

    return crcl6;
}

```

You will find this function on the Compax3 CD under RS232\_485\Function UpdateCRC16.txt!

## 6.3 Remote diagnosis via Modem

**In this chapter you can read about:**

Structure ..... 350  
 Configuration of local modem 1 ..... 351  
 Configuration of remote modem 2 ..... 352  
 Recommendations for preparing the modem operation ..... 353

**Caution!**

**As the transmission via modem may be very slow and interference-prone, the operation of the Compax3 ServoManager via modem connection is on your own risk!**

**The function setup mode as well as the ROLL mode of the oscilloscope are not available for remote diagnosis!**


**It is not recommended to use the logic analyzer in the Compax3 IEC61131-3 debugger due to the limited bandwidth.**

**Requirements:**

For modem operation, a direct and stable telephone connection is required. Operation via a company-internal telephone system is not recommended.

### 6.3.1. Structure

**Layout and configuration of a modem connection ServoManager - Compax3:**



Autoryzowany dystrybutor Parker:

**ARA**  
**PNEUMATIK**  
 53-012 Wrocław tel. 71 364 72 82  
 ul. Wyścigowa 38 fax 71 364 72 83  
 www.arapneumatik.pl



The green part of the drawing shows the proceeding for Compax3 release versions < R5-0!

The proceeding for Compax3 release versions < R5-0 is described in an application example (.../modem/C3\_Appl\_A1016\_ *language*.pdf on the Compax3 CD).

### **Connection Compax3 ServoManager <=> Compax3**

The Compax3 ServoManager (1) establishes a RS232 connection with modem 1 (PC internal or external).

Modem 1 dials modem 2 via a telephone connection (3).

Modem 2 communicates with Compax3 (6) via RS232.

### **Configuration**


Modem 1 is configured via the Compax3 ServoManager (1)

Modem 2 can be configured via Compax3 (on place), triggered by putting **SSK31** (see page 446) on X10. For this, the device must be configured before. This can be made locally before the system / machine is delivered with the aid of the Compax3 ServoManager (8).

The transmission was tested with a TD33 modem made by "**Westermo** <http://www.westermo.com>". The configuration with this standard modem is especially simple.

Other modem types are also possible.

## **6.3.2. Configuration of local modem 1**

- ◆ Menu "Options: Communication settings RS232/RS485..." must be opened
- ◆ Select "Connection via Modem"
- ◆ Under "name" you can enter a name for the connection
- ◆ Enter the target telephone number.
  - Note: If an ISDN telephone system is operated within a company network, an additional "0" may be required in order to get out of the local system into the company network before reaching the outside line with an additional "0".
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type: "Westermo TD-33" or "user-defined modem"
  - ◆ For "Westermo TD-33", no further settings are required.
  - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.
    - Then you can enter special AT commands.
  - ◆ **Note:** When operating the local modem on a telephone system, it may be necessary to make a blind dialling. Here, the modem does not wait for the dialling tone. For the Westermo TD33, the additional command sequence is ATX3.
- ◆ Select the COM interface where the modem is connected.
- ◆ Close the window and establish the connection with button  (open/close COM port).
- ◆ The connection is interrupted when the COM port is closed.

- ◆ Select the modem type: "Westermo TD-33" or "user-defined modem"
  - ◆ For "Westermo TD-33", no further settings are required.
  - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.  
Then you can enter special AT commands.
  - ◆ **Note:** When operating the local modem on a telephone system, it may be necessary to make a blind dialling. Here, the modem does not wait for the dialling tone. For the Westermo TD33, the additional command sequence is ATX3.

### 6.3.3. Configuration of remote modem 2

Settings in Compax3 under "configure communication: Modem settings":

- ◆ Modem initialization = "ON": After the SSK31 modem cable has been connected, Compax3 initializes the modem
- ◆ Modem initialization after Power On = "ON": After Power on of Compax3, the device initializes the modem
- ◆ Modem check = "ON": a modem check is performed
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type: "Westermo TD-33" or "user-defined modem"
  - ◆ For "Westermo TD-33", no further settings are required.
  - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.  
Then you can enter special AT commands.
  - ◆ **Note:** When operating the local modem on a telephone system, it may be necessary to make a blind dialling. Here, the modem does not wait for the dialling tone. For the Westermo TD33, the additional command sequence is ATX3.
- ◆ in the following wizard window, a specific download of the modem configuration can be made.

#### Note:

If a configuration download is interrupted, the original settings in the non volatile memory of the Compax3 are still available.

You have to finish the communication on the PC side and to reset the Compax3 via the 24V supply before you can start a new trial.

#### Reinitialization of the remote modem 2


Remove cable on Compax3 X10 and connect again!

### 6.3.4. Recommendations for preparing the modem operation

#### **Preparations:**

- ◆ Settings in Compax3 under "configure communication: Modem settings":
  - ◆ Modem initialization: "ON"
  - ◆ Modem initialization after Power On: "ON"
  - ◆ Modem check: "ON"
- ◆ Deposit SSK31 cable in the control cabinet.
- ◆ Install modem in the control cabinet and connect to telephone line.

#### **Remote diagnosis required:**

- ◆ On site:
  - ◆ Connect modem to Compax3 X10 via SSK31
  - ◆ Modem is automatically initialized
- ◆ Local:
  - ◆ connect modem to telephone line
  - ◆ Establish cable connection to modem (COM interface)
  - ◆ Select "connection via modem" under "options: communication settings RS232/RS485...".
  - ◆ Select modem under "selection"
  - ◆ Enter telephone number
  - ◆ Select COM interface (PC - modem)
  - ◆ Establish connection with button  (open/close COM port).

## 6.4 Profibus

### In this chapter you can read about:

Typical application with fieldbus and IEC61131 .....	354
Profibus configuration.....	354
Cyclic process data channel.....	356
Acyclic parameter channel .....	357
Simatic S7 -300/400 - modules .....	366

### I20 Function

The Profibus option is available with the Compax3 devices C3I20Txx!

### Notes on the configuration of the Profibus master

Before configuring the Profibus master (e.g. S7), you will have to configure the Compax3 axis.

In the **Profibus window** (see page 354) of the configuration wizard you will receive the status message "Profibus Telegram" with the information on the telegram which can be set in the master (PPO type).

### 6.4.1. Typical application with fieldbus and IEC61131

We recommend the following procedure to control the IEC61131-3 program via Profibus:

- ◆ Use the control word (DeviceControl\_Controlword\_1) to control the PLCopen function modules (Execute, Enable) to activate the modules via Profibus.
- ◆ The logical module outputs can be placed on the status word (DeviceState\_Statusword\_1).
- ◆ Place the control word and the status word on the cyclic process data channel.
- ◆ Connect variable module outputs of your IEC61131-3 program with the recipe array.
  - ◆ For rapid access, the values from the first 5 rows of the recipe array can be placed in the cyclic channel.
  - ◆ Additional values of the recipe array can be written acyclically.

Now you can use the bus to assign values, to activate function modules with the control word and to read the current status with the control word.

### 6.4.2. Profibus configuration

#### In this chapter you can read about:

Configuration of the process-data channel.....	355
PKW parameter channel .....	356
Error reaction to a bus failure .....	356

Following are described the input windows of the Profibus configuration wizard. Can be called up in the tree (Compax3 ServoManager, left window) under "configure configuration".

**6.4.2.1 Configuration of the process-data channel**

You can use the Process Data Channel (PZD) to exchange actual and Setpoint values cyclically between the Compax3 and the Profibus master.

Adjusting the cyclic PZD:

The PZD is adjusted separately for the following transfer directions:

- ◆ Profibus-Master ⇒ Compax3 (PAD)
- ◆ Compax3 ⇒ Profibus-Master (PED)

Maximum size of the process-data channel:  
 8 words (16 bytes) PAD and  
 8 words (16 bytes) PED

**The objects that can be put on the process data channel can be found in the " Compax3 Objects (see page 414)"!**

**Assignment of the process data channel**

Assignment of the process data channel is automated in Compax3 ServoManager. You select the objects which you want to put one after the other to the process input data (PED: Compax3 => PLC) and to the process output data (PAD: PLC => Compax3).

ServoManager continuously checks areas of the PZD that are free and enables additional input options correspondingly.

**PPO type** Depending on the configuration that is set, the resulting PPO type is displayed in the "Profibus telegram" wizard window (in the status line of the wizard window). You can use this value for the configuration of the Profibus master.

**Assignment of the PZD** When data is read out of the Process Data Channel (PZD), the word width of the individual objects must be carefully noted.


**Example:** Assignment:

Object	Word width	Assignment	address
POSITION_position	2	AW(n) & AW(n+1)	AD(n)
POSITION_speed	2	AW(n+2) & AW(n+3)	AD(n+2)
AnalogOutput0_DemandValue	1	AW(n+4)	AW(n+4)
AnalogOutput1_DemandValue	1	AW(n+5)	AW(n+5)
Array_Col1_Row1	2	AW(n+6) & AW(n+7)	AD(n+6)

PLC → Compax3



Compax3 → PLC



### 6.4.2.2 PKW parameter channel

#### Parameter access with DPV0

In addition to cyclic data exchange, you can use the PKW mechanism for acyclic access to parameters.


The PKW mechanism is implemented for Profibus masters without DPV1 functionality.

**PKW:**Parameter identification value

You can select between:

- ◆ **no PKW** - without acyclic parameter access.
- ◆ **PKW** - parameter access via a PKW length of 8 bytes.

#### PKW structure



Additional information on the **structure of the PKW** (see page 357)

### 6.4.2.3 Error reaction to a bus failure

Here you can adjust how Compax3 will respond to a fieldbus error:

Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

## 6.4.3. Cyclic process data channel

The structure of the PZD is defined in the configuration menu: "Profibus Telegram" of the Servomanager.

### 6.4.3.1 Control and status word

The cyclic process data channel contains a control word and a status word both, freely available and 16 bits in size:

Control word: Profibus-Master ⇒ Compax3

Status word: Compax3 ⇒ Profibus-Master



## 6.4.4. Acyclic parameter channel

**In this chapter you can read about:**  
 Parameter access with DPV0: Required data channel ..... 357  
 Data formats of the bus objects ..... 363  
 Compax3 supports parameter access with DPV1.

### 6.4.4.1 Parameter access with DPV0: Required data channel

You can use the PKW mechanism for acyclic access to parameters in cyclic data exchange as well. This is made available to make it possible for the master to have access to the important device parameters without DPV1 functionality. The master formulates an order in the PKW mechanism. Compax3 processes the order and formulates the response.

**PKW structure:**

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
PKE		IND		PWE			

PKW: Parameter identification value  
 PKE: Parameter identification (1. and 2. octet) (see below)  
 IND: Subindex\* (3. Octet), 4. byte is reserved  
 PWE: Parameter value (5th to 8th byte resp. 5th to 12th byte with extended PKW)


**PKE structure:**

Byte 1						Byte 2									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
AK				SPM	PNU										

AK: Order /response identification (value range 0 ... 15)  
 SPM: Reserved  
 PNU: Parameter number

**\*Reference to the subindex**

The information for PNU subindex (parameter number) also applies to PROFIdrive profile Version 3, i.e., that the subindex is counted starting at 0, while for PROFIdrive profile Version 2 the subindex is counted starting at 1:



The result of this is as follows:

**Profibus master based on PROFIdrive profile Version 3**

The subindex of the Profibus No. (PNU) specified in the object list is directly valid. Example: Example: PNU object forward speed control = 400.1 (as specified).

**Profibus master based on PROFIdrive profile Version 2**

The subindex of the Profibus No. (PNU) specified in the object list must be incremented by 1. Example: PNU object forward speed control = 400.2

### Order and response processing

Order/response identifications are defined so that it is apparent from the identification which fields of the PKW interface (IND, PWE) also need to be evaluated. To this may be added the distinction between parameter value and parameter description.

Order identification	Order Master → Compax3	response identification Compax3 → Master
0	No order	0
1	Request parameter value	1,2
2	Change parameter value (word)	1
3	Change parameter value (double word)	2
6	Request parameter value (array)	4,5
7	Change parameter value (array of word)	4
8	Change parameter value (array of double word)	5
9	Request number of array elements	6
14	Change object	14
15	Request object	15

Response identifications 7 and 8 are used for negative acknowledgements for problems.

### Sequence

- ◆ The master transfers an order to a Compax3.
- ◆ The master repeats this order at least until a response is received from Compax3. This procedure ensures the transfer of orders /responses on the user level.
- ◆ Only one order is ever being processed at a time.
- ◆ Compax3 continues to make the response available until the master formulates a new order.
- ◆ For responses containing parameter values, Compax3 always responds upon repetition with the current value (cyclic processing). This applies to all responses to the orders "Request parameter value", "Request parameter value (Array)" and "Request object".
- ◆ The PWE transfer of word sizes takes place with byte 7 and 8, while the transfer of double word sizes takes place with byte 5 through 8.

### Explanation of response identification

Response identification	Response Compax3 → Master
0	No response
1	Transfer value (word)
2	Transfer parameter value (double word)
4	Transfer parameter value (array of word)
5	Transfer parameter value (array of double word)
7	Order cannot be executed (with error no..)
8	No user level for PKW interface
9	Reserved
10	Reserved
14	Object value transferred
15	Object value transferred

**Example: Changing the stiffness**

**Task:**

Parameter / object change via PKW (DPV0)  
 The object "stiffness" will be set to 200%  
 Object stiffness: PNU 402.2; valid after VP  
 Format UNSIGNED 16 == 1 word == order identification = 2 == "Change parameter value (word)"  
 The master sends to Compax3:

**PLC - Compax3**

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
2											0											402																3								0								200															
0	0	1	0	0	0	0	0	1	1	0	0	1	0	0	1	0																																																					
0x21											0x92											0x3								0x0								0x0								0x0								0x0								0xC8							

Compax3 responds with the same content, except with response identification = 1:

**Compax3 - PLC**

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
1											0											402																3																200															
0	0	0	1	0	0	0	0	1	1	0	0	1	0	0	1	0																																																					
0x11											0x92											0x3								0x0								0x0								0x0								0x0								0xC8							

If no additional object needs to be changed, the new value can be set to valid with VP:  
 Object: Set objects to valid PNU 338.10 (because of DPV0, the **Subindex must be incremented by 1** (see page 357))

**PLC - Compax3**

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
2											0											338																11																1															
0	0	1	0	0	0	0	0	1	0	1	0	1	0	0	1	0																																																					
0x21											0x52											0xB								0x0								0x0								0x0								0x0								0x1							

Compax3 responds with the same content, except with response identification = 1:

**Compax3 - PLC**

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
1											0											338																11																1															
0	0	0	1	0	0	0	0	1	0	1	0	1	0	0	1	0																																																					
0x11											0x52											0xB								0x0								0x0								0x0								0x0								0x1							

Reading back the object set objects to valid makes it possible to check whether the command was performed. Byte 8 will contain the value 0.

The change can be stored and will not be lost even with a power failure by using the object "Save objects permanently".  
 Object: Save objects permanently PNU 339

**PLC - Compax3**

Octet 1										Octet 2										Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE										IND										PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-								MSB												LSB																														
<b>AK</b>										<b>PNU</b>																																																									
2										0										339																0																1															
0	0	1	0	0	0	0	0	1	0	1	0	1	0	0	1	1																																																			
0x21										0x53										0x0								0x0								0x0								0x0								0x0								0x1							

Compax3 responds with the same content, except with response identification = 1:

**Compax3 - PLC**

Octet 1										Octet 2										Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE										IND										PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-								MSB												LSB																														
<b>AK</b>										<b>PNU</b>																																																									
1										0										339																0																1															
0	0	0	1	0	0	0	1	0	1	0	1	0	0	1	1																																																				
0x11										0x53										0x0								0x0								0x0								0x0								0x0								0x1							

**Upload/download objects via the Profibus**

All settings of Compax3 can be read using the Profibus and written back to Compax3. This makes it easy to replace a device, for example.

**Condition:** Compax3 must be configured (once running through the configuration wizard followed by a download is enough; the configuration settings are, however, not relevant)  
To implement this, the PKW mechanism has been changed.

**Structure of modified PKW:**

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
PKE		IND		PWE			

PKW: Parameter identification value  
 PKE: Parameter identification (1. and 2. octet) (see below)  
 IND: Object index (3. octet high 4. octet low)  
 PWE: Parameter value (5. to 8. octet)

**Structure of modified PKE:**

Byte 1							Byte 2								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
AK=14 or 15				SPM	DF	DPZ		SI							

AK: Order/response identification  
 SPM: Reserved  
 DF: Data format (DF=1 constant)  
 DPZ: Data buffer access  
 SI: Object subindex

Data buffer access:  
 For each object, 16 bytes must be read or written. Since the size of the PWE channel is 4 bytes, each object must be read or written 4 times.

**Sequence for reading / writing and object:**

DPZ=0: Object byte 1 ... 4 can be read / is being written  
 Order executed  
 DPZ=1 Object byte 5 ... 8 can be read / is being written  
 DPZ=2 Object byte 9 ... 12 can be read / is being written  
 DPZ=3 Object byte 13 ... 16 can be read / is being written  
 The data will either be read from the PWE or written into the PWE.

**Access algorithm for reading objects**

- ◆ Object 20.2 written with value 0 (object 20.2 is a counter that specifies the next object to be read; the starting value is 0).
- ◆ Read object index and subindex in object 20.5.  
 Format I32 of Object 20.5:

Not assigned	Index (high byte)	Index (low byte)	Subindex
--------------	-------------------	------------------	----------

- ◆ Read the object with the index and subindex read in object 20.5 and in save it in a table with the following structure: Index (2Byte), Subindex(1Byte), Contents (16Byte).
- ◆ Read the next object-Index and subindex in object 20.5.
- ◆ .....

This must be performed until index = 0xFFFF and until subindex = 0xFF.

**Writing objects**

Write the entire table to Compax3. Each index and subindex is written with the value stored in the table.

It should be noted in this regard that each time an object is written, the internal buffer must first be written with DPZ=1, 2, 3 and then the entire order is written with DPZ0.

**6.4.4.2 Data formats of the bus objects**

**In this chapter you can read about:**

Integer formats..... 363  
 Unsigned - Formats ..... 363  
 Fixed point format E2\_6..... 363  
 Fixed point format C4\_3 ..... 364  
 Bus format Y2 and Y4..... 364  
 Bit sequence V2..... 365  
 Byte string OS..... 365

**Integer formats**

Twos complement representation;  
 The highest order bit (MSB) is the bit after the sign bit (VZ) in the first octet.  
 VZ == 0: positive numbers and zero; VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
<b>Integer 8</b> length: 1 Byte		VZ	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
<b>Integer 16</b>	MSB	VZ	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>
Length: 1 Word	LSB	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
<b>Integer 32</b>	MSB	VZ	2 <sup>30</sup>	2 <sup>29</sup>	2 <sup>28</sup>	2 <sup>27</sup>	2 <sup>26</sup>	2 <sup>25</sup>	2 <sup>24</sup>
Length: 2 Words		2 <sup>23</sup>	2 <sup>22</sup>	2 <sup>21</sup>	2 <sup>20</sup>	2 <sup>19</sup>	2 <sup>18</sup>	2 <sup>17</sup>	2 <sup>16</sup>
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>
	LSB	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>

**Unsigned - Formats**

Type	Bit	8	7	6	5	4	3	2	1
<b>Unsigned 8</b> Length: 1 Byte		2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
<b>Unsigned 16</b>	MSB	2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>
Length: 1 Word	LSB	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
<b>Unsigned 32</b>	MSB	2 <sup>31</sup>	2 <sup>30</sup>	2 <sup>29</sup>	2 <sup>28</sup>	2 <sup>27</sup>	2 <sup>26</sup>	2 <sup>25</sup>	2 <sup>24</sup>
Length: 2 Words		2 <sup>23</sup>	2 <sup>22</sup>	2 <sup>21</sup>	2 <sup>20</sup>	2 <sup>19</sup>	2 <sup>18</sup>	2 <sup>17</sup>	2 <sup>16</sup>
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>
	LSB	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>

**Fixed point format E2\_6**

Linear fixed point value with six binary places after the decimal point. 0 corresponds to 0, 256 corresponds to 2<sup>14</sup> (0x4000).  
 Twos complement representation;  
 MSB is the bit after the sign bit  
 VZ == 0: positive numbers and zero;  
 VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
<b>E2_6</b>	MSB	VZ	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>
Length: 1 Word	LSB	2 <sup>1</sup>	2 <sup>0</sup>	2 <sup>-1</sup>	2 <sup>-2</sup>	2 <sup>-3</sup>	2 <sup>-4</sup>	2 <sup>-5</sup>	2 <sup>-6</sup>

**Fixed point format C4\_3**

Linear fixed point value with three decimal places after the decimal point. 0 corresponds to 0 and 0.001 corresponds to  $2^0$  (0x0000 0001).  
Structure like data type Integer32, value of the bits reduced by a factor of 1000.  
Length: 2 Words

**Bus format Y2 and Y4****Layout:**

- ◆ Y2 like data type Integer16
- ◆ Y4 like data type Integer32

The values can be adjusted by a scaling factor.

The following rules apply:

- ◆ Scaling factor for Y2: Object 200.1, ... 200.5
- ◆ Scaling factor for Y4: Object 201.1, ... 201.5

There are different scaling factors for individual values

**1. Y2 scaling factors**

- ◆ Object 200.1: NormFactorY2\_Speed: Scaling factor for Y2 speeds
- ◆ Object 200.2: NormFactorY2\_Position: Scaling factor for Y2 positions
- ◆ Object 200.3: NormFactorY2\_Voltage: Scaling factor for Y2 voltages
- ◆ Object 200.5: NormFactorY2\_Array\_Col2: Scaling factor for Column 2 of the recipe array

**2. Y4 scaling factors**

- ◆ Object 201.1: NormFactorY4\_Speed: Scaling factor for Y4 speeds
- ◆ Object 201.2: NormFactorY4\_Position: Scaling factor for Y4 positions
- ◆ Object 201.3: NormFactorY4\_Voltage: Scaling factor for Y4 voltages
- ◆ Object 201.4: NormFactorY4\_Array\_Col1: Scaling factor for Column 1 of the recipe array



**Meaning of scaling factors**

◆ Bit 5: Meaning of scaling factor:

◆ Bit 5 = "0": decimal factors 1, 1/10, 1/100, ..

**Bit 0 .. Bit 4: Scaling factor**

#	Bit 0...4	Factor dec (Bit 5 = 0) yy0x xxxx	
0	00000	$10^0$	,1
1	00001	$10^{-1}$	0,1
2	00010	$10^{-2}$	0,01
3	00011	$10^{-3}$	0,001
4	00100	$10^{-4}$	0,0001
5	00101	$10^{-5}$	0,00001
6	00110	$10^{-6}$	0,000001
7	00111	$10^{-7}$	0,0000001
8	01000	$10^{-8}$	0,00000001
9	01001	$10^{-9}$	0,000000001

◆ Bit 5 = "1": binary factors 1, 1/2, 1/4, 1/8, ...

**Bit 0 ... Bit 4: Scaling factor**

#	Bit 0...4	Factor bin (Bit 5 = 1) yy1x xxxx	
32	00000	$2^0$	1
33	00001	$2^{-1}$	0,5
34	00010	$2^{-2}$	0,25
35	00011	$2^{-3}$	0,125
36	00100	$2^{-4}$	0,0625
37	00101	$2^{-5}$	0,03125
38	00110	$2^{-6}$	0,015625
39	00111	$2^{-7}$	0,0078125
40	01000	$2^{-8}$	0,00390625
41	01001	$2^{-9}$	0,001953125
42	01010	$2^{-10}$	0,0009765625
43	01011	$2^{-11}$	0,00048828125
44	01100	$2^{-12}$	0,000244140625
45	01101	$2^{-13}$	0,0001220703125
46	01110	$2^{-14}$	0,00006103515625
47	01111	$2^{-15}$	0,000030517578125
48	10000	$2^{-16}$	0,0000152587890625
49	10001	$2^{-17}$	0,00000762939453125
50	10010	$2^{-18}$	0,000003814697265625
51	10011	$2^{-19}$	0,0000019073486328125
20	10100	$2^{-20}$	0,00000095367431640625
21	10101	$2^{-21}$	0,000000476837158203125
22	10110	$2^{-22}$	0,0000002384185791015625
23	10111	$2^{-23}$	0,00000011920928955078125
24	11000	$2^{-24}$	0,000000059604644775390625

◆ Bit 6 ... Bit 15: Reserved

### Bit sequence V2

The V2 bus format is a bit sequence with a length of 16 bits.

### Byte string OS

Octet string OS: String with variable length.

### 6.4.5. Simatic S7 -300/400 - modules

You can find the modules on the Compax3 DVD or in the internet under **<http://www.compax3.info/startup>** <http://www.compax3.info/startup>.  
You will find a description of these function modules in the help file !

## 6.5 CANopen - Node Settings

### In this chapter you can read about:

CANopen - configuration .....	367
Supporting IEC modules.....	369
CANopen communication profile .....	377
Acyclic parameter channel .....	382

### I21 Function

The CANopen option is available with the Compax3 devices C3I21Txx!

### 6.5.1. CANopen - configuration

#### In this chapter you can read about:

CANopen Operating Mode .....	367
Error reaction to a bus failure .....	368
Baud rate .....	368
Possible PDO assignment.....	369
Transmission cycle time .....	369

Following are described the input windows of the CANopen configuration wizard. Can be called up in the tree (Compax3 ServoManager, left window) under "configure configuration".

#### 6.5.1.1 CANopen Operating Mode

CANopen Operating Modes:

◆ **Slave on C3 powerPLmC:**

Compax3 as Slave on C3 powerPLmC integrated via the DriveInterface  
Note for C3I21T40: The cam programming is made in the slave axis

◆ **Slave**

Compax3 is Slave of a CANopen Master; the CANopen configuration is made via the ServoManager

◆ **Slave with configuration via Master**

Compax3 is Slave of a CANopen Master; the CANopen configuration is made via the Master

◆ **Master for PIOs**

Compax3 as CANopen Master only for the operation of external digital and analog PIOs (Parker Input and Output modules).

Please note: The device cannot be operated with an additional CANopen Master!

◆ **Slave on C3 powerPLmC (Cam programming on C3 powerPLmC)**

Operating mode only available with I21T40!

The programming of the device (C3I21T40) is only made on the C3 powerPLmC.

**C3 Master PIO**

In the "C3 Master PIO" operating mode, the input window for the CANopen PIO mapping is following:  
 Please state, how many words the process image of the PIOs will need, 1.. 4 words are possible.  
 The process image is transmitted via teh process data objects as follows:  
 Digital Inputs: RPDO1  
 Analog Inputs: RPDO2  
 Digital Outputs: TPDO1  
 Analog Outputs: TPDO2  
 The inputs and outputs are stored in objects (O150.x ... O153.x).  
 Object 150.x: Digital Inputs  
 Object 151.x: Digital Outputs  
 Object 152.x: Analog Inputs  
 Object 153.x: Analog Outputs  
 The digital inputs and outputs can be read or written into in the IEC program via **modules** (see page 309) in order to get an exact process image. Modules: PIO\_Input0\_15, PIO\_Input16\_31, PIO\_Input32\_47, PIO\_Input48\_63, PIO\_Output0\_15, PIO\_Output16\_31, PIO\_Output32\_47, PIO\_Output48\_63.  
 Before that, you must execute some initializations; this can be made with the aid of the **PIO\_INIT** (see page 309) module.

**6.5.1.2 Error reaction to a bus failure**

Here you can adjust how Compax3 will respond to a fieldbus error:  
 Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

**6.5.1.3 Baud rate**

Selecting the Baud rate.  
 Bear in mind that the maximum cable length depends on the Baud rate:

Baud rate	Maximum length
1Mbit/s	25m
800kbit/s	50m
500kbit/s	100m
250kbit/s	250m
125kbit/s	500m
100kbit/s	700m
50kbit/s	1,000m
20kbit/s	2,500m

### 6.5.1.4 Possible PDO assignment

Via the process data objects (PDOs) actual values and Setpoint values are continually exchanged between Compax3 and the CANopen client.  
4 cyclic PDOs are possible, they are configured with the help of the Compax3 ServoManager:

The PDOs are set separately for the transmission directions

- ◆ CANopen - Client ⇒ Compax3 (**RPDO**) (max. 16 words)
- ◆ Compax3 ⇒ CANopen - Client (**TPDO**) (max. 16 words)

The objects that can be put on the process data channel can be found in the "**Compax3 Objects** (see page 414)"!

### 6.5.1.5 Transmission cycle time

For the TPDOs a transmission cycle time can be set in each case.  
This time specifies the time intervals at which Compax3 applies the cyclic data new to the respective PDO.  
The minimum value is thereby 1ms.


## 6.5.2. Supporting IEC modules

### In this chapter you can read about:


C3_CANopen_State .....	370
C3_CANopen_GuardingState .....	371
C3_CANopen_AddNode .....	372
C3_CANopen_ConfigNode .....	373
C3_CANopen_NMT .....	374
Reading an object in another node (C3_CANopen_SDO_Read4) .....	375
Writing an object in another node (C3_CANopen_SDO_Write4) .....	376

**6.5.2.1 C3\_CANOpen\_State**

<b>FB name</b>	<b>C3_CANOpen_State</b>	
This module is used to determine the status of the CANopen NMT status machine		
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activating the module
<b>VAR_OUTPUT</b>		
<b>Stopped</b>	BOOL	CANopen node is in "Stopped" state
<b>Operational</b>	BOOL	CANopen node is in the "Operational" state (communication via process data and service data objects is possible)
<b>PreOperational</b>	BOOL	CANopen node is in the "PreOperational" state (communication via process data and service data objects is possible)



**CANopen states**




- 6: Start Remote Node
- 7: Stop Remote Node
- 8: Enter Pre-Operational State
- 10: Reset Node
- 11: Reset Communication

The "Initialization" state is no fixed state but only a transition state.


**6.5.2.2 C3\_CANopen\_GuardingState**

<b>FB name</b>	<b>C3_CANopen_GuardingState</b>	
This module is used to determine the status during Nodeguarding		
<b>VAR_INPUT</b>		
<b>Enable</b>	BOOL	Activating the module
<b>VAR_OUTPUT</b>		
<b>GuardingStarted</b>	BOOL	The NMT master started the Nodeguarding procedure
<b>LostGuarding</b>	BOOL	The node did not receive a Nodeguarding RTR telegram from the NMT master during the Guarding time.
<b>LostConnection</b>	BOOL	The node did not receive a RTR telegram from the NMT Master during the "Node Life Time" (GuardingTime * LifeTimeFactor) and therefore considers the connection as interrupted.



**6.5.2.3 C3\_CANopen\_AddNode**


<b>FB name</b>	<b>C3_CANopen_AddNode</b>	
This module inserts a new CANopen node into the management list of the NMT master with the stated Node Guarding parameters and the current CANopen status PRE_OPERATIONAL.		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activating the module
<b>Device</b>	INT	Node-ID (1 ... 127)
<b>GuardTime</b>	INT	Guard time = 0
<b>LifeTimeFactor</b>	INT	Life Time Factor = 0
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Function executed without error
<b>Error</b>	BOOL	Error occurred
<b>ErrorCode</b>	WORD	You will find the error code in the Compax3 error list.
<b>AbortCode</b>	DWORD	CANopen SDO <b>abort code</b> (see page 383) upon error 65377 C3 CANopen <b>stack error</b> (see page 374) no. upon error 65376
<b>MyNode_ID</b>	INT	Own Node_ID (NMT master)
Note: Compax3 must be CANopen master.		






**6.5.2.4 C3\_CANopen\_ConfigNode**

<b>FB name</b>	<b>C3_CANopen_ConfigNode</b>	
This module establishes a PDO connection between two CANopen nodes. To do this, the module changes the COB-Ids of the 2nd node (RemoteDevice) to the COB-Ids of the 1st node (ReferenceDevice).		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activating the module
<b>ReferenceDevice</b>	INT	Node ID of the 1st node (1 ... 127)
<b>RemoteDevice</b>	INT	Node ID of the 2nd node (1 ... 127)
<b>ReferenceTxPDO</b>	INT	TxPDO number of the 1st node (1 ... 4)
<b>RemoteRxPDO</b>	INT	TxPDO number of the 2nd node (1 ... 4)
<b>ReferenceRxPDO</b>	INT	RxPDO number of the 1st node (1 ... 4)
<b>RemoteTxPDO</b>	INT	TxPDO number of the 2nd node (1 ... 4) "0" do not establish connection
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Function executed without error
<b>Error</b>	BOOL	Error occurred
<b>ErrorCode</b>	WORD	You will find the error code in the Compax3 error list.
<b>AbortCode</b>	DWORD	CANopen SDO <b>abort code</b> (see page 383) upon error 65377 C3 CANopen <b>stack error</b> (see page 374) no. upon error 65376
Note: Compax3 must be CANopen master.		




**6.5.2.5 C3\_CANOpen\_NMT**

<b>FB name</b>		<b>C3_CANOpen_NMT</b>
This module allows to send NMT messages.		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activating the module
<b>Device</b>	INT	Node ID (0 ... 127) 0 = NMT-message is valid for all nodes
<b>State</b>	INT	State which the node must take on: START_REMOTE_NODE STOP_REMOTE_NODE ENTER_PRE_OPERATIONAL RESET_NODE RESET_COMMUNICATION (these are no constants; please enter therefore directly)
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Function executed without error
<b>Error</b>	BOOL	Error occurred
<b>ErrorCode</b>	WORD	CANopen-Stack error no. 1 = not sufficient memory 2 = node is not in the management list 3 = node is already in the management list 4 = nodes are in the wrong state 11 = network object not available 12 = node 0 was selected 65378 = C3 has no master functionality
Note: Compax3 must be CANopen master.		




**6.5.2.6 Reading an object in another node (C3\_CANopen\_SDO\_Read4)**

<b>FB name</b>	<b>C3_CANopen_SDO_Read4</b>	
This module allows to read an object with a max. length of 4 bytes in another node via SDO.		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activating the module
<b>Device</b>	INT	Node ID of the other node (1 ... 127)
<b>Index</b>	WORD	Object Index (CAN-No.)
<b>Subindex</b>	WORD	Object Subindex (CAN-No.)
<b>VAR_OUTPUT</b>		
<b>Data</b>	DWORD	Object data read in
<b>Length</b>	WORD	Data length in Byte
<b>Done</b>	BOOL	Function executed without error
<b>Error</b>	BOOL	Error occurred
<b>ErrorCode</b>	WORD	You will find the error code in the Compax3 error list.
<b>AbortCode</b>	DWORD	CANopen SDO <b>abort code</b> (see page 383) upon error 65377 C3 CANopen <b>stack error</b> (see page 374) no. upon error 65376
Note: Compax3 must be CANopen master.		



**6.5.2.7 Writing an object in another node (C3\_CANopen\_SDO\_Write4)**

<b>FB name</b>	<b>C3_CANopen_SDO_Write4</b>	
This module allows to write an object with a max. length of 4 bytes in another node via SDO.		
<b>VAR_INPUT</b>		
<b>Execute</b>	BOOL	Activating the module
<b>Device</b>	INT	Node ID of the other node (1 ... 127)
<b>Index</b>	WORD	Object Index
<b>Subindex</b>	WORD	Object subindex
<b>Data</b>	DWORD	Object data which must be written
<b>Length</b>	WORD	Data length in Byte
<b>VAR_OUTPUT</b>		
<b>Done</b>	BOOL	Function executed without error
<b>Error</b>	BOOL	Error occurred
<b>ErrorCode</b>	WORD	You will find the error code in the Compax3 error list.
<b>AbortCode</b>	DWORD	CANopen SDO <b>abort code</b> (see page 383) upon error 65377 C3 CANopen <b>stack error</b> (see page 374) no. upon error 65376
Note: Compax3 must be CANopen master.		



### 6.5.3. CANopen communication profile

The CANopen communication objects described in this chapter are either set to sensible standard values or they are set under menu control with the help of the ServoManager.

The communication objects described below must be modified only for special deviating settings.

- ◆ CAN is an open system which has been standardised in the ISO 11898 and OSI reference model ISO 7498.
- ◆ CAN is Multi-Master compatible.
- ◆ Data transmission takes place with up to 8 Bytes useful data.
- ◆ The CAN objects are designated with an 11 Bit identifier (ID or COB-ID: CAN Object identifier). The identifier specifies the priority of the objects (the smaller the value of the object ID is, the higher is the priority level of the object).
- ◆ The COB-ID consists of the function code and the node ID:

#### Structure of the COB-ID

Bit 10	9	8	7	6	5	4	3	2	1	0
Function code						NodeID (1 ... 127)				

NodeID: The Compax3 device address is used here as standard value

#### I21 Function

#### CANopen ratings

Baud rate [kBit/s]	◆ 20, 50, 100, 125, 250, 500, 800, 1000
EDS file	◆ C3.EDS
Service data object	◆ SDO1
Process data objects	◆ PDO1, ... PDO4

### 6.5.3.1 Object types

The following table shows the preset COB-IDs:

Communication object type	Function code	COB - Identifier (dec)	COB - Identifier (hex)	Defined in Index...	Description	
<b>Broadcast objects</b>						
NMT	0000b	0	0h	-	Network management and identifier assignment	
SYNC	0001b	128	80h	1005h	CANSYNC	
TIME	0010b	256	100h	1012h	TIME is not implemented in Compax3.	
<b>Point to point objects</b>						
EMCY	0001b	129-255	81h-FFh	1014h	Error messages	
T-PDO1	0011b	385-511	181h-1FFh	1800h	Assignment via Index 1A00h	Transmit process data object (Compax3) max. 8 Bytes
T-PDO2	0101b	641-767	281h-2FFh	1801h	Assignment via Index 1A01h	
T-PDO3	0111b	897-1023	381h-3FFh	1802h	Assignment via Index 1A02h	
T-PDO4	1001b	1153-1279	481h-1279h	1803h	Assignment via Index 1A03h	
R-PDO1	0100b	513-639	201h-27Fh	1400h	Assignment via Index 1600h	Receive process data objects (Compax3) max. 8 Bytes
R-PDO2	0110b	769-895	301h-37Fh	1401h	Assignment via Index 1601h	
R-PDO3	1000b	1025-1151	401h-47Fh	1402h	Assignment via Index 1602h	
R-PDO4	1010b	1281-1407	501h-57Fh	1403h	Assignment via Index 1603h	
T-SDO1	1011b	1409-1535	581h-5FFh	1200h	Transmit service data object 1	
T-SDO2	-*	-*	-	1201h	Transmit service data object 2	
R-SDO1	1100b	1537-1663	601h-67Fh	1200h	Receive service data object 1	
R-SDO2	-*	-*	-	1201h	Receive service data object 2	
Node guard	1110b	1793-1919	701h-77Fh	100Eh	Check bus subscribers.	

\* The SDO2 are not activated.

The standard value of the COB-ID for an object is calculated as follows: COB-ID = (Function code \* 128) + Device address

The standard values of the COB-IDs can be changed via communication objects via SDOs.

#### Application of the communication object types

##### Transmission of real time data (faster transmission because higher priority)

**T-PDO** Transmit process data object: Compax3 reply.

**R-PDO** Receive process data object: send to Compax3.

##### Once only transmission, e. g. of parameters or programme lines

**T-SDO** Transmit service data object: Compax3 reply.

**R-SDO** Receive service data object: send to Compax3.

### 6.5.3.2 Communication objects

General note:

Every CAN object which is created as array (with subindex) contains the number of entries in subindex 0.

**CAN communication objects overview sorted according to CAN No.**

CAN-No	Name	Bus format	Standard value	Minimum value	Maximum value	Access
0x1000	Device Type	Unsigned32	0x00020192	0x00000000	0xFFFFFFFF	const
0x1001	Error Register	Unsigned8	0x00	0x00	0xFF	ro
0x1005	COB-ID SYNC	Unsigned32	0x80000080	0x00000001	0xFFFFFFFF	rw
0x1006	Communication Cycle Period	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1007	Synchronous Window Length	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1008	Manufacturer Device Name	Visible_String	C3xxxxxxxxxxxxxxxxxx			const
0x1009	Manufacturer Hardware Version	Visible_String	CTPxxxxxxxxLEIxxxxxxx			const
0x100A	Manufacturer Software Version	Visible_String	Vxxxxxxxxxxxxxxxxxxxx			const
0x100C	Guard Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x100D	Life Time Factor	Unsigned8	0x00	0x0	0xFF	rw
0x1014	COB-ID EMCY	Unsigned32	0x000000FF	0x00000001	0xFFFFFFFF	rw
0x1015	Inhibit Time Emergency	Unsigned16	0x0	0x0	0xFFFF	rw
0x1018	<b>Identity Object</b> (see page 381)	-				
0x1018.1	Vendor Id	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.2	Product Code	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.3	Revision number	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.4	Serial number	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1200	Server SDO1 Parameter	-				
0x1200.1	SDO1: COB-ID Client -> Server	Unsigned32	0x0000067F	0x00000001	0xFFFFFFFF	ro
0x1200.2	SDO1: COB-ID Server -> Client	Unsigned32	0x000005FF	0x00000001	0xFFFFFFFF	ro
0x1200.3	Node ID of the SDO1 client	Unsigned8	0x00	0x00	0xFF	rw
0x1201	Server SDO2 Parameter	-				
0x1201.1	SDO2: COB-ID Client -> Server	Unsigned32	0x800006E0	0x00000001	0xFFFFFFFF	rw
0x1201.2	SDO2: COB-ID Server -> Client	Unsigned32	0x800006E0	0x00000001	0xFFFFFFFF	rw
0x1201.3	Node ID of the SDO2 Client	Unsigned8	0x00	0x00	0xFF	rw
0x1400	Receive PDO1 communication parameters	-				
0x1400.1	RPDO1: COB-ID	Unsigned32	0x0000027F	0x00000001	0xFFFFFFFF	rw
0x1400.2	RPDO1: Transmission type	Unsigned8	0xFE	0x00	0xFF	rw
0x1400.3	RPDO1: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1400.5	RPDO1: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1401	Receive PDO2 communication parameters	-				
0x1401.1	RPDO2: COB-ID	Unsigned32	0x0000037F	0x00000001	0xFFFFFFFF	rw
0x1401.2	RPDO2: Transmission type	Unsigned8	0xFE	0x00	0xFF	rw
0x1401.3	RPDO2: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1401.5	RPDO2: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1402	Receive PDO3 communication parameter	-				
0x1402.1	RPDO3: COB-ID	Unsigned32	0x0000047f	0x0	0xFFFFFFFF	rw
0x1402.2	RPDO3: Transmission type	Unsigned8	0xFE	0x0	0xFF	rw
0x1402.3	RPDO3: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1402.5	RPDO3: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1403	Receive PDO4 communication parameter	-				
0x1403.1	RPDO4: COB-ID	Unsigned32	0x0000057f	0x0	0xFFFFFFFF	rw
0x1403.2	RPDO4: Transmission type	Unsigned8	0xFE	0x0	0xFF	rw
0x1403.3	RPDO4: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1403.5	RPDO4: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1600	Receive PDO1 mapping parameter	-				
0x1600.1	RPDO1 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.2	RPDO1 mapping entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.3	RPDO1 mapping entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.4	RPDO1 mapping entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.5	RPDO1 mapping entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw

CAN-No	Name	Bus format	Standard value	Minimum value	Maximum value	Access
0x1601	Receive PDO2 mapping parameter	-				
0x1601.1	RPDO2 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.2	RPDO2 mapping entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.3	RPDO2 mapping entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.4	RPDO2 mapping entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.5	RPDO2 mapping entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1602	Receive PDO3 mapping parameter	-				
0x1602.1	RPDO3 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.2	RPDO3 mapping entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.3	RPDO3 mapping entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.4	RPDO3 mapping entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.5	RPDO3 mapping entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603	Receive PDO3 mapping parameter	-				
0x1603.1	RPDO4 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.2	RPDO4 mapping entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.3	RPDO4 mapping entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.4	RPDO4 mapping entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.5	RPDO4 mapping entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1800	Transmit PDO1 communication parameter	-				
0x1800.1	TPDO1: COB-ID	Unsigned32	0x000001FF	0x00000001	0xFFFFFFFF	rw
0x1800.2	TPDO1: Transmission type	Unsigned8	0xFE	0x00	0xFF	rw
0x1800.3	TPDO1: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1800.5	TPDO1: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1801	Transmit PDO2 communication parameter	-				
0x1801.1	TPDO2: COB-ID	Unsigned32	0x000002FF	0x00000001	0xFFFFFFFF	rw
0x1801.2	TPDO2: Transmission type	Unsigned8	0xFE	0x00	0xFF	rw
0x1801.3	TPDO2: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1801.5	TPDO2: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1802	Transmit PDO3 communication parameter	-				
0x1802.1	TPDO3: COB-ID	Unsigned32	0x000003ff	0x0	0xFFFFFFFF	rw
0x1802.2	TPDO3: Transmission type	Unsigned8	0xFE	0x0	0xFF	rw
0x1802.3	TPDO3: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1802.5	TPDO3: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1803	Transmit PDO4 communication parameter	-				
0x1803.1	TPDO4: COB-ID	Unsigned32	0x000004ff	0x0	0xFFFFFFFF	rw
0x1803.2	TPDO4: Transmission type	Unsigned8	0xFE	0x0	0xFF	rw
0x1803.3	TPDO4: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1803.5	TPDO4: Event timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1A00	Transmit PDO1 mapping parameter	-				
0x1A00.1	TPDO1 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.2	TPDO1 mapping entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.3	TPDO1 mapping entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.4	TPDO1 mapping entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.5	TPDO1 mapping entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01	Transmit PDO2 mapping parameter	-				
0x1A01.1	TPDO2 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.2	TPDO2 mapping entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.3	TPDO2 mapping entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.4	TPDO2 mapping entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.5	TPDO2 mapping entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A02	Transmit PDO3 mapping parameter	-				
0x1A02.1	TPDO3 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.2	TPDO3 mapping entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.3	TPDO3 mapping entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.4	TPDO3 mapping entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw



CAN-No	Name	Bus format	Standard value	Minimum value	Maximum value	Access
0x1A02.5	TPDO3 mapping entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03	Transmit PDO4 mapping parameter	-				
0x1A03.1	TPDO4 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.2	TPDO4 mapping entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.3	TPDO4 mapping entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.4	TPDO4 mapping entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.5	TPDO4 mapping entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw

### Identity Object (0x1018)

This object is composed as follows:

#### Vendor-ID (0x1018.1)

Is stored in the FBI-EEPROM binarily from addr. 56...59 (low...high). Current value = 0x02000089.

#### Product-Code (0x1018.2)

Is composed of the part of the order code "Faa lbb Tcc Mdd" to 0xaabbcddd, i.e. the device with the order code C3S025V2F10I21T40M11 has the product code 0x10214011.

The product code is hex coded, but can be read decimally.

#### Revision number (0x1018.3)

Is composed of 5 digits of the software version no. of the DSP software and 3 digits of the SV no. of the FBI softwre, i.e. the device with the DSP SV no. 01.08.02 and the FBI SV no. 1.21 has the revision no. 0x10802121.

#### Serial number (0x1018.4)

Is stored in the CTP-EEPROM as a 10 digit ASCII string from addr. 56...65 (series number of the device). A C3 with the series number 1423440001 has the serial number 0x54D7F881.

### Communication objects

The description of the CANopen communication objects can be found in the corresponding help file.

## 6.5.4. Acyclic parameter channel

### In this chapter you can read about:

Service Data Objects (SDO).....	382
Object up-/download via RS232 / RS485 .....	384
Data formats of the bus objects.....	384

### 6.5.4.1 Service Data Objects (SDO)

Asynchronous access to the object directory of Compax3 is implemented with the help of the SDOs. The SDOs serve for parameter configuration and status interrogation. Access to an individual object takes place via the RS232 / RS485 index and subindex of the object directory.

#### **Attention!**

**A SDO is a confirmed service, therefore the SDO reply telegram must always be awaited before a new telegram may be transmitted.**

**CiA405\_SDO\_Error (Abort Code): UDINT**

In the case of an incorrect SDO transmission, the error cause is returned via the "abort code".

<b>Abort Code</b>	<b>Description</b>
0x0503 0000	" Toggle Bit" was not alternated
0x0504 0000	SDO protocol "time out"
0x0504 0001	Client/server command designator invalid or unknown
0x0504 0002	Unknown block size (block mode only)
0x0504 0003	Unknown block number (block mode only)
0x0504 0004	CRC error (block mode only)
0x0504 0005	Outside of memory
0x0601 0000	Access to this object is not supported
0x0601 0001	Attempted read access to a write only object
0x0601 0002	Attempted write access to a read only object
0x0602 0000	The object does not exist in the object directory
0x0604 0041	The object cannot be "mapped" in a PDO
0x0604 0042	The size and number of the "mapped" objects exceeds the maximum PDO length
0x0604 0043	General parameter incompatibility
0x0604 0047	General incompatibility in the device
0x0606 0000	Access infringement due to a hardware error
0x0607 0010	Data type does not fit, length of the service parameter does not fit
0x0607 0012	Data type does not fit, length of the service parameter too large
0x0607 0013	Data type does not fit, length of the service parameter too small
0x0609 0011	Subindex does not exist
0x0609 0030	Outside parameter value range (only for write access operations)
0x0609 0031	Parameter value too large
0x0609 0032	Parameter value too small
0x0609 0036	Maximum value smaller than minimum value
0x0800 0000	General error
0x0800 0020	Date cannot be transmitted or saved
0x0800 0021	Date cannot be transmitted or saved due to local device management
0x0800 0022	Date cannot be transmitted or stored due to device status
0x0800 0023	Dynamic generation of the object directory is impossible or no object directory exists (the object directory is created from a file and an error occurs due to a defective file)

### 6.5.4.2 Object up-/download via RS232 / RS485

The up-/download takes place via the RS232 / RS485 objects C3\_Request (Index 0x2200) and C3\_Response (Index 0x2201). These have the data type data type octet string with a length of 20 bytes (octets). Write/read of a C3 object is carried out by writing of C3\_Request with the corresponding data. When a C3 object is read, the data appear in the C3\_Response object .

#### Meaning of the data from C3\_Request

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	...	...	Byte 19	Byte 20		
Request header				C3 object data (write)							
AK	Subindex	Index		D1	D2	...	...	D15	D16		

AK: Job identifier; 3=read, 4= write

OD1..OD16: Object data; OD1 = High, OD16 = Low

#### Meaning of the data from C3\_Response

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	...	...	Byte 19	Byte 20		
Reply header				C3 object data (read)							
-	-	-	-	OD1	OD2	...	...	OD15	OD16		

OD1..OD16: Object data; OD1 = High, OD16 = Low

#### Upload

RS232 / RS485	O 1	O 2	O 3	O 4	O 5	O 6	O 7	O 8	...	O 20	
Access	Object		C3 object request/reply				C3 object data				
1. Write C3 object 20.2 with the value 0											
Write	0x2200.0	4	2	0	20	0	0	0	x	...	x
2. read next C3 object index/subindex in C3 object 20.5											
Write	0x2200.0	3	5	0	20	x	x	x	x	...	x
Read	0x2201.0	x	x	x	x	I_hi	I_lo	Subi	x	...	x
3. read the C3 object with the in index/subindex read in the C3 object 20.5											
Write	0x2200.0	3	Subi	I_hi	I_lo	x	x	x	x	...	x
Read	0x2201.0	x	x	x	x	D1	D2	D3	D4	...	D16
4. Store C3 object index, subindex and data D1...D16 in table											
5. Repeat steps 2 to 4 until I_hi = I_lo = Subi = 0xFF											

#### Download: Write the entire table of C3 objects.

RS232 / RS485	O 1	O 2	O 3	O 4	O 5	O 6	O 7	O 8	...	O 20	
Access	Object		C3 object request/reply				C3 object data				
1. Write C3 object from the table											
Write	0x2200.0	4	Subi	I_hi	I_lo	D1	D2	D3	D4	...	D16
2. Repeat step 1 until the end of the table											

### 6.5.4.3 Data formats of the bus objects

Data formats of the bus objects (see page 363)

## 6.6 DeviceNet

### In this chapter you can read about:

DeviceNet Configuration.....	385
DeviceNet object classes .....	386
Data formats of the bus objects.....	387

### I22 Function

#### **Please note:**

**A changed assignment (mapping) of the Input/Output Message is accepted with Power off / Power on!**

**The length of the Input / Output Message is adapted to the real assignment (mapping) (2...32).**

#### **Statement of Conformance**

[http://www.compax3.de/C3\\_DeviceNet\\_Statement\\_of\\_Conformance.pdf](http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf) (in the Internet)

**Address or Baud rate settings** (see page 35)

**Connector assignment** (see page 35)

### 6.6.1. DeviceNet Configuration

#### In this chapter you can read about:

Error reaction to a bus failure .....	385
---------------------------------------	-----

Following are described the input windows of the configuration wizard. Can be called up in the tree (Compax3 ServoManager, left window) under "configure configuration".

#### 6.6.1.1 Error reaction to a bus failure

Here you can adjust how Compax3 will respond to a fieldbus error: Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

## 6.6.2. DeviceNet object classes

**In this chapter you can read about:**

Overview of the DeviceNet object classes ..... 387  
 Object classes ..... 387

The DeviceNet object classes described in this chapter are either set to sensible standard values or they are set under menu control with the help of the ServoManager.

The communication objects described below must be modified only for special deviating settings.

**I22 Function**

**DeviceNet characteristic data**

<b>DeviceNet</b>	<ul style="list-style-type: none"> <li>◆ Predefined Master/Slave Connection Set</li> <li>◆ Standard 2.0 Group-2-Slave</li> <li>◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)</li> </ul>
<b>Implemented object classes</b>	<ul style="list-style-type: none"> <li>◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler</li> </ul>
<b>Baud rate [kBit/s]</b>	<ul style="list-style-type: none"> <li>◆ 125, 250, 500</li> </ul>
<b>permissible cable length</b>	<ul style="list-style-type: none"> <li>◆ up to 500m on 125Bit/s,</li> <li>◆ up to 200m on 250Bit/s,</li> <li>◆ up to 100m on 500Bit/s,</li> </ul>
<b>Max. number of nodes</b>	<ul style="list-style-type: none"> <li>◆ 63 Slave</li> </ul>
<b>Insulation</b>	<ul style="list-style-type: none"> <li>◆ Isolated Device Physical Layer</li> </ul>
<b>EDS file</b>	<ul style="list-style-type: none"> <li>◆ C3_DeviceNet.EDS</li> </ul>
<b>Conformance (file in the Internet)</b>	<ul style="list-style-type: none"> <li>◆ <b>Statement of Conformance</b>  <a href="http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf">http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf</a></li> </ul>
<b>Further information:</b>	<ul style="list-style-type: none"> <li>◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory</li> </ul>

### 6.6.2.1 Overview of the DeviceNet object classes

Object name	Class ID	Instance ID	Description
Identify	0x01	1	Mandatory
Message Router	0x02	1	Mandatory
DeviceNet	0x03	1	Mandatory
Assembly	0x04	101-103	I/O Messages
Connection	0x05	1	Explicit Messages
		2	Polled I/O Data
		3	Bit Strobe
		4	Change of State (COS), Cyclic I/O Data
Acknowledge Handler	0x2B	1	Necessary for connection class ID 05hex, instance ID 04
Image of I/O Data	0x64	1	Manufacturer-specific object class image of I/O data
C3 object	0x65	20-3300	Manufacturer-specific object class C3 object

### 6.6.2.2 Object classes

Detailed information on the topic of "object classes" can be found in the online help of the device.

### 6.6.3. Data formats of the bus objects

Data formats of the bus objects (see page 363)

## 6.7 Ethernet Powerlink

### In this chapter you can read about:

Configuring Ethernet Powerlink / EtherCAT .....	388
---	-----

**The Ethernet Powerlink option is available with the Compax3 devices C3I30Txx!**

**The EtherCAT option is available with the Compax3 devices C3I31Txx!**

### 6.7.1. Configuring Ethernet Powerlink / EtherCAT

#### In this chapter you can read about:

CN Controlled Node (Slave) .....	388
Slave with configuration via master .....	388
Error reaction to a bus failure .....	388
Possible PDO assignment .....	389

Following are described the input windows of the Ethernet Powerlink / EtherCAT configuration wizard.

Can be called up in the tree (Compax3 ServoManager, left window) under "configure configuration".

#### 6.7.1.1 CN Controlled Node (Slave)

Compax3 is the slave of an Ethernet / EtherCAT master; the bus configuration is made via the ServoManager

#### 6.7.1.2 Slave with configuration via master

Select "Slave with configuration via master". for operating mode and mapping via master.

Then run through the wizard completely.

#### 6.7.1.3 Error reaction to a bus failure

Here you can adjust how Compax3 will respond to a fieldbus error:

Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)



#### 6.7.1.4 Possible PDO assignment

Via the process data objects (RPDO and TPDO), actual values and Setpoint values are cyclically exchanged between Compax3 and the Ethernet Powerlink Controlled Nodes (Slaves).

The cyclic PDOs are configured with the aid of the Compax3 ServoManager:

The PDOs are set separately for the transmission directions

- ◆ Slave ⇒ Compax3 (**RPDO**)
- ◆ Compax3 ⇒ Slave (**TPDO**)

The objects that can be put on the process data channel can be found in the "**Compax3 Objects** (see page 414)"!

## 6.8 HEDA Bus

### In this chapter you can read about:

HEDA standard mode.....	391
HEDA expansion (HEDA advanced).....	393
Coupling objects.....	412

HEDA: **H**igh **E**fficiency **D**ata **A**ccess: Option M10 or M11

- ◆ Real-time data transfer
- ◆ High-stage axis synchronization
- ◆ fixed transfer rate of 10MBit/s
- ◆ Jitter < 300ns (Bus) which results in a high synchronicity
- ◆ Peer-to-Peer communication
- ◆ maximum cable length 50m (greater lengths on request)
- ◆ 1 Master / 31 Slave: Individual HEDA axis address in the range between 1...32
- ◆ fixed cycle time of 0.5ms
- ◆ Synchronization of the scanning grid of the digital control loops and of the setpoint generation
- ◆ cyclic data exchange
- ◆ acyclic data exchange of time-uncritical values

**HEDA wiring** (see page 448)

### Function of the HEDA LEDs

#### Green LED (left)

HEDA module energized

#### Red LED (right)

Error in the receive area

Possible causes:

- ◆ at the Master
  - ◆ no slave sending back
  - ◆ Wrong cabling
  - ◆ Terminal plug is missing
  - ◆ several masters are sending in the same slot
- ◆ at the slave
  - ◆ several masters in the system
  - ◆ no master active
  - ◆ Terminal plug is missing
  - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)

#### The configuration may take place in two different ways:

- ◆ HEDA standard: Simple Master -> Slave communication
- ◆ HEDA advanced: Communication Master <-> Slave and Slave <-> Slave.

## 6.8.1. HEDA standard mode

### In this chapter you can read about:

Error reaction to a bus failure .....	391
HEDA-Master .....	392
HEDA-Slave .....	392

The HEDA option (option M10 or M11) can be used to send 4 process values in the "HEDA standard" operating mode from master to slave. A return transmission from Slave to Master is possible with "HEDA advanced".

First choose, if Compax3 is HEDA Master or HEDA Slave:

- ◆ HEDA master: in order to send process values
- ◆ HEDA slave: in order to receive process values

**Please respect that only 1 HEDA station can be Master.**

- ◆ Error reaction (from Compax3) at bus failure:
  - ◆ activated: Compax3 switches to error state in the case of a bus error. (Error reaction 2: Downramp / apply brake / de-energize.)
  - ◆ deactivated: Compax3 will ignore a bus error.

### 6.8.1.1 Error reaction to a bus failure

Here you can adjust how Compax3 will respond to a fieldbus error:  
Possible settings for the error reaction are:

- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)


### 6.8.1.2 HEDA-Master

You can transmit 4 process values with max. 7 words (one process value per channel).

The 1st process value (takes 3 words) is reserved for the axis synchronization. You may choose between:

- ◆ Process - setpoint position (Object 2000.1)
- ◆ Process - actual position (Object 2200.2)
- ◆ Position from external setpoint (object 2020.1)  
Signal read in via Analog channel 4 (X11/17 and X11/18), encoder input or step / direction input in the master.

Principle:



#### **Attention in the case of a configuration download with master-slave coupling (electronic gearbox, cam)**

Switch Compax3 to currentless before starting the configuration download: Master and Slave axis

- ◆ Position from virtual Master (object 2000.2)

You can transmit 3 additional process values with 4 words data max. You can make your choice between the Compax3 PD objects.

**Note:** Please use the **coupling objects** (see page 412) for axis coupling.

### 6.8.1.3 HEDA-Slave

The transferred process values can be read and assigned to objects in the configuration wizard (e.g. array objects) in the HEDA slave.

Objects with appropriate data width (corresponding to the process values read in) must be assigned.

The 1st process value is used as input process value (object 3920.1: HEDA SignalProcessing Input) for axis synchronization. The target for the process values 2, 3, 4 can be selected from a list in the configuration wizard.

## 6.8.2. HEDA expansion (HEDA advanced)

### In this chapter you can read about:

The possibilities of the HEDA expansion .....	393
Technical data of the HEDA interface / overview .....	394
Definitions .....	395
Calling up the HEDA wizard in the C3 ServoManager .....	395
Configuration of the HEDA communication .....	395

### 6.8.2.1 The possibilities of the HEDA expansion

The HEDA option (option M10 or M11) can be used to exchange process values in the "HEDA advanced" operating mode.

- ◆ from Slave to Master
- ◆ from Slave to Master and
- ◆ from Slave to Slave.

## 6.8.2.2 Technical data of the HEDA interface / overview


### General HEDA data

- ◆ Synchronous, bidirectional, deterministic real-time bus.
- ◆ Bus access via time sharing (slots), Master/Slave, Producer/Consumer. (synchronization exactitude  $<1\mu\text{s}$ ).
- ◆ Bus cycle time  $500\mu\text{s}$ , distributed into 20 time slots à  $25\mu\text{s}$ .
- ◆ 18 slots cyclic transmitting and receiving data channels (Slot 0 .. 17).
- ◆ 2 slots reserved for acyclic communication.
- ◆ Telegrams (frames) with max. 7 words à 16 bit can be sent and received in a slot.
- ◆ Freely configurable assignment of the cyclic transmit(Tx)/receive(rx)-slots to the stations.
- ◆ The transmitting and receiving data are freely definable via mapping tables.
- ◆ Master-Slave as well as Slave-Slave communication (cross-communication) are possible.
- ◆ A master=>slave frame in slot x can be received by every slave.
- ◆ A slave=>slave frame (cross-communication) in slot x can be received by every bus node.

### Compax3-specific HEDA data:

- ◆ The Compaxa3 system cycle time is synchronized with the bus cycle time.
- ◆ System cycle time  $500\mu\text{s}$ , distributed into 4 position control cycles à  $125\mu\text{s}$ .
- ◆ For system-immanent reasons, only one slot is able to send and receive during the same position control cycle (every  $125\mu\text{s}$ ).
- ◆ Transmit- and receive slot can differ within one position controller cycle.
- ◆ The Master can receive frames from 4 slaves max.

### Principle:



Displayed are the number of the possible telegrams (Frames).

**6.8.2.3 Definitions**

DSP Format	Objects with this format: <ul style="list-style-type: none"> <li>◆ are not reset</li> <li>◆ are unlimited: you have a value range between <math>2^{23}</math> and <math>2^{23}-1</math></li> <li>◆ are suitable as coupling objects</li> </ul> If the DSP Format is not selected, the objects are transmitted into the <b>described formats</b> (see page 414). Please note that the <b>Bus formats Y2 and Y4</b> (see page 364) are set against the scaling factors.
Frame	Telegram of process values with a data width of 7 words.
Mapping	Image of process data on a communication channel (slot)
Mapping Table	Overview of process values that can be put on a communication channel (slot).
Coupling objects	Are suitable as master signals for electronic coupling and must be in the DSP format.
Receive	Received:
Slot	communication channel
Transmit	Send:
Process data	Objects, which are suitable for use in the cyclic data channel.

**6.8.2.4 Calling up the HEDA wizard in the C3 ServoManager**

The "HEDA Advanced" wizard can be found in the C3 ServoManager tree under communication.  
 Please observe:

**The "HEDA advanced" wizard settings overwrite the settings of the HEDA standard wizard!**

**6.8.2.5 Configuration of the HEDA communication**

**In this chapter you can read about:**

Error reaction to a bus failure .....	395
Data transfer Master – Slave and back .....	396
Example: Communication Master – Slave and back .....	403
Data transfer from Slave to Slave .....	407

**Error reaction to a bus failure**

Here you can adjust how Compax3 will respond to a fieldbus error:  
 Possible settings for the error reaction are:


- ◆ No response
- ◆ downramp / stop
- ◆ Downramp / switch to currentless (standard setting)

**Data transfer Master – Slave and back**

**In this chapter you can read about:**

Setting the HEDA master..... 398  
 Setting the HEDA slave ..... 401

In standard applications the master sends process values to the slaves and reads the answers from the slaves.




- \* only one of the assigned slots per frame group may be activated on the slave transmit side (this is blocked by the C3 ServoManager)
- \* only one of the assigned slots per frame group may be activated on the master or slave receive side (this is blocked by the C3 ServoManager)

**Print version available in the Internet**

[http://apps.parker.com/euro\\_emd/EME/downloads/compax3/HEDA-Formulare/HEDA-Standard.pdf](http://apps.parker.com/euro_emd/EME/downloads/compax3/HEDA-Formulare/HEDA-Standard.pdf)





**Functionality:**

The master can send 4 different frames (F1,... F4). A frame can be sent from several slots:

Frame:	F1	F2	F3	F4
possible slots:	0 ... 2	3 ... 7	8 ... 12	13 ... 17

Each frame is assigned a mapping table number.

The individual slaves read in the slot from where their relevant data are sent.

It is necessary to define a mapping table in the slave, stating where the individual process data are to be written (e.g. into an array-object).

The assignment of the mapping table is made via the mapping table number which is transferred via HEDA.

For this reason, the receive mapping table number and the transfer mapping table number must always be the same.

**Important:** Receive-Mapping-Tablen-Number = Transmit-Mapping-Table-Number

### Setting the HEDA master

HEDA master settings:

- ◆ activate HEDA Master
- ◆ Axis address = 0
- ◆ Setting the error reaction (from Compax3) at bus failure:
  - ◆ activated: Compax3 switches to error state in the case of a bus error.
  - ◆ deactivated: Compax3 will ignore a bus error.

## Master transmission slots (Transmit Slots)

**Important:**

**For standard applications (data transfer master – slave and back) all slots in the master must be transmitting.**

- ◆ for this reason you should activate all transmit slots (0...17, in the lower area of the wizard window).
- ◆ Please assign, according to your requirements, a mapping table to each of the 4 transmit frames.

The contents of the transmit mapping table is defined in the next wizard window.


Autoryzowany dystrybutor Parker:

**ARA**  
PNEUMATIK  
53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83  
[www.arapneumatik.pl](http://www.arapneumatik.pl)



### Master receive slots

Activate the receive slots from which the slave sends data (corresponding to the settings in the slave).



In each of the 125 $\mu$ s cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be received only via one slot, see also the **HEDA communication structure** (see page 396).

The assignment of the data is made via the mapping table number (which was defined in the slave), this number is also received.

In the Wizard window "Receive Mapping table", it is defined under this mapping table number where the data received are to be written to.

### Master Transmit Mapping Table (max. 4)

Here the transmit mapping tables, which were assigned to the max. 4 transmit 125 $\mu$ s slots, are defined.

Procedure:

- ◆ Selection of the corresponding transmit mapping table.
- ◆ Selection of the Compax3 objects to be transmitted.
  - ◆ The assignment of the mapping table is permanently identified and displayed.
  - ◆ Up to 7 words are possible.
  - ◆ How many words are used by an **object** (see page 414) depends on the **bus format** (see page 363) / DSP format

**Note:** For axis coupling, please use the **coupling objects** (see page 412) in the **DSP format** (see page 395) (selected by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

**Master Receive Mapping Table (max. 4)**

Please select the mapping table number, which was defined in the slave (under transmit mapping table).

Please enter where the data received shall be written (e.g. into an array object).

Please use the data formats as defined in the mapping table of the slave.

**Note:** For axis coupling, please use the **coupling object** (see page 412) O3920.1 in the **DSP format** (see page 395) as an input (selection by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

**Setting the HEDA slave**

HEDA slave settings:

- ◆ Activating the HEDA Slave
- ◆ Assigning the axis address = 0 (can be changed by clicking)
- ◆ Setting the error reaction (from Compax3) at bus failure:
  - ◆ activated: Compax3 switches to error state in the case of a bus error.
  - ◆ deactivated: Compax3 will ignore a bus error.

### Slave receive slots

Activate the receive slots, from where the slave is to receive the data.

In each of the four 125µs cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be received only via one slot, see also the **HEDA communication structure** (see page 396).

The assignment of the data is made via the mapping table number (which was defined in the master), this number is also received.

In the Wizard window "Receive Mapping table", it is defined under this mapping table number where the data received are to be written to.

### Slave transmission slots (Transmit Slots)

Activate the transmit slots, from where the slave is to send the data.

In each of the four 125µs cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be transmitted only via one slot, see also the **HEDA communication structure** (see page 396).

Please make sure, that no other slave can send on this slot.

Now you can assign a mapping table to each individual activated slot.

**Please consider, that transmit mapping table numbers are only used once in one transmit/receive range.**

The contents of the transmit mapping table is defined in the next wizard window.

### Slave Transmit Mapping table

Here the transmit mapping tables, which were assigned to the transmit slots activated before, are defined.

Procedure:

- ◆ Selection of the corresponding transmit mapping table.
- ◆ Selection of the Compax3 objects to be transmitted.
  - ◆ The assignment of the mapping table is permanently identified and displayed.
  - ◆ Up to 7 words are possible.
  - ◆ How many words are used by an **object** (see page 414) depends on the **bus format** (see page 363).

**Note:** For axis coupling, please use the **coupling objects** (see page 412) in the **DSP format** (see page 395) (selected by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

### Slave Receive Mapping table

Please select the mapping table number, which was defined in the master (under transmit mapping table).


Please enter now, where the received data are to be written.

Please use the data formats as defined in the mapping table of the master.

**Note:** For axis coupling, please use the **coupling object** (see page 412) O3920.1 in the **DSP format** (see page 395) as an input (selection by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

**Example: Communication Master – Slave and back**

HEDA communication structure:



Master and Slave 1 to 3 (from left to right).

**Task:****Master Transmit**

- ◆ Master sends on:
  - ◆ Slot 0..2: Mapping table 1
  - ◆ Slot 3..7: Mapping table 2
  - ◆ Slot 8..12: Mapping table 4
  - ◆ Slot 13..17: Mapping table 5

**Slave Receive**

- ◆ Slave 1 reads on:
  - ◆ Slot 2: Mapping table 1
  - ◆ Slot 3: Mapping table 2 and
  - ◆ Slot 8: Mapping table 4
- ◆ Slave 2 reads on:
  - ◆ Slot 6: Mapping table 2
  - ◆ Slot 9: Mapping table 4 and
  - ◆ Slot 13: Mapping table 5.
- ◆ Slave 3 reads on
  - ◆ Slot 1: Mapping table 1 and
  - ◆ Slot 9: Mapping table 4.

**Slave Transmit**

- ◆ Slave 1 sends on:
  - ◆ Slot 1: Mapping table 1
  - ◆ Slot 5: Mapping table 6
- ◆ Slave 2 sends on:
  - ◆ Slot 8: Mapping table 7
- ◆ Slave 3 sends on:
  - ◆ Slot 17: Mapping table 8

**Master Receive**

- ◆ Master receives on:
  - ◆ Slot 1: Mapping table 1
  - ◆ Slot 5: Mapping table 6
  - ◆ Slot 8: Mapping table 7
  - ◆ Slot 17: Mapping table 8



**C3 ServoManger settings:**

**Slot - settings Master:**

Receive Slot : \$20122 {131362}

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

0 .. 125 us      125 .. 250 us      250 .. 375 us      375 .. 500 us

Transmit Slot : \$3FFFF {262143}

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

Mapping Table 1      Mapping Table 2      Mapping Table 4      Mapping Table 5

**Example for transmit mapping table 1 on the master or slave**

Transmit Mapping Table 1

TxPD Obj 1.1	PositionController_ActualValue [2200.2] 3w DSP
TxPD Obj 1.2	Array_Col07_Row01 [1907.1] 3w DSP
TxPD Obj 1.3	leer
TxPD Obj 1.4	leer
TxPD Obj 1.5	leer
TxPD Obj 1.6	leer
TxPD Obj 1.Z	leer

1 Worte frei

**Slot settings slave 1:**

Receive Slot : \$10C {268}

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

0 .. 125 us      125 .. 250 us      250 .. 375 us      375 .. 500 us

Transmit Slot : \$22 {34}

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----


Mapping Table 1      Mapping Table 6      Mapping Table 1      Mapping Table 1

**Example for receive mapping table 1 at slave 1 (is also valid for slave 3, master)**

RECEIVE MAPPING TABLE 1	
RxPD Obj 1.1	HEDA_SignalProcessing_Input [3920.1] 3w DSP
RxPD Obj 1.2	leer
RxPD Obj 1.3	leer
RxPD Obj 1.4	leer
RxPD Obj 1.5	leer
RxPD Obj 1.6	leer
RxPD Obj 1.7	leer
<div style="display: flex; justify-content: space-between;"> <span>4</span> <span>3</span> <span>2</span> <span>1</span> </div>	
4 Worte frei	

**Data transfer from Slave to Slave.**

HEDA communication structure with data transfer from Slave to Slave:



**Print version available in the Internet**

[http://apps.parker.com/divapps/eme/EME/downloads/compax3/HEDA-Formulare/HEDA\\_adv.pdf](http://apps.parker.com/divapps/eme/EME/downloads/compax3/HEDA-Formulare/HEDA_adv.pdf)

If a transmit slot of the HEDA master is not assigned, the master will pass the received data directly on to the slaves (independent of his reading from this slot or not).

I.e. if a transmit slot of the master where a slave is sending is disabled, the data will be passed on and can be received from any slave on this slot.

**It is, however, valid:**

**All transmit slots must send!**

This is also true, if a slave sends on this slot.


**Please note:**

**Please ensure that all slots are used for transmission, the C3 ServoManager cannot verify this fact!**

In order to verify this, please use the HEDA communication structure.

**Example 1: Communication Master - Slave and Slave - Slave.**


**Task:**



MT1 ... MT7: Mapping table 1... 7

**Step-by-step setting of the HEDA communications:**

Firstly, activate all transmit slots of the master in order to ensure that all transmit slots of the master are sending:




The mapping tables are now distributed to different slots:

Mapping Table	Slot	
MT1	1	Slave transmit range
MT2	4	
MT3	11	
MT4	16	
MT5	2 (& 0, 1)	Master transmit range
MT6	9 (& 8, 10, 12)	
MT7	13 (& 14, 15, 17)	

**Note:** The transmit slots where a slave-slave communication is taking place (Slot 11 & 16), must be deactivated in the master! Otherwise, the master would overwrite the data of the slave.

This results in the following image:



## The following objects are transmitted:

TRANSMIT (send)		RECEIVE	RECEIVE
Mapping Table	Source	Objects	Target
1	S1	C3Array.Col01Row01 (1901.1)	M
2	S1	C3Plus.DeviceState_Statusword1 (1000.3)	M
3	S1	C3Plus.ProfileGenerators_SG1Position (2000.1)	M S2
4	S2	C3Plus.PositionController_DemandValue (2200.1)	S3
5	M	C3Plus.ProfilGenerators_PG2Position (2000.2)	S1 S2 S3
6	M	C3Plus.DeviceControl_Controlword1 (1100.3)	S1
7	M	C3Array.Col06Row01 (1906.1)	S1

M: Master

S1, S2, S3: Slave 1 ... 3


**Word form for the objects to be transmitted in the internet**

[http://apps.parker.com/euro\\_emd/EME/downloads/compax3/HEDA-Formulare/communications-table.doc](http://apps.parker.com/euro_emd/EME/downloads/compax3/HEDA-Formulare/communications-table.doc).

**Example 2: 4-axis application with HEDA**

**Task:**

- ◆ four-axis processing machine
- ◆ Setting the steps via virtual master
- ◆ Forwards and backwards movement with the master (closed curve)
- ◆ Linearized feed movement with Slave 1 = rotating blade (open curve)
- ◆ Position synchronous operation of slave 2 with respect to slave 1 with slip correction (use of C3\_Shift\_Position)
- ◆ Fixed position assignment of a turning axis slave 3 to slave 2 with consideration of the correction movement of slave 2




**Master / Slave Configuration of the reference system**

Configuration	Master	Slave 1	Slave 2	Slave 3
Travel distance per motor revolution				
◆ Numerator	127	<b>233</b>	<b>100</b>	360
◆ Denominator	10	<b>5</b>	<b>3</b>	7
Reset distance				
◆ Numerator	100	100	100	360
◆ Denominator	1	1	1	1
Signal source (Master axis)				
◆ Virtual Master				
◆ Reset distance	360			
◆ Use as current signal source	yes			
Source HEDA (Slave axis)				
◆ "Virtual master" as HEDA Master		yes	no	no
◆ Path per motor revolution of the HEDA Master		not required	<b>233</b>	<b>100</b>
◆ Numerator			<b>5</b>	<b>3</b>
◆ Denominator				
◆ Create cams with the CamDesinger				
◆ Distance Counter Reset Position - Numerator	360	360	100	100
◆ Distance Counter Reset Position - Denominator	1	1	1	1

The C3 ServoManager projects (configuration) can be found on the Compax3 CD: ...\Examples\HEDAMaster.c3p, slave1.c3p, slave2.c3p, slave3.c3p

**6.8.3. Coupling objects**

Coupling objects (framed objects) are suitable as master signal for electronic coupling and should be in the **DSP Format** (see page 395).





Input value for HEDA couplings is object 3920.1.

**Note:** \* This values are not even reset by a home run.  
Direction -1 / +1: with direction inversion (in the configuration wizard) these coupling values are inverted, relative to the drive direction (factor -1).

# 7. Compax3 - Objects

## In this chapter you can read about:

Objects for the process data channel.....	415
Object overview sorted by object name (T40).....	416
Detailed object list .....	426

**Compax3 objects are encapsulated in the "C3, C3Array, ..." modules in the IEC61131-3 programming environment (CoDeSys).**

**Enter the object names before the "." and the corresponding list of objects will appear.**

**Objects that are not described here are reserved objects!**

### **Note on searching objects:**

- ◆ If the object number is known, you can enter it directly in the index.
- ◆ In addition you can find the CoDeSys name of the objects in the index.

### **Note on bus numbers (PNU, CAN-No.):**

The bus numbers of the array can be found in the description on column 1, line 1 (Object 1901.1)

### **Set objects to valid**

Please note that certain objects are not valid (read by Compax3) immediately after a change. This is described in the heading "Valid after".  
These objects are converted to internal variables the Compax3 "VP" command (write in object 210.10 with value <> 0).

### **Save objects permanently**

It should also be noted that modified objects are not permanently stored in the Compax3, i.e. the changes are lost after the power (24 VDC) is turned off.  
The object "Save objects permanently" (write in object 20.11 with value <> 0) can be used to save objects in a flash memory so they are retained even if the power fails.

## 7.1 Objects for the process data channel

No.	Object name	Object	PNU	PZD	CAN No.	PD	Bus format	Word width
634.4	Setpoint for analog output 0	C3.AnalogOutput0_DemandValue	24	PED/PAD	0x2019	R/TPDO	I16	1
635.4	setpoint for analog output 1	C3.AnalogOutput1_DemandValue	103	PED/PAD	0x201A	R/TPDO	I16	1
120.3	Status of digital inputs	C3.DigitalInput_DebouncedValue	21	PED	0x6100.1	TPDO	V2	1
121.2	Input word of I/O option	C3.DigitalInputAddition_Value	175	PED	0x6100.2	TPDO	V2	1
133.3	Output word for I/O option	C3.DigitalOutputAddition_Value	176	PED/PAD	0x6300.2	R/TPDO	V2	1
140.3	Command value of the digital outputs	C3.DigitalOutputWord_DemandState	22	PED/PAD	0x6300.1	R/TPDO	V2	1
2020.1	Position from external signal source	C3.ExternalSignal_Position		PED	0x2095.1	TPDO	C4_3	2
3921.1	Interpolation input CanSync, PowerLink	C3.FBI_SignalProcessing0_Input		PED/PAD	0x2050	R/TPDO	I32	2
695.11	Actual value force controller main axis [N]	C3.StatusForce_Actual	221	PED		TPDO	I32	2
695.14	Actual value force controller auxiliary axis [N]	C3.StatusForce_Actual2	222	PED		TPDO	I32	2
680.5	Status actual position	C3.StatusPosition_Actual	28	PED	0x6064	TPDO	C4_3	2
680.15	Actual position of auxiliary axis	C3.StatusPosition_Actual2	211	PED		TPDO	C4_3	2
680.4	Status demand position	C3.StatusPosition_DemandValue	323	PED	0x60FC	TPDO	C4_3	2
680.1	Position command value of Profile transmitter1	C3.StatusPosition_DemandValue1	0	PED	0x2052	TPDO	Y4	2
680.2	Status demand position virtual master	C3.StatusPosition_DemandValue2	202	PED	0x2042	TPDO	Y4	2
680.10	Status of encoder input 0 (5V)	C3.StatusPosition_EncoderInput5V		PED	0x2095.2	TPDO	C4_3	2
680.6	Status of tracking error	C3.StatusPosition_FollowingError	100	PED	0x60F4	TPDO	C4_3	2
680.16	Following error auxiliary axis	C3.StatusPosition_FollowingError2	212	PED		TPDO	C4_3	2
694.4	System pressure for main axis	C3.StatusPressure_p01	216	PED		TPDO	C4_3	2
694.9	System pressure for auxiliary axis	C3.StatusPressure_p02	220	PED		TPDO	C4_3	2
694.1	Pressure on A side of main axis	C3.StatusPressure_pA1	213	PED		TPDO	C4_3	2
694.6	Pressure on A side of auxiliary axis	C3.StatusPressure_pA2	217	PED		TPDO	C4_3	2
694.2	Pressure on B side of main axis	C3.StatusPressure_pB1	214	PED		TPDO	C4_3	2
694.7	Pressure on B side of auxiliary axis	C3.StatusPressure_pB2	218	PED		TPDO	C4_3	2
694.3	Tank pressure for main axis	C3.StatusPressure_pT1	215	PED		TPDO	C4_3	2
694.8	Tank pressure for auxiliary axis	C3.StatusPressure_pT2	219	PED		TPDO	C4_3	2
681.5	Status actual speed unfiltered	C3.StatusSpeed_Actual	8	PED	0x6069	TPDO	C4_3	2
681.14	Actual speed unfiltered auxiliary axis	C3.StatusSpeed_Actual2Filtered	210	PED		TPDO	C4_3	2
681.9	Status actual speed filtered	C3.StatusSpeed_ActualFiltered		PED	0x606C	TPDO	C4_3	2
681.7	Status of the actual filtered speed speed in the Y2 format	C3.StatusSpeed_ActualFiltered_Y2	6	PED	0x2023	TPDO	Y2	1
681.8	Status of the actual filtered speed in the Y4 format	C3.StatusSpeed_ActualFiltered_Y4	117	PED	0x2024	TPDO	Y4	2
681.4	Status demand speed of setpoint generator	C3.StatusSpeed_DemandValue	324	PED	0x606B	TPDO	C4_3	2
681.1	Speed command value of profile transmitter1	C3.StatusSpeed_DemandValue1	337	PED	0x2053	TPDO	Y4	2
681.2	Status demand speed virtual master	C3.StatusSpeed_DemandValue2	203	PED	0x2043	TPDO	Y4	2
681.6	Status control deviation of speed	C3.StatusSpeed_Error	101	PED	0x2027	TPDO	C4_3	2
685.3	Status of analog input 0	C3.StatusVoltage_AnalogInput0	23	PED	0x2025	TPDO	Y2	1
685.4	Status of analog input 1	C3.StatusVoltage_AnalogInput1	102	PED	0x2026	TPDO	Y2	1
1901.1	variable Column 1 Row 1	C3Array.Col01_Row01	130/341.1	PED/PAD	0x2301.1	R/TPDO	Y4	2
1901.2	Variable Column 1 Row 2	C3Array.Col01_Row02	131/341.2	PED/PAD	0x2301.2	R/TPDO	Y4	2
1901.3	Variable Column 1 Row 3	C3Array.Col01_Row03	132/341.3	PED/PAD	0x2301.3	R/TPDO	Y4	2
1901.4	Variable Column 1 Row 4	C3Array.Col01_Row04	133/341.4	PED/PAD	0x2301.4	R/TPDO	Y4	2
1901.5	Variable Column 1 Row 5	C3Array.Col01_Row05	134/341.5	PED/PAD	0x2301.5	R/TPDO	Y4	2
1902.1	variable Column 2 Row 1	C3Array.Col02_Row01	135/342.1	PED/PAD	0x2302.1	R/TPDO	Y2	1
1902.2	variable Column 2 Row 2	C3Array.Col02_Row02	136/342.2	PED/PAD	0x2302.2	R/TPDO	Y2	1
1902.3	variable Column 2 Row 3	C3Array.Col02_Row03	137/342.3	PED/PAD	0x2302.3	R/TPDO	Y2	1
1902.4	Variable Column 2 Row 4	C3Array.Col02_Row04	138/342.4	PED/PAD	0x2302.4	R/TPDO	Y2	1
1902.5	Variable Column 2 Row 5	C3Array.Col02_Row05	139/342.5	PED/PAD	0x2302.5	R/TPDO	Y2	1
1903.1	variable Column 3 Row 1	C3Array.Col03_Row01	140/343.1	PED/PAD	0x2303.1	R/TPDO	I16	1
1903.2	Variable Column 3 Row 2	C3Array.Col03_Row02	141/343.2	PED/PAD	0x2303.2	R/TPDO	I16	1
1903.3	Variable Column 3 Row 3	C3Array.Col03_Row03	142/343.3	PED/PAD	0x2303.3	R/TPDO	I16	1
1903.4	Variable Column 3 Row 4	C3Array.Col03_Row04	143/343.4	PED/PAD	0x2303.4	R/TPDO	I16	1
1903.5	Variable Column 3 Row 5	C3Array.Col03_Row05	144/343.5	PED/PAD	0x2303.5	R/TPDO	I16	1
1904.1	variable Column 4 Row 1	C3Array.Col04_Row01	145/344.1	PED/PAD	0x2304.1	R/TPDO	I16	1
1904.2	Variable Column 4 Row 2	C3Array.Col04_Row02	146/344.2	PED/PAD	0x2304.2	R/TPDO	I16	1
1904.3	Variable Column 4 Row 3	C3Array.Col04_Row03	147/344.3	PED/PAD	0x2304.3	R/TPDO	I16	1
1904.4	Variable Column 4 Row 4	C3Array.Col04_Row04	148/344.4	PED/PAD	0x2304.4	R/TPDO	I16	1
1904.5	Variable Column 4 Row 5	C3Array.Col04_Row05	149/344.5	PED/PAD	0x2304.5	R/TPDO	I16	1
1905.1	variable Column 5 Row 1	C3Array.Col05_Row01	150/345.1	PED/PAD	0x2305.1	R/TPDO	I16	1
1905.2	Variable Column 5 Row 2	C3Array.Col05_Row02	151/345.2	PED/PAD	0x2305.2	R/TPDO	I16	1
1905.3	Variable Column 5 Row 3	C3Array.Col05_Row03	152/345.3	PED/PAD	0x2305.3	R/TPDO	I16	1
1905.4	Variable Column 5 Row 4	C3Array.Col05_Row04	153/345.4	PED/PAD	0x2305.4	R/TPDO	I16	1
1905.5	Variable Column 5 Row 5	C3Array.Col05_Row05	154/345.5	PED/PAD	0x2305.5	R/TPDO	I16	1
1906.1	variable Column 6 Row 1	C3Array.Col06_Row01	155/346.1	PED/PAD	0x2306.1	R/TPDO	I32	2
1906.2	Variable Column 6 Row 2	C3Array.Col06_Row02	156/346.2	PED/PAD	0x2306.2	R/TPDO	I32	2
1906.3	Variable Column 6 Row 3	C3Array.Col06_Row03	157/346.3	PED/PAD	0x2306.3	R/TPDO	I32	2
1906.4	Variable Column 6 Row 4	C3Array.Col06_Row04	158/346.4	PED/PAD	0x2306.4	R/TPDO	I32	2
1906.5	Variable Column 6 Row 5	C3Array.Col06_Row05	159/346.5	PED/PAD	0x2306.5	R/TPDO	I32	2
1907.1	variable Column 7 Row 1	C3Array.Col07_Row01	160/347.1	PED/PAD	0x2307.1	R/TPDO	I32	2
1907.2	Variable Column 7 Row 2	C3Array.Col07_Row02	161/347.2	PED/PAD	0x2307.2	R/TPDO	I32	2
1907.3	Variable Column 7 Row 3	C3Array.Col07_Row03	162/347.3	PED/PAD	0x2307.3	R/TPDO	I32	2
1907.4	Variable Column 7 Row 4	C3Array.Col07_Row04	163/347.4	PED/PAD	0x2307.4	R/TPDO	I32	2
1907.5	Variable Column 7 Row 5	C3Array.Col07_Row05	164/347.5	PED/PAD	0x2307.5	R/TPDO	I32	2
1908.1	variable Column 8 Row 1	C3Array.Col08_Row01	165/348.1	PED/PAD	0x2308.1	R/TPDO	I32	2
1908.2	Variable Column 8 Row 2	C3Array.Col08_Row02	166/348.2	PED/PAD	0x2308.2	R/TPDO	I32	2
1908.3	Variable Column 8 Row 3	C3Array.Col08_Row03	167/348.3	PED/PAD	0x2308.3	R/TPDO	I32	2
1908.4	Variable Column 8 Row 4	C3Array.Col08_Row04	168/348.4	PED/PAD	0x2308.4	R/TPDO	I32	2
1908.5	Variable Column 8 Row 5	C3Array.Col08_Row05	169/348.5	PED/PAD	0x2308.5	R/TPDO	I32	2
1909.1	variable Column 9 Row 1	C3Array.Col09_Row01	170/349.1	PED/PAD	0x2309.1	R/TPDO	I32	2
1909.2	Variable Column 9 Row 2	C3Array.Col09_Row02	171/349.2	PED/PAD	0x2309.2	R/TPDO	I32	2
1909.3	Variable Column 9 Row 3	C3Array.Col09_Row03	172/349.3	PED/PAD	0x2309.3	R/TPDO	I32	2
1909.4	Variable Column 9 Row 4	C3Array.Col09_Row04	173/349.4	PED/PAD	0x2309.4	R/TPDO	I32	2

No.	Object name	Object	PNU	PZD	CAN No.	PD	Bus format	Word width
1909.5	Variable Column 9 Row 5	C3Array.Col09_Row05	174/349.5	PED/PAD	0x2309.5	R/TPDO	I32	2
1910.1	Indirect table access Column 1	C3Array.Indirect_Col01	181	PED/PAD	0x2311	R/TPDO	Y4	2
1910.2	Indirect table access Column 2	C3Array.Indirect_Col02	182	PED/PAD	0x2312	R/TPDO	Y2	1
1910.3	Indirect table access Column 3	C3Array.Indirect_Col03	183	PED/PAD	0x2313	R/TPDO	I16	1
1910.4	Indirect table access Column 4	C3Array.Indirect_Col04	184	PED/PAD	0x2314	R/TPDO	I16	1
1910.5	Indirect table access Column 5	C3Array.Indirect_Col05	185	PED/PAD	0x2315	R/TPDO	I16	1
1910.6	Indirect table access Column 6	C3Array.Indirect_Col06	186	PED/PAD	0x2316	R/TPDO	I32	2
1910.7	Indirect table access Column 7	C3Array.Indirect_Col07	187	PED/PAD	0x2317	R/TPDO	I32	2
1910.8	Indirect table access Column 8	C3Array.Indirect_Col08	188	PED/PAD	0x2318	R/TPDO	I32	2
1910.9	Indirect table access Column 9	C3Array.Indirect_Col09	189	PED/PAD	0x2319	R/TPDO	I32	2
1900.1	Pointer to table row	C3Array.Pointer_Row	180	PED/PAD	0x2300	R/TPDO	U16	1
3701.3	output of cam group 0	C3Cam.ControlledSwitches_Output0	205/501.3	PED/PAD	0x2401.3	R/TPDO	U16	1
3701.5	output of cam group 1	C3Cam.ControlledSwitches_Output1	206/501.5	PED/PAD	0x2401.5	R/TPDO	U16	1
3700.3	output for fast cams	C3Cam.ControlledSwitchesFast_Output	204/500.3	PED/PAD	0x2400.3	R/TPDO	U16	1
3030.1	Reset master position	C3Cam.StatusMaster_Position	207	PED	0x2410	TPDO	C4_3	2
3032.24	End of curve	C3Cam.StatusOutput_CurvePositionUnits	208	PED	0x2411	TPDO	C4_3	2
1100.1	Control command	C3Plus.DeviceControl_CommandOnRequest	108	PED/PAD	0x2028	R/TPDO	I16	1
1100.3	Control word CW	C3Plus.DeviceControl_Controlword_1	1	PED/PAD	0x6040	R/TPDO	V2	1
1100.4	Control word 2	C3Plus.DeviceControl_Controlword_2	3	PED/PAD	0x201B	R/TPDO	V2	1
1100.8	Device demand value C	C3Plus.DeviceControl_DemandValue3		PED/PAD	0x2048	R/TPDO	Y2	1
1100.5	Operating mode	C3Plus.DeviceControl_OperationMode	127/930	PED/PAD	0x6060	R/TPDO	I16	1
1000.5	Operating mode display	C3Plus.DeviceState_ActualOperationMode	128	PED/PAD	0x6061	R/TPDO	I16	1
1000.3	Status word SW	C3Plus.DeviceState_Statusword_1	2	PED/PAD	0x6041	R/TPDO	V2	1
1000.4	Status word 2	C3Plus.DeviceState_Statusword_2	4	PED/PAD	0x201C	R/TPDO	V2	1
550.1	Current error (n)	C3Plus.ErrorHistory_LastError	115/947.0	PED	0x603F/ 0x201D.1	TPDO	U16	1
1200.1	Control of virtual Master	C3Plus.PG2Control_CommandOnRequest	200	PED/PAD	0x2040	R/TPDO	I16	1
1111.3	Acceleration for positioning	C3Plus.POSITION_accel	114	PED/PAD	0x6083	R/TPDO	U32	2
1111.4	Deceleration for positioning	C3Plus.POSITION_decel	312	PED/PAD	0x6084	R/TPDO	U32	2
1111.1	Target position	C3Plus.POSITION_position	27	PED/PAD		R/TPDO	C4_3	2
1111.2	Speed for positioning	C3Plus.POSITION_speed	111	PED/PAD		R/TPDO	C4_3	2
1111.9	Speed for Positioning in Y2 Format	C3Plus.POSITION_speed_Y2	110	PED/PAD		R/TPDO	Y2	1
2000.2	Position value of the setpoint encoder of the virtual axis	C3Plus.ProfilGenerators_PG2Position		PED	0x2061	TPDO	C4_3	2
2000.5	Speed of the virtual axis	C3Plus.ProfilGenerators_PG2Speed		PED	0x2064	TPDO	I32	2
2000.1	Position value of the setpoint encoder	C3Plus.ProfilGenerators_SG1Position		PED	0x2060	TPDO	C4_3	2
2000.4	Speed of the setpoint encoder	C3Plus.ProfilGenerators_SG1Speed		PED	0x2063	TPDO	I32	2
152.1	PIO analog input 0	C3Plus.RemoteAnalogInput_I0		PED/PAD	0x2082.1	R/TPDO	I16	1
152.2	PIO analog input 1	C3Plus.RemoteAnalogInput_I1		PED/PAD	0x2082.2	R/TPDO	I16	1
152.3	PIO analog input 2	C3Plus.RemoteAnalogInput_I2		PED/PAD	0x2082.3	R/TPDO	I16	1
152.4	PIO analog input 3	C3Plus.RemoteAnalogInput_I3		PED/PAD	0x2082.4	R/TPDO	I16	1
153.1	PIO analog output 0	C3Plus.RemoteAnalogOutput_O0		PED/PAD	0x2083.1	R/TPDO	I16	1
153.2	PIO analog output 1	C3Plus.RemoteAnalogOutput_O1		PED/PAD	0x2083.2	R/TPDO	I16	1
153.3	PIO analog output 2	C3Plus.RemoteAnalogOutput_O2		PED/PAD	0x2083.3	R/TPDO	I16	1
153.4	PIO analog output 3	C3Plus.RemoteAnalogOutput_O3		PED/PAD	0x2083.4	R/TPDO	I16	1
150.1	Digital PIO inputs 0...15	C3Plus.RemoteDigInput_I0_15		PED/PAD	0x2080.1	R/TPDO	V2	1
150.2	Digital PIO inputs 16...31	C3Plus.RemoteDigInput_I16_31		PED/PAD	0x2080.2	R/TPDO	V2	1
150.3	Digital PIO inputs 32...47	C3Plus.RemoteDigInput_I32_47		PED/PAD	0x2080.3	R/TPDO	V2	1
150.4	Digital PIO inputs 48...63	C3Plus.RemoteDigInput_I48_63		PED/PAD	0x2080.4	R/TPDO	V2	1
151.1	Digital PIO outputs 0...15	C3Plus.RemoteDigOutput_O0_15		PED/PAD	0x2081.1	R/TPDO	V2	1
151.2	Digital PIO outputs 16...31	C3Plus.RemoteDigOutput_O16_31		PED/PAD	0x2081.2	R/TPDO	V2	1
151.3	Digital PIO outputs 32...47	C3Plus.RemoteDigOutput_O32_47		PED/PAD	0x2081.3	R/TPDO	V2	1
151.4	Digital PIO outputs 48...63	C3Plus.RemoteDigOutput_O48_63		PED/PAD	0x2081.4	R/TPDO	V2	1
1127.3	Target speed in speed control operating mode	C3Plus.SPEED_speed	7	PED/PAD		R/TPDO	C4_3	2
680.8	Status position actual value in the bus format Y4	C3Plus.StatusPosition_Actual_Y4	119	PED	0x2022	TPDO	Y4	2

## 7.2 Object overview sorted by object name (T40)

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
172.5	C3.AnalogInput0_ActualValue	Actual value X1:IN0			I32	no	-	-	-
172.7	C3.AnalogInput0_ActualValueFiltered	Filtered actual value X1:IN0			I32	no	-	-	-
173.5	C3.AnalogInput1_ActualValue	Actual value X1:IN1			I32	no	-	-	-
173.7	C3.AnalogInput1_ActualValueFiltered	Filtered actual value X1:IN1			I32	no	-	-	-
174.5	C3.AnalogInput2_ActualValue	Actual value X1:IN2			I32	no	-	-	-
174.7	C3.AnalogInput2_ActualValueFiltered	Filtered actual value X1:IN2			I32	no	-	-	-
175.5	C3.AnalogInput3_ActualValue	Actual value X1:IN3			I32	no	-	-	-
175.7	C3.AnalogInput3_ActualValueFiltered	Filtered actual value X1:IN3			I32	no	-	-	-
176.5	C3.AnalogInput4_ActualValue	Actual value X1:IN4			I16	no	-	-	-
176.7	C3.AnalogInput4_ActualValueFiltered	Filtered actual value X1:IN4			I16	no	-	-	-
177.5	C3.AnalogInput5_ActualValue	Actual value X1:IN5			I16	no	-	-	-
177.7	C3.AnalogInput5_ActualValueFiltered	Filtered actual value X1:IN5			I16	no	-	-	-
634.4	C3.AnalogOutput0_DemandValue	Setpoint for analog output 0	24	0x2019	I16	yes	Immediately	-	-
635.4	C3.AnalogOutput1_DemandValue	setpoint for analog output 1	103	0x201A	I16	yes	Immediately	-	-
2101.14	C3.ControllerTuning_2_AccelFeedback_Ka	Acceleration feedback (A2)			U16	no	VP	-	-
2101.11	C3.ControllerTuning_2_ActuatingSignalGain_speed	Control signal gain of auxiliary axis			U16	no	VP	-	-
2101.8	C3.ControllerTuning_2_FilterAccel2	Filter actual acceleration 2			U16	no	VP	-	-
2101.7	C3.ControllerTuning_2_FilterSpeed2	Filter actual velocity 2			U16	no	VP	-	-
2101.13	C3.ControllerTuning_2_SpeedFeedback_Kv	Speed feedback (A2)			U16	no	VP	-	-
2100.14	C3.ControllerTuning_AccelFeedback_Ka	Acceleration feedback (A1)			U16	no	VP	-	-
2100.12	C3.ControllerTuning_ActuatingSignalGain_speed	open loop gain			U16	no	VP	-	-
2100.21	C3.ControllerTuning_FilterAccel_us	Filter - Actual acceleration			U16	no	VP	-	-
2100.11	C3.ControllerTuning_FilterAccel2	Filter actual acceleration 2			U16	no	VP	-	-
2100.10	C3.ControllerTuning_FilterSpeed2	Filter actual velocity 2			U16	no	VP	-	-
2100.13	C3.ControllerTuning_SpeedFeedback_Kv	Speed feedback (A1)			U16	no	VP	-	-
990.1	C3.Delay_MasterDelay	Setpoint delay for bus master			I16	no	Immediately	-	-
1.15	C3.Device_ProfileID	Profibus profile number	965		OS	no	-	X	-
120.3	C3.DigitalInput_DebouncedValue	Status of digital inputs	21	0x6100.1	V2	yes	-	-	-
120.2	C3.DigitalInput_Value	Status of digital inputs			V2	yes	-	-	-
121.2	C3.DigitalInputAddition_Value	Input word of I/O option	175	0x6100.2	V2	yes	-	-	-
133.4	C3.DigitalOutputAddition_Enable	Activate input/output option M10/M12	350	0x6300.3	V2	no	Immediately	-	-
133.2	C3.DigitalOutputAddition_Error	Error in I/O option	351	0x6300.4	V2	no	-	-	-
133.3	C3.DigitalOutputAddition_Value	Output word for I/O option	176	0x6300.2	V2	yes	Immediately	-	-
140.3	C3.DigitalOutputWord_DemandState	Command value of the digital outputs	22	0x6300.1	V2	yes	Immediately	X	X
2401.8	C3.DirectionDependentGain_Ch0_Factor_negative_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2401.7	C3.DirectionDependentGain_Ch0_Factor_positive_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2401.3	C3.DirectionDependentGain_Ch0_FactorDenominator	Direction dependent gain denominator			I16	no	VP	-	-
2401.2	C3.DirectionDependentGain_Ch0_FactorNumerator	Direction dependent gain numerator			I16	no	VP	-	-
2401.1	C3.DirectionDependentGain_Ch0_Type	Direction dependent gain of output 0			I16	no	VP	-	-
2411.8	C3.DirectionDependentGain_Ch1_Factor_negative_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2411.7	C3.DirectionDependentGain_Ch1_Factor_positive_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2411.3	C3.DirectionDependentGain_Ch1_FactorDenominator	Direction dependent gain denominator			I16	no	VP	-	-
2411.2	C3.DirectionDependentGain_Ch1_FactorNumerator	Direction dependent gain numerator			I16	no	VP	-	-
2411.1	C3.DirectionDependentGain_Ch1_Type	Direction dependent gain of output 1			I16	no	VP	-	-
2421.8	C3.DirectionDependentGain_Ch2_Factor_negative_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2421.7	C3.DirectionDependentGain_Ch2_Factor_positive_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2421.3	C3.DirectionDependentGain_Ch2_FactorDenominator	Direction dependent gain denominator			I16	no	VP	-	-
2421.2	C3.DirectionDependentGain_Ch2_FactorNumerator	Direction dependent gain numerator			I16	no	VP	-	-
2421.1	C3.DirectionDependentGain_Ch2_Type	Direction dependent gain of output 2			I16	no	VP	-	-
2431.8	C3.DirectionDependentGain_Ch3_Factor_negative_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2431.7	C3.DirectionDependentGain_Ch3_Factor_positive_Pressure	Direction dependent gain (pressure control)			I32	no	Immediately	-	-
2431.3	C3.DirectionDependentGain_Ch3_FactorDenominator	Direction dependent gain denominator			I16	no	VP	-	-
2431.2	C3.DirectionDependentGain_Ch3_FactorNumerator	Direction dependent gain numerator			I16	no	VP	-	-
2431.1	C3.DirectionDependentGain_Ch3_Type	Direction dependent gain of output 3			I16	no	VP	-	-
550.2	C3.ErrorHistory_1	Error (n-1) in the error history	947.1	0x201D.2	U16	no	-	X	X
2020.1	C3.ExternalSignal_Position	Position from external signal source		0x2095.1	C4_3	yes	-	-	-
2020.2	C3.ExternalSignal_Speed	Speed from external signal source			C4_3	yes	-	-	-
3925.23	C3.FBI_Interpolation_AccelStatus	Input value of the acceleration of O3925.21			C4_3	no	-	-	X
3925.1	C3.FBI_Interpolation_SubModeSelect	Interpolation method		0x60C0	I16	no	Immediately	-	X
3925.22	C3.FBI_Interpolation_VelocityStatus	Input speed of the differentiated input position O2121.1			C4_3	no	-	-	X

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	I20	I21 / I22
950.1	C3.FBI_RxPD_Mapping_Object_1	1. Object of the setpoint PZD (Profibus)	915.0		U16	no	Immediately	X		-
950.2	C3.FBI_RxPD_Mapping_Object_2	2. object of the Setpoint value PZD	915.1		U16	no	Immediately	X		-
950.3	C3.FBI_RxPD_Mapping_Object_3	3. object of the Setpoint value PZD	915.2		U16	no	Immediately	X		-
950.4	C3.FBI_RxPD_Mapping_Object_4	4. object of the Setpoint value PZD	915.3		U16	no	Immediately	X		-
950.5	C3.FBI_RxPD_Mapping_Object_5	5. object of the Setpoint value PZD	915.4		U16	no	Immediately	X		-
950.6	C3.FBI_RxPD_Mapping_Object_6	6. object of the Setpoint value PZD	915.5		U16	no	Immediately	X		-
950.7	C3.FBI_RxPD_Mapping_Object_7	7. object of the Setpoint value PZD	915.6		U16	no	Immediately	X		-
950.8	C3.FBI_RxPD_Mapping_Object_8	8. object of the Setpoint value PZD	915.7		U16	no	Immediately	X		-
3921.1	C3.FBI_SignalProcessing0_Input	Interpolation input CanSync, PowerLink		0x2050	I32	yes	Immediately	-		X
951.1	C3.FBI_TxPD_Mapping_Object_1	1. object of actual value PZD	916.0		U16	no	Immediately	X		-
951.2	C3.FBI_TxPD_Mapping_Object_2	2. object of actual value PZD	916.1		U16	no	Immediately	X		-
951.3	C3.FBI_TxPD_Mapping_Object_3	3. object of actual value PZD	916.2		U16	no	Immediately	X		-
951.4	C3.FBI_TxPD_Mapping_Object_4	4. object of actual value PZD	916.3		U16	no	Immediately	X		-
951.5	C3.FBI_TxPD_Mapping_Object_5	5. object of actual value PZD	916.4		U16	no	Immediately	X		-
951.6	C3.FBI_TxPD_Mapping_Object_6	6. object of actual value PZD	916.5		U16	no	Immediately	X		-
951.7	C3.FBI_TxPD_Mapping_Object_7	7. object of actual value PZD	916.6		U16	no	Immediately	X		-
951.8	C3.FBI_TxPD_Mapping_Object_8	8. object of actual value PZD	916.7		U16	no	Immediately	X		-
2050.10	C3.FeedForward_2_Accel_FFW	Acceleration feedforward (A2)			C4_3	no	VP	-	-	-
2050.9	C3.FeedForward_2_Speed_FFW	Speed feedforward (A2)			C4_3	no	VP	-	-	-
2050.8	C3.FeedForward_2_Valve	Valve feedforward auxiliary axis			U16	no	VP	-	-	-
2010.24	C3.FeedForward_Speed_FFW	Acceleration feedforward (A1)			C4_3	no	VP	-	-	-
2010.23	C3.FeedForward_Speed_FFW	Speed feedforward (A1)			C4_3	no	VP	-	-	-
2010.21	C3.FeedForward_Valve	Valve feedforward			U16	no	VP	-	-	-
2011.5	C3.FeedForwardExternal_FilterAccel_us	Filter time constant ext. Acceleration			U16	no	VP	-	-	-
2011.4	C3.FeedForwardExternal_FilterSpeed_us	Filter time constant ext. Velocity			U16	no	VP	-	-	-
1141.8	C3.GEAR_actual_master_speed	Master speed for Gearing			C4_3	no	-	-	-	-
1141.7	C3.GEAR_actual_masterposition	Position input value for Gearing		0x2058	C4_3	no	-	-	-	-
696.1	C3.HydraulicPower_Axis1	Control signal main axis			I32	no	-	-	-	-
696.2	C3.HydraulicPower_Axis2	Control signal auxiliary axis			I32	no	-	-	-	-
696.3	C3.HydraulicPower_Sum	Sum of the hydraulic corner power			I32	no	-	-	-	-
402.2	C3.Limit_SpeedNegative	Maximum permissible negative speed	318	0x200A	I16	no	VP	-	-	-
402.1	C3.Limit_SpeedPositive	Maximum permissible positive speed	317	0x2009	I16	no	VP	-	-	-
425.2	C3.LimitForcePressure_FollowingErrorTime	Trigger time for event "Control deviation of force controller"			I16	no	Immediately	-	-	-
425.1	C3.LimitForcePressure_FollowingErrorWindow	Max. control deviation of force controller			C4_3	no	VP	-	-	-
425.6	C3.LimitForcePressure_ForceReachedAux	Force of auxiliary axis in the control window			BOOL	no	-	-	-	-
425.5	C3.LimitForcePressure_ForceReachedMain	Force of main axis in the control window			BOOL	no	-	-	-	-
425.3	C3.LimitForcePressure_MaxForce	Maximum force			I32	no	Immediately	-	-	-
425.4	C3.LimitForcePressure_Window	Window for "Force achieved"			I32	no	VP	-	-	-
425.7	C3.LimitForcePressure_WindowTime	Trigger time for message "Force achieved"			U16	no	Immediately	-	-	-
410.3	C3.LimitPosition_Negative	negative end limit	322	0x607D.1	C4_3	no	Immediately	-	-	-
410.2	C3.LimitPosition_Positive	positive end limit	321	0x607D.2	C4_3	no	Immediately	-	-	-
3310.1	C3.Multiturnemulation_Status	Status of the Multiturn emulation			I16	no	-	-	-	-
200.10	C3.NormFactorY2_ActualValue2_Y2	Normalization factor for 1000.14			V2	no	Immediately	X	X	
200.7	C3.NormFactorY2_ActualValue3	Normalization factor for 1000.8	355.7	0x2020.7	V2	no	Immediately	X	X	
200.8	C3.NormFactorY2_ActualValue4	Normalization factor for 1000.9	355.8	0x2020.8	V2	no	Immediately	X	X	
200.5	C3.NormFactorY2_Array_Col2	Scaling factor recipe arrays column 2	355.5	0x2020.5	V2	no	Immediately	X	X	
200.9	C3.NormFactorY2_DemandValue2_Y2	Normalization factor for 1100.14			V2	no	Immediately	X	X	
200.4	C3.NormFactorY2_DemandValue3	Normalization factor for 1100.8	355.4	0x2020.4	V2	no	Immediately	X	X	
200.6	C3.NormFactorY2_DemandValue4	Normalization factor for 1100.9	355.6	0x2020.6	V2	no	Immediately	X	X	
200.1	C3.NormFactorY2_Speed	Scaling factor for Y2 speeds	355.1	0x2020.1	V2	no	Immediately	X	X	
200.3	C3.NormFactorY2_Voltage	Scaling factor for Y2 voltages	355.3	0x2020.3	V2	no	Immediately	X	X	
201.7	C3.NormFactorY4_ActualValue1	Normalization factor for 1000.6	356.7	0x2021.7	V2	no	Immediately	X	X	
201.8	C3.NormFactorY4_ActualValue2	Normalization factor for 1000.7	356.8	0x2021.8	V2	no	Immediately	X	X	
201.13	C3.NormFactorY4_ActualValue8	Normalization factor for 1000.13	356.13	0x2021.13	V2	no	Immediately	X	X	
201.4	C3.NormFactorY4_Array_Col1	Scaling factor recipe arrays column 1	356.4	0x2021.4	V2	no	Immediately	X	X	
201.5	C3.NormFactorY4_DemandValue1	Normalization factor for 1100.6	356.5	0x2021.5	V2	no	Immediately	X	X	

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
201.6	C3.NormFactorY4_DemandValue2	Normalization factor for 1100.7	356.6	0x2021.6	V2	no	Immediately	X	X
201.12	C3.NormFactorY4_DemandValue8	Normalization factor for 1100.13	356.12	0x2021.12	V2	no	Immediately	X	X
201.11	C3.NormFactorY4_FBI_SignalProcessing	Normalization factor for bus interpolation CANSync/EthernetPowerLink	356.11	0x2021.11	V2	no	Immediately	-	X
201.1	C3.NormFactorY4_Speed	Scaling factor for Y4 speeds	356.1	0x2021.1	V2	no	Immediately	X	X
201.3	C3.NormFactorY4_Voltage	Scaling factor for Y4 voltages	356.3	0x2021.3	V2	no	Immediately	X	X
20.1	C3.ObjectDir_Objekts--FLASH	Store objects permanently (bus)	339	0x2017	I16	no	Immediately	X	X
20.10	C3.ObjectDir_ReadObjects	Read objects from Flash			I16	no	Immediately	-	-
20.11	C3.ObjectDir_WriteObjects	Save objects permanently			I16	no	Immediately	-	-
2260.8	C3.PositionController_2_TrackingErrorFilter_us	Following error filter of auxiliary axis			U16	no	Immediately	-	-
420.3	C3.PositioningAccuracy_FollowingErrorTimeout	Following Error Time	331	0x6066	U16	no	Immediately	-	-
420.2	C3.PositioningAccuracy_FollowingErrorWindow	Following error limit	330	0x6065	C4_3	no	VP	-	-
420.6	C3.PositioningAccuracy_PositionReached	Position reached			I32	no	-	-	-
420.8	C3.PositioningAccuracy_PositionReached_2	Position reached (auxiliary axis)			I32	no	-	-	-
420.1	C3.PositioningAccuracy_Window	Positioning window for position reached	328	0x6067	C4_3	no	VP	-	-
420.7	C3.PositioningAccuracy_WindowTime	In Position Window Time	329	0x6068	U16	no	Immediately	-	-
165.1	C3.PressureArray_Index0	Analog Input X1:IN0 measured pressure in mbar			I16	no	Immediately	-	-
165.2	C3.PressureArray_Index1	Analog Input X1:IN1 measured pressure in mbar			I16	no	Immediately	-	-
165.11	C3.PressureArray_Index10	Reference pressure 10			I16	no	Immediately	-	-
165.12	C3.PressureArray_Index11	Reference pressure 11			I16	no	Immediately	-	-
165.13	C3.PressureArray_Index12	Reference pressure 12			I16	no	Immediately	-	-
165.3	C3.PressureArray_Index2	Analog Input X1:IN2 measured pressure in mbar			I16	no	Immediately	-	-
165.4	C3.PressureArray_Index3	Analog Input X1:IN3 measured pressure in mbar			I16	no	Immediately	-	-
165.5	C3.PressureArray_Index4	Analog Input X1:IN4 measured pressure in mbar			I16	no	Immediately	-	-
165.6	C3.PressureArray_Index5	Analog Input X1:IN5 measured pressure in mbar			I16	no	Immediately	-	-
165.7	C3.PressureArray_Index6	Reference pressure 6			I16	no	Immediately	-	-
165.8	C3.PressureArray_Index7	Reference pressure 7			I16	no	Immediately	-	-
165.9	C3.PressureArray_Index8	Reference pressure 8			I16	no	Immediately	-	-
165.10	C3.PressureArray_Index9	Reference pressure 9			I16	no	Immediately	-	-
2250.22	C3.PressureController_1_ActuatingSignalFilter	Control signal filter of force			I32	no	VP	-	-
2250.8	C3.PressureController_1_TimeDelay_DT1_T1	Delay time constant T1			U32	no	VP	-	-
2251.22	C3.PressureController_2_ActuatingSignalFilter	Control signal filter of force (A2)			I32	no	VP	-	-
2251.8	C3.PressureController_2_TimeDelay_DT1_T1	PID force controller 2 delay time constant of the D-term T1			U32	no	VP	-	-
2210.8	C3.SpeedController_ActuatingSignal_filt	Control signal filter of position			U16	no	VP	-	-
2270.8	C3.SpeedController2_ActuatingSignal_filt	Control signal filter of position auxiliary axis			U16	no	VP	-	-
682.5	C3.StatusAccel_Actual	Status of actual acceleration unfiltered			I32	no	-	-	-
682.6	C3.StatusAccel_ActualFilter	Status of filtered actual acceleration			I32	no	-	-	-
682.4	C3.StatusAccel_DemandValue	Status demand acceleration	325	0x200E	I32	no	-	-	-
682.7	C3.StatusAccel_FeedForwardAccel	Status acceleration feed forward			C4_3	no	-	-	-
692.4	C3.StatusFeedback_EncoderCosine	Status of analog input cosine			I32	no	-	-	-
692.3	C3.StatusFeedback_EncoderSine	Status of analog input sine			I32	no	-	-	-
692.2	C3.StatusFeedback_FeedbackCosineDSP	Status of cosine in signal processing			I32	yes	-	-	-
692.1	C3.StatusFeedback_FeedbackSineDSP	Status of sine in signal processing			I32	yes	-	-	-
692.5	C3.StatusFeedback_FeedbackVoltage[Vpp]	Status of feedback level			C4_3	no	-	-	-
695.11	C3.StatusForce_Actual	Actual value force controller main axis [N]	221		I32	yes	-	-	-
695.14	C3.StatusForce_Actual2	Actual value force controller auxiliary axis [N]	222		I32	yes	-	-	-
695.10	C3.StatusForce_Demand	Setpoint value force controller main axis [N]			I32	no	-	-	-
695.13	C3.StatusForce_Demand2	Setpoint value force controller auxiliary axis [N]			I32	no	-	-	-
695.12	C3.StatusForce_Error	Control deviation force controller main axis [N]			I32	no	-	-	-
695.15	C3.StatusForce_Error2	Control deviation force controller auxiliary axis [N]			I32	no	-	-	-
695.1	C3.StatusForce_Force1	Force of force sensor main axis			I32	no	-	-	-
695.2	C3.StatusForce_Force2	Force of force sensor of auxiliary axis			I32	no	-	-	-
689.1	C3.StatusHeda_RxPD	Receive string			OS	no	-	-	-
689.2	C3.StatusHeda_TxPD	Transmit string			OS	no	-	-	-
697.4	C3.StatusPosController_ActuatingSignal_AddAccel_YA	Acceleration feedback (A1)			C4_3	no	-	-	-
697.14	C3.StatusPosController_ActuatingSignal_AddAccel_YA2	Acceleration feedback (A2)			C4_3	no	-	-	-
697.3	C3.StatusPosController_ActuatingSignal_AddSpeed_YV	Speed feedback (A1)			C4_3	no	-	-	-

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	I20	I21 / I22
697.13	C3.StatusPosController_ActuatingSignal_AddSpeed_YV2	Speed feedback (A2)			C4_3	no	-	-	-	-
697.2	C3.StatusPosController_ActuatingSignal_IPart_Y1	Control signal I-term (A1)			C4_3	no	-	-	-	-
697.12	C3.StatusPosController_ActuatingSignal_IPart_Y12	Control signal I-term (A2)			C4_3	no	-	-	-	-
697.5	C3.StatusPosController_ActuatingSignal_PosCtrl_Ycom	Control signal total (A1)			C4_3	no	-	-	-	-
697.15	C3.StatusPosController_ActuatingSignal_PosCtrl_Ycom2	Control signal total (A2)			C4_3	no	-	-	-	-
697.1	C3.StatusPosController_ActuatingSignal_PPart_YP	Control signal P-term (A1)			C4_3	no	-	-	-	-
697.11	C3.StatusPosController_ActuatingSignal_PPart_YP2	Control signal P-term (A2)			C4_3	no	-	-	-	-
680.5	C3.StatusPosition_Actual	Status actual position	28	0x6064	C4_3	yes	-	-	-	-
680.15	C3.StatusPosition_Actual2	Actual position of auxiliary axis	211		C4_3	yes	-	-	-	-
680.13	C3.StatusPosition_ActualController	Status actual position without absolute reference			C4_3	no	-	-	-	-
680.18	C3.StatusPosition_ActualNotReset	Status actual position (not reset)			C4_3	yes	-	-	-	-
680.12	C3.StatusPosition_DemandController	Status demand position without absolute reference			C4_3	no	-	-	-	-
680.4	C3.StatusPosition_DemandValue	Status demand position	323	0x60FC	C4_3	yes	-	-	-	-
680.1	C3.StatusPosition_DemandValue1	Position command value of Profile transmitter1	0	0x2052	Y4	yes	-	-	-	-
680.2	C3.StatusPosition_DemandValue2	Status demand position virtual master	202	0x2042	Y4	yes	-	-	-	-
680.11	C3.StatusPosition_EncoderInput24V	Status of encoder input 0 (24V)			C4_3	yes	-	-	-	-
680.10	C3.StatusPosition_EncoderInput5V	Status of encoder input 0 (5V)		0x2095.2	C4_3	yes	-	-	-	-
680.6	C3.StatusPosition_FollowingError	Status of tracking error	100	0x60F4	C4_3	yes	-	-	-	-
680.16	C3.StatusPosition_FollowingError2	Following error auxiliary axis	212		C4_3	yes	-	-	-	-
680.17	C3.StatusPosition_MasterSlaveError	Position deviation main/auxiliary axis			C4_3	no	-	-	-	-
680.30	C3.StatusPosition_Referenced	Status of axis referenced			I16	no	-	-	-	-
694.4	C3.StatusPressure_p01	System pressure for main axis	216		C4_3	yes	-	-	-	-
694.9	C3.StatusPressure_p02	System pressure for auxiliary axis	220		C4_3	yes	-	-	-	-
694.1	C3.StatusPressure_pA1	Pressure on A side of main axis	213		C4_3	yes	-	-	-	-
694.6	C3.StatusPressure_pA2	Pressure on A side of auxiliary axis	217		C4_3	yes	-	-	-	-
694.2	C3.StatusPressure_pB1	Pressure on B side of main axis	214		C4_3	yes	-	-	-	-
694.7	C3.StatusPressure_pB2	Pressure on B side of auxiliary axis	218		C4_3	yes	-	-	-	-
694.3	C3.StatusPressure_pT1	Tank pressure for main axis	215		C4_3	yes	-	-	-	-
694.8	C3.StatusPressure_pT2	Tank pressure for auxiliary axis	219		C4_3	yes	-	-	-	-
698.4	C3.StatusPressureForceController_ActuatingSignal_AddSpeed_YV	Control signal velocity component of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.14	C3.StatusPressureForceController_ActuatingSignal_AddSpeed_YV2	Control signal velocity component of force/pressure controller (A2)			C4_3	no	-	-	-	-
698.3	C3.StatusPressureForceController_ActuatingSignal_DPart_YD	Control signal D-term of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.13	C3.StatusPressureForceController_ActuatingSignal_DPart_YD2	Control signal D-term of force/pressure controller (A2)			C4_3	no	-	-	-	-
698.6	C3.StatusPressureForceController_ActuatingSignal_FFPart_YF	Force feedforward of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.16	C3.StatusPressureForceController_ActuatingSignal_FFPart_YF2	Force feedforward of force/pressure controller (A2)			C4_3	no	-	-	-	-
698.5	C3.StatusPressureForceController_ActuatingSignal_ForceCtrl_Ycom	Total control signal of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.15	C3.StatusPressureForceController_ActuatingSignal_ForceCtrl_Ycom2	Total control signal of force/pressure controller (A2)			C4_3	no	-	-	-	-
698.2	C3.StatusPressureForceController_ActuatingSignal_IPart_Y1	Control signal I-term of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.12	C3.StatusPressureForceController_ActuatingSignal_IPart_Y12	Control signal I-term of force/pressure controller (A2)			C4_3	no	-	-	-	-
698.1	C3.StatusPressureForceController_ActuatingSignal_PPart_YP	Control signal P-term of force/pressure controller (A1)			C4_3	no	-	-	-	-
698.11	C3.StatusPressureForceController_ActuatingSignal_PPart_YP2	Control signal P-term of force/pressure controller (A2)			C4_3	no	-	-	-	-
681.5	C3.StatusSpeed_Actual	Status actual speed unfiltered	8	0x6069	C4_3	yes	-	-	-	-
681.14	C3.StatusSpeed_Actual2Filtered	Actual speed unfiltered auxiliary axis	210		C4_3	yes	-	-	-	-
681.9	C3.StatusSpeed_ActualFiltered	Status actual speed filtered		0x606C	C4_3	yes	-	-	-	-
681.7	C3.StatusSpeed_ActualFiltered_Y2	Status of the actual filtered speed speed in the Y2 format	6	0x2023	Y2	yes	-	X	X	X
681.8	C3.StatusSpeed_ActualFiltered_Y4	Status of the actual filtered speed in the Y4 format	117	0x2024	Y4	yes	-	X	X	X
681.12	C3.StatusSpeed_ActualScaled	Filtered actual speed			C4_3	no	-	-	-	-
681.13	C3.StatusSpeed_DemandScaled	Setpoint speed of the setpoint generator			C4_3	no	-	-	-	-
681.10	C3.StatusSpeed_DemandSpeedController	Status demand speed controller input			C4_3	yes	-	-	-	-
681.4	C3.StatusSpeed_DemandValue	Status demand speed of setpoint generator	324	0x606B	C4_3	yes	-	-	-	-
681.1	C3.StatusSpeed_DemandValue1	Speed command value of profile transmitter1	337	0x2053	Y4	yes	-	-	-	-
681.2	C3.StatusSpeed_DemandValue2	Status demand speed virtual master	203	0x2043	Y4	yes	-	-	-	-
681.6	C3.StatusSpeed_Error	Status control deviation of speed	101	0x2027	C4_3	yes	-	-	-	-
681.15	C3.StatusSpeed_Error2	Speed control deviation			C4_3	no	-	-	-	-
681.11	C3.StatusSpeed_FeedForwardSpeed	Status speed feed forward			C4_3	no	-	-	-	-
685.3	C3.StatusVoltage_AnalogInput0	Status of analog input 0	23	0x2025	Y2	yes	-	-	-	-
685.4	C3.StatusVoltage_AnalogInput1	Status of analog input 1	102	0x2026	Y2	yes	-	-	-	-
685.1	C3.StatusVoltage_AuxiliaryVoltage	Status of auxiliary voltage	326	0x200F	E2_6	no	-	-	-	-
210.10	C3.ValidParameter_Global	Set objects to valid	338.10	0x2016.10	U16	no	Immediately	-	-	-
210.6	C3.ValidParameter_Limits				U16	no	Immediately	-	-	-
180.6	C3.ValveOutput0_Status	Status of valve output 0			U16	no	-	-	-	-
181.6	C3.ValveOutput1_Status	Status of valve output 1			U16	no	-	-	-	-
182.6	C3.ValveOutput2_Status	Status of valve output 2			U16	no	-	-	-	-
183.6	C3.ValveOutput3_Status	Status of valve output 3			U16	no	-	-	-	-
1901.1	C3.Array.Col01_Row01	variable Column 1 Row 1	130/341.1	0x2301.1	Y4	yes	Immediately	-	-	-



No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
1901.2	C3Array.Col01_Row02	Variable Column 1 Row 2	131/341.2	0x2301.2	Y4	yes	Immediat ely	-	-
1901.3	C3Array.Col01_Row03	Variable Column 1 Row 3	132/341.3	0x2301.3	Y4	yes	Immediat ely	-	-
1901.4	C3Array.Col01_Row04	Variable Column 1 Row 4	133/341.4	0x2301.4	Y4	yes	Immediat ely	-	-
1901.5	C3Array.Col01_Row05	Variable Column 1 Row 5	134/341.5	0x2301.5	Y4	yes	Immediat ely	-	-
1902.1	C3Array.Col02_Row01	variable Column 2 Row 1	135/342.1	0x2302.1	Y2	yes	Immediat ely	-	-
1902.2	C3Array.Col02_Row02	variable Column 2 Row 2	136/342.2	0x2302.2	Y2	yes	Immediat ely	-	-
1902.3	C3Array.Col02_Row03	variable Column 2 Row 3	137/342.3	0x2302.3	Y2	yes	Immediat ely	-	-
1902.4	C3Array.Col02_Row04	Variable Column 2 Row 4	138/342.4	0x2302.4	Y2	yes	Immediat ely	-	-
1902.5	C3Array.Col02_Row05	Variable Column 2 Row 5	139/342.5	0x2302.5	Y2	yes	Immediat ely	-	-
1903.1	C3Array.Col03_Row01	variable Column 3 Row 1	140/343.1	0x2303.1	I16	yes	Immediat ely	-	-
1903.2	C3Array.Col03_Row02	Variable Column 3 Row 2	141/343.2	0x2303.2	I16	yes	Immediat ely	-	-
1903.3	C3Array.Col03_Row03	Variable Column 3 Row 3	142/343.3	0x2303.3	I16	yes	Immediat ely	-	-
1903.4	C3Array.Col03_Row04	Variable Column 3 Row 4	143/343.4	0x2303.4	I16	yes	Immediat ely	-	-
1903.5	C3Array.Col03_Row05	Variable Column 3 Row 5	144/343.5	0x2303.5	I16	yes	Immediat ely	-	-
1904.1	C3Array.Col04_Row01	variable Column 4 Row 1	145/344.1	0x2304.1	I16	yes	Immediat ely	-	-
1904.2	C3Array.Col04_Row02	Variable Column 4 Row 2	146/344.2	0x2304.2	I16	yes	Immediat ely	-	-
1904.3	C3Array.Col04_Row03	Variable Column 4 Row 3	147/344.3	0x2304.3	I16	yes	Immediat ely	-	-
1904.4	C3Array.Col04_Row04	Variable Column 4 Row 4	148/344.4	0x2304.4	I16	yes	Immediat ely	-	-
1904.5	C3Array.Col04_Row05	Variable Column 4 Row 5	149/344.5	0x2304.5	I16	yes	Immediat ely	-	-
1905.1	C3Array.Col05_Row01	variable Column 5 Row 1	150/345.1	0x2305.1	I16	yes	Immediat ely	-	-
1905.2	C3Array.Col05_Row02	Variable Column 5 Row 2	151/345.2	0x2305.2	I16	yes	Immediat ely	-	-
1905.3	C3Array.Col05_Row03	Variable Column 5 Row 3	152/345.3	0x2305.3	I16	yes	Immediat ely	-	-
1905.4	C3Array.Col05_Row04	Variable Column 5 Row 4	153/345.4	0x2305.4	I16	yes	Immediat ely	-	-
1905.5	C3Array.Col05_Row05	Variable Column 5 Row 5	154/345.5	0x2305.5	I16	yes	Immediat ely	-	-
1906.1	C3Array.Col06_Row01	variable Column 6 Row 1	155/346.1	0x2306.1	I32	yes	Immediat ely	-	-
1906.2	C3Array.Col06_Row02	Variable Column 6 Row 2	156/346.2	0x2306.2	I32	yes	Immediat ely	-	-
1906.3	C3Array.Col06_Row03	Variable Column 6 Row 3	157/346.3	0x2306.3	I32	yes	Immediat ely	-	-
1906.4	C3Array.Col06_Row04	Variable Column 6 Row 4	158/346.4	0x2306.4	I32	yes	Immediat ely	-	-
1906.5	C3Array.Col06_Row05	Variable Column 6 Row 5	159/346.5	0x2306.5	I32	yes	Immediat ely	-	-
1907.1	C3Array.Col07_Row01	variable Column 7 Row 1	160/347.1	0x2307.1	I32	yes	Immediat ely	-	-
1907.2	C3Array.Col07_Row02	Variable Column 7 Row 2	161/347.2	0x2307.2	I32	yes	Immediat ely	-	-
1907.3	C3Array.Col07_Row03	Variable Column 7 Row 3	162/347.3	0x2307.3	I32	yes	Immediat ely	-	-
1907.4	C3Array.Col07_Row04	Variable Column 7 Row 4	163/347.4	0x2307.4	I32	yes	Immediat ely	-	-
1907.5	C3Array.Col07_Row05	Variable Column 7 Row 5	164/347.5	0x2307.5	I32	yes	Immediat ely	-	-
1908.1	C3Array.Col08_Row01	variable Column 8 Row 1	165/348.1	0x2308.1	I32	yes	Immediat ely	-	-
1908.2	C3Array.Col08_Row02	Variable Column 8 Row 2	166/348.2	0x2308.2	I32	yes	Immediat ely	-	-
1908.3	C3Array.Col08_Row03	Variable Column 8 Row 3	167/348.3	0x2308.3	I32	yes	Immediat ely	-	-
1908.4	C3Array.Col08_Row04	Variable Column 8 Row 4	168/348.4	0x2308.4	I32	yes	Immediat ely	-	-
1908.5	C3Array.Col08_Row05	Variable Column 8 Row 5	169/348.5	0x2308.5	I32	yes	Immediat ely	-	-
1909.1	C3Array.Col09_Row01	variable Column 9 Row 1	170/349.1	0x2309.1	I32	yes	Immediat ely	-	-
1909.2	C3Array.Col09_Row02	Variable Column 9 Row 2	171/349.2	0x2309.2	I32	yes	Immediat ely	-	-
1909.3	C3Array.Col09_Row03	Variable Column 9 Row 3	172/349.3	0x2309.3	I32	yes	Immediat ely	-	-
1909.4	C3Array.Col09_Row04	Variable Column 9 Row 4	173/349.4	0x2309.4	I32	yes	Immediat ely	-	-
1909.5	C3Array.Col09_Row05	Variable Column 9 Row 5	174/349.5	0x2309.5	I32	yes	Immediat ely	-	-
1910.1	C3Array.Indirect_Col01	Indirect table access Column 1	181	0x2311	Y4	yes	Immediat ely	-	-
1910.2	C3Array.Indirect_Col02	Indirect table access Column 2	182	0x2312	Y2	yes	Immediat ely	-	-
1910.3	C3Array.Indirect_Col03	Indirect table access Column 3	183	0x2313	I16	yes	Immediat ely	-	-
1910.4	C3Array.Indirect_Col04	Indirect table access Column 4	184	0x2314	I16	yes	Immediat ely	-	-
1910.5	C3Array.Indirect_Col05	Indirect table access Column 5	185	0x2315	I16	yes	Immediat ely	-	-

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
1910.6	C3Array.Indirect_Col06	Indirect table access Column 6	186	0x2316	I32	yes	Immediately	-	-
1910.7	C3Array.Indirect_Col07	Indirect table access Column 7	187	0x2317	I32	yes	Immediately	-	-
1910.8	C3Array.Indirect_Col08	Indirect table access Column 8	188	0x2318	I32	yes	Immediately	-	-
1910.9	C3Array.Indirect_Col09	Indirect table access Column 9	189	0x2319	I32	yes	Immediately	-	-
1900.1	C3Array.Pointer_Row	Pointer to table row	180	0x2300	U16	yes	Immediately	-	-
3730.3	C3Cam.ControlledSwitch00_PositionOff	switch-off position of cam	509.1	0x2409.1	C4_3	no	VP	-	-
3730.2	C3Cam.ControlledSwitch00_PositionOn	switch-on position of cam	508.1	0x2408.1	C4_3	no	VP	-	-
3730.1	C3Cam.ControlledSwitch00_Source	source of cam	507.1	0x2407.1	I16	no	VP	-	-
3730.5	C3Cam.ControlledSwitch00_TimeOff	switch-off anticipation of cam	511.1	0x240B.1	I16	no	Immediately	-	-
3730.4	C3Cam.ControlledSwitch00_TimeOn	switch-on anticipation of cam	510.1	0x240A.1	I16	no	Immediately	-	-
3701.2	C3Cam.ControlledSwitches_Enable0	enable of cam group 0	501.2	0x2401.2	U16	no	Immediately	-	-
3701.4	C3Cam.ControlledSwitches_Enable1	enable of cam group 1	501.4	0x2401.4	U16	no	Immediately	-	-
3701.6	C3Cam.ControlledSwitches_NumberPerCycle	Number of cams in one cycle			U16	no	Immediately	-	-
3701.3	C3Cam.ControlledSwitches_Output0	output of cam group 0	205/501.3	0x2401.3	U16	yes	Immediately	-	-
3701.5	C3Cam.ControlledSwitches_Output1	output of cam group 1	206/501.5	0x2401.5	U16	yes	Immediately	-	-
3700.2	C3Cam.ControlledSwitchesFast_Enable	enable fast cams	500.2	0x2400.2	U16	no	Immediately	-	-
3700.3	C3Cam.ControlledSwitchesFast_Output	output for fast cams	204/500.3	0x2400.3	U16	yes	Immediately	-	-
3705.1	C3Cam.ControlledSwitchesHysteresis_ActualPosition	Hysteresis for cam switching mechanism, source "current position"			C4_3	no	VP	-	-
3705.5	C3Cam.ControlledSwitchesHysteresis_Masterposition	Hysteresis for cam switching mechanism, source "master position"			C4_3	no	VP	-	-
3710.3	C3Cam.ControlledSwitchFast0_PositionOff	switch-off position for fast cam	504.1	0x2404.1	C4_3	no	VP	-	-
3710.2	C3Cam.ControlledSwitchFast0_PositionOn	switch-on position for fast cam	503.1	0x2403.1	C4_3	no	VP	-	-
3710.1	C3Cam.ControlledSwitchFast0_Source	source of fast cam	502.1	0x2402.1	I16	no	VP	-	-
3710.5	C3Cam.ControlledSwitchFast0_TimeOff	switch-off anticipation of fast cam	506.1	0x2406.1	I16	no	Immediately	-	-
3710.4	C3Cam.ControlledSwitchFast0_TimeOn	switch-on anticipation of fast cam	505.1	0x2405.1	I16	no	Immediately	-	-
3022.1	C3Cam.Manipulation_OffsetMasterposition	Master position offset			C4_3	no	Immediately	-	-
3022.6	C3Cam.Manipulation_OffsetMasterposition_Units	Offset Master position			C4_3	no	Immediately	-	-
3022.3	C3Cam.Manipulation_ScalefactorMasterGlobal	Global scaling factor for the master speed			C4_3	no	Immediately	-	-
3021.10	C3Cam.SignalSource_InputAdditional	CAM Master position			C4_3	yes	Immediately	-	-
3021.2	C3Cam.SignalSource_Position	Status of position of selected master signal source			C4_3	yes	-	-	-
3021.1	C3Cam.SignalSource_Select	Source of master position			U16	no	Immediately	-	-
3031.4	C3Cam.StatusData_ActualCurve	Current curve number			I16	no	-	-	-
3030.7	C3Cam.StatusMaster_Enable	Status: Enable of master acquisition			U16	no	-	-	-
3030.17	C3Cam.StatusMaster_EnableCam	Status: Enable of cam input			U16	no	-	-	-
3030.13	C3Cam.StatusMaster_InputSum	Free running master position after MP enable			C4_3	yes	-	-	-
3030.12	C3Cam.StatusMaster_PhasingSum	Added up position sum of the master-side phasing			C4_3	no	-	-	-
3030.1	C3Cam.StatusMaster_Position	Reset master position	207	0x2410	C4_3	yes	-	-	-
3030.24	C3Cam.StatusMaster_PositionCamUnits	Master position at the beginning of the curve			C4_3	yes	-	-	-
3030.22	C3Cam.StatusMaster_SpeedUnits	Master speed [Units/s]			C4_3	no	-	-	-
3032.4	C3Cam.StatusOutput_AbsolutePositionGreat	Slave position (free running)			C4_3	yes	-	-	-
3032.24	C3Cam.StatusOutput_CurvePositionUnits	End of curve	208	0x2411	C4_3	yes	-	-	-
3032.1	C3Cam.StatusOutput_Position	Slave position			C4_3	yes	-	-	-
172.3	C3Plus.AnalogInput0_FilterCoefficient	Filter X1:IN0			I32	no	VP	-	-
172.2	C3Plus.AnalogInput0_Gain	Gain X1:IN0			C4_3	no	VP	-	-
172.9	C3Plus.AnalogInput0_LowerLimit	Lower limit value X1:IN0			I32	no	Immediately	-	-
172.11	C3Plus.AnalogInput0_Offset_normed	Offset X1:IN0			C4_3	no	Immediately	-	-
172.10	C3Plus.AnalogInput0_UpperLimit	upper limit value X1:IN0			I32	no	Immediately	-	-
173.3	C3Plus.AnalogInput1_FilterCoefficient	Filter X1:IN1			I32	no	VP	-	-
173.2	C3Plus.AnalogInput1_Gain	Gain X1:IN1			C4_3	no	VP	-	-
173.9	C3Plus.AnalogInput1_LowerLimit	Lower limit value X1:IN1			I32	no	Immediately	-	-
173.11	C3Plus.AnalogInput1_Offset_normed	Offset X1:IN1			C4_3	no	Immediately	-	-
173.10	C3Plus.AnalogInput1_UpperLimit	Upper limit value X1:IN1			I32	no	Immediately	-	-
174.3	C3Plus.AnalogInput2_FilterCoefficient	Filter X1:IN2			I32	no	VP	-	-
174.2	C3Plus.AnalogInput2_Gain	Gain X1:IN2			C4_3	no	VP	-	-
174.9	C3Plus.AnalogInput2_LowerLimit	Lower limit value X1:IN2			I32	no	Immediately	-	-
174.11	C3Plus.AnalogInput2_Offset_normed	Offset X1:IN2			C4_3	no	Immediately	-	-
174.10	C3Plus.AnalogInput2_UpperLimit	upper limit value X1:IN2			I32	no	Immediately	-	-
175.3	C3Plus.AnalogInput3_FilterCoefficient	Filter X1:IN3			I32	no	VP	-	-
175.2	C3Plus.AnalogInput3_Gain	Gain X1:IN3			C4_3	no	VP	-	-

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
175.9	C3Plus.AnalogInput3_LowerLimit	Lower limit value X1:IN3			I32	no	Immediately	-	-
175.11	C3Plus.AnalogInput3_Offset_normed	Offset X1:IN3			C4_3	no	Immediately	-	-
175.10	C3Plus.AnalogInput3_UpperLimit	Upper limit value X1:IN3			I32	no	Immediately	-	-
176.3	C3Plus.AnalogInput4_FilterCoefficient	Filter X1:IN4			I16	no	VP	-	-
176.2	C3Plus.AnalogInput4_Gain	Gain X1:IN4			C4_3	no	VP	-	-
176.9	C3Plus.AnalogInput4_LowerLimit	Lower limit value X1:IN4			I32	no	Immediately	-	-
176.11	C3Plus.AnalogInput4_Offset_normed	Offset X1:IN4			C4_3	no	Immediately	-	-
176.10	C3Plus.AnalogInput4_UpperLimit	Upper limit value X1:IN4			I32	no	Immediately	-	-
177.3	C3Plus.AnalogInput5_FilterCoefficient	Filter X1:IN5			I16	no	VP	-	-
177.2	C3Plus.AnalogInput5_Gain	Gain X1:IN5			C4_3	no	VP	-	-
177.11	C3Plus.AnalogInput5_Offset_normed	Offset X1:IN4			C4_3	no	Immediately	-	-
177.10	C3Plus.AnalogInput5_UpperLimit	Upper limit value X1:IN5			I32	no	Immediately	-	-
206.1	C3Plus.C3FluidNorm_Metric_Imperial	Unit system			BOOL	no	Immediately	-	-
2439.3	C3Plus.CurveMemory_Erase	Delete valve characteristics			I16	no	Immediately	-	-
2405.2	C3Plus.DeadBandCompensation_Ch0_A_Side	Threshold value on A side output 0			I32	no	VP	-	-
2405.3	C3Plus.DeadBandCompensation_Ch0_B_Side	Threshold value on B side output 0			I32	no	VP	-	-
2405.4	C3Plus.DeadBandCompensation_Ch0_Threshold	Width of deadband output 0			I32	no	VP	-	-
2405.1	C3Plus.DeadBandCompensation_Ch0_Type	Deadband compensation output 0			I16	no	VP	-	-
2415.2	C3Plus.DeadBandCompensation_Ch1_A_Side	Threshold value on A side output 1			I32	no	VP	-	-
2415.3	C3Plus.DeadBandCompensation_Ch1_B_Side	Threshold value on B side output 1			I32	no	VP	-	-
2415.4	C3Plus.DeadBandCompensation_Ch1_Threshold	Width of deadband output 1			I32	no	VP	-	-
2415.1	C3Plus.DeadBandCompensation_Ch1_Type	Deadband compensation output 1			I16	no	VP	-	-
2425.2	C3Plus.DeadBandCompensation_Ch2_A_Side	Threshold value on A side output 2			I32	no	VP	-	-
2425.3	C3Plus.DeadBandCompensation_Ch2_B_Side	Threshold value on B side output 2			I32	no	VP	-	-
2425.4	C3Plus.DeadBandCompensation_Ch2_Threshold	Width of deadband output 2			I32	no	VP	-	-
2425.1	C3Plus.DeadBandCompensation_Ch2_Type	Deadband compensation output 2			I16	no	VP	-	-
2435.2	C3Plus.DeadBandCompensation_Ch3_A_Side	Threshold value on A side output 3			I32	no	VP	-	-
2435.3	C3Plus.DeadBandCompensation_Ch3_B_Side	Threshold value on B side output 3			I32	no	VP	-	-
2435.4	C3Plus.DeadBandCompensation_Ch3_Threshold	Width of deadband output 3			I32	no	VP	-	-
2435.1	C3Plus.DeadBandCompensation_Ch3_Type	Deadband compensation output 3			I16	no	VP	-	-
1100.1	C3Plus.DeviceControl_CommandOnRequest	Control command	108	0x2028	I16	yes	Immediately	-	-
1100.3	C3Plus.DeviceControl_Controlword_1	Control word CW	1	0x6040	V2	yes	Immediately	-	-
1100.4	C3Plus.DeviceControl_Controlword_2	Control word 2	3	0x201B	V2	yes	Immediately	-	-
1100.8	C3Plus.DeviceControl_DemandValue3	Device demand value C		0x2048	Y2	yes	Immediately	-	-
1100.5	C3Plus.DeviceControl_OperationMode	Operating mode	127/930	0x6060	I16	yes	Immediately	X	X
1000.5	C3Plus.DeviceState_ActualOperationMode	Operating mode display	128	0x6061	I16	yes	Immediately	X	X
1000.3	C3Plus.DeviceState_Statusword_1	Status word SW	2	0x6041	V2	yes	Immediately	-	-
1000.4	C3Plus.DeviceState_Statusword_2	Status word 2	4	0x201C	V2	yes	Immediately	-	-
2401.5	C3Plus.DirectionDependentGain_Ch0_Factor_negative	Direction dependent gain			I32	no	Immediately	-	-
2401.4	C3Plus.DirectionDependentGain_Ch0_Factor_positive	Direction dependent gain			I32	no	Immediately	-	-
2401.6	C3Plus.DirectionDependentGain_Ch0_InvertType	Inversion output 0			I16	no	Immediately	-	-
2411.5	C3Plus.DirectionDependentGain_Ch1_Factor_negative	Gain factor for negative input values			I32	no	Immediately	-	-
2411.4	C3Plus.DirectionDependentGain_Ch1_Factor_positive	Gain factor for positive input values			I32	no	Immediately	-	-
2411.6	C3Plus.DirectionDependentGain_Ch1_InvertType	Inversion output 1			I16	no	Immediately	-	-
2421.5	C3Plus.DirectionDependentGain_Ch2_Factor_negative	Gain factor for negative input values			I32	no	Immediately	-	-
2421.4	C3Plus.DirectionDependentGain_Ch2_Factor_positive	Gain factor for positive input values			I32	no	Immediately	-	-
2421.6	C3Plus.DirectionDependentGain_Ch2_InvertType	Inversion output 3			I16	no	Immediately	-	-
2431.5	C3Plus.DirectionDependentGain_Ch3_Factor_negative	Direction dependent gain			I32	no	Immediately	-	-
2431.4	C3Plus.DirectionDependentGain_Ch3_Factor_positive	Direction dependent gain			I32	no	Immediately	-	-
2431.6	C3Plus.DirectionDependentGain_Ch3_InvertType	Inversion output 3			I16	no	Immediately	-	-
550.1	C3Plus.ErrorHistory_LastError	Current error (n)	115/947.0	0x603F/ 0x201D.1	U16	yes	-	-	-
2020.7	C3Plus.ExternalSignal_Accel_Munits	Acceleration of the external signal source			I32	yes	-	-	-
2020.6	C3Plus.ExternalSignal_Speed_Munits	Speed value of the external signal source			C4_3	yes	-	-	-
3921.7	C3Plus.FBI_SignalProcessing0_OutputGreat	Interpolation output of the Position CanSync, PowerLink			Y4	no	-	-	X
3921.8	C3Plus.FBI_SignalProcessing0_Source	Switching the position source of the interpolator			I16	no	Immediately	-	X
1141.10	C3Plus.GEAR_FFW_mode	Control bits for feedforward with source CANSync/EthernetPowerLink		0x2097	U16	no	Immediately	-	X
1141.4	C3Plus.GEAR_mode	Source selection Gearing		0x2055	U16	no	Immediately	-	-

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	I20	I21 / I22
900.12	C3Plus.HEDA_CRC_ErrorCounter	Error counter CRC (HEDA)			U32	no	Immediately	-	-	-
3920.1	C3Plus.HEDA_SignalProcessing_Input	Process input signal Slave			C4_3	yes	Immediately	-	-	-
3920.7	C3Plus.HEDA_SignalProcessing_OutputGreat	Output of the Heda Tracking Filter			C4_3	no	-	-	-	-
900.1	C3Plus.HEDA_State	Status HEDA			I16	no	Immediately	-	-	-
900.13	C3Plus.HEDA_SyncErrorCounter	Error counter Sync (HEDA)			U32	no	Immediately	-	-	-
1130.1	C3Plus.HOMING_accel	Acceleration / deceleration homing run	300	0x609A	U32	no	Immediately	-	-	-
1130.7	C3Plus.HOMING_edge_sensor_distance	Initiator adjustment	304	0x2000	C4_3	no	Immediately	-	-	-
1130.2	C3Plus.HOMING_jerk	Jerk for machine reference run	357	0x201E	U32	no	Immediately	-	-	-
1130.4	C3Plus.HOMING_mode	Adjusting the machine reference mode	302	0x6098	U16	no	Immediately	-	-	-
1130.3	C3Plus.HOMING_speed	Speed for machine reference run	301	0x6099.1	C4_3	no	Immediately	-	-	-
201.2	C3Plus.NormFactorY4_Position	Scaling factor for Y4 positions	356.2	0x2021.2	V2	no	Immediately	X	X	X
2400.7	C3Plus.OutputConditioningChain_Ch0_Input_DefaultValue	Replacement value at the input of Chain0			I32	no	VP	-	-	-
2400.5	C3Plus.OutputConditioningChain_Ch0_Input_Offset	Offset at input Chain 0			I16	no	VP	-	-	-
2400.4	C3Plus.OutputConditioningChain_Ch0_Lower_Limit	Lower output limitation of output 0			I16	no	VP	-	-	-
2400.6	C3Plus.OutputConditioningChain_Ch0_Output_Offset	Offset at output Chain 0			I32	no	VP	-	-	-
2400.3	C3Plus.OutputConditioningChain_Ch0_Upper_Limit	Upper output limitation of output 0			I16	no	VP	-	-	-
2410.7	C3Plus.OutputConditioningChain_Ch1_Input_DefaultValue	Preset value at the input of Chain1			I32	no	VP	-	-	-
2410.5	C3Plus.OutputConditioningChain_Ch1_Input_Offset	Offset at input Chain1			I16	no	VP	-	-	-
2410.4	C3Plus.OutputConditioningChain_Ch1_Lower_Limit	Lower output limitation of output 1			I16	no	VP	-	-	-
2410.6	C3Plus.OutputConditioningChain_Ch1_Output_Offset	Offset at output Chain1			I32	no	VP	-	-	-
2410.3	C3Plus.OutputConditioningChain_Ch1_Upper_Limit	Upper output limitation of output 1			I16	no	VP	-	-	-
2420.7	C3Plus.OutputConditioningChain_Ch2_Input_DefaultValue	Preset value at the input of Chain2			I32	no	VP	-	-	-
2420.5	C3Plus.OutputConditioningChain_Ch2_Input_Offset	Offset at input Chain2			I16	no	VP	-	-	-
2420.4	C3Plus.OutputConditioningChain_Ch2_Lower_Limit	Lower output limitation of output 2			I16	no	VP	-	-	-
2420.6	C3Plus.OutputConditioningChain_Ch2_Output_Offset	Offset at output Chain2			I32	no	VP	-	-	-
2420.3	C3Plus.OutputConditioningChain_Ch2_Upper_Limit	Upper output limitation of output 2			I16	no	VP	-	-	-
2430.7	C3Plus.OutputConditioningChain_Ch3_Input_DefaultValue	Preset value at the input of Chain3			I32	no	VP	-	-	-
2430.5	C3Plus.OutputConditioningChain_Ch3_Input_Offset	Offset at input Chain 3			I16	no	VP	-	-	-
2430.4	C3Plus.OutputConditioningChain_Ch3_Lower_Limit	Lower limit of valve output 3			I16	no	VP	-	-	-
2430.6	C3Plus.OutputConditioningChain_Ch3_Output_Offset	Offset at output Chain 3			I32	no	VP	-	-	-
2430.3	C3Plus.OutputConditioningChain_Ch3_Upper_Limit	Upper limit of valve output 3			I16	no	VP	-	-	-
185.1	C3Plus.OutputGroup_OutputSelect_0	Output signal valves 0 & 1			BOOL	no	Immediately	-	-	-
185.2	C3Plus.OutputGroup_OutputSelect_1	Output signal valves 2&3			BOOL	no	Immediately	-	-	-
1200.1	C3Plus.PG2Control_CommandOnRequest	Control of virtual Master	200	0x2040	I16	yes	Immediately	-	-	-
1211.13	C3Plus.PG2POSITION_direction	Manipulation of the motion direction in reset mode			I32	no	Immediately	-	-	-
50.3	C3Plus.PLC_ActualCycleTime	Status of cycle time of the control program	353	0x201F.2	U16	no	-	-	-	-
50.4	C3Plus.PLC_ActualCycleTimeMax	Status of maximum cycle time	354	0x201F.3	U16	no	Immediately	-	-	-
50.1	C3Plus.PLC_DemandCycleTime	Cycle time specification	352	0x201F.1	U16	no	Immediately	-	-	-
1111.3	C3Plus.POSITION_accel	Acceleration for positioning	114	0x6083	U32	yes	Immediately	-	-	-
1111.4	C3Plus.POSITION_decel	Deceleration for positioning	312	0x6084	U32	yes	Immediately	-	-	-
1111.13	C3Plus.POSITION_direction	Manipulation of the motion direction in reset mode			I32	no	Immediately	-	-	-
1111.5	C3Plus.POSITION_jerk_accel	Acceleration jerk for positioning	313	0x2005	U32	no	Immediately	-	-	-
1111.6	C3Plus.POSITION_jerk_decel	Deceleration jerk for positioning	314	0x2006	U32	no	Immediately	-	-	-
1111.1	C3Plus.POSITION_position	Target position	27		C4_3	yes	Immediately	-	-	-
1111.8	C3Plus.POSITION_resetposition_mode	Continuous mode	0	0	U16	no	Immediately	-	-	-
1111.2	C3Plus.POSITION_speed	Speed for positioning	111		C4_3	yes	Immediately	-	-	-
1111.9	C3Plus.POSITION_speed_Y2	Speed for Positioning in Y2 Format	110		Y2	yes	Immediately	-	-	-
1111.17	C3Plus.POSITION_turnaround	Direction inversion - lock			U16	no	Immediately	-	-	-
2260.13	C3Plus.PositionController_2_DeadBand	Deadband of position controller auxiliary axis			C4_3	no	VP	-	-	-

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
2260.20	C3Plus.PositionController_2_Disturbance_Offset	Disturbance compensation (A2)			C4_3	no	Immediately	-	-
2260.14	C3Plus.PositionController_2_InsideWindow_IPart	Internal window I-term (A2)			C4_3	no	VP	-	-
2260.18	C3Plus.PositionController_2_IPart_Scaling	Quantifier I-term (A2)			C4_3	no	VP	-	-
2260.21	C3Plus.PositionController_2_Ki_IPart	I-term for the position controller (auxiliary axis)			I16	no	VP	-	-
2260.22	C3Plus.PositionController_2_Kp_PPart	P-term for the position controller (auxiliary axis)			I16	no	VP	-	-
2260.17	C3Plus.PositionController_2_NegLimit_IPart	Lower limit I-term (A2)			C4_3	no	VP	-	-
2260.15	C3Plus.PositionController_2_OutsideWindow_IPart	External window I-term (A2)			C4_3	no	VP	-	-
2260.16	C3Plus.PositionController_2_PosLimit_IPart	Upper limit I-term (A2)			C4_3	no	VP	-	-
2260.19	C3Plus.PositionController_2_PPart_Scaling	Quantifier P-term (A2)			C4_3	no	VP	-	-
2200.2	C3Plus.PositionController_ActualValue	Position actual value (sequentially)			C4_3	yes	-	-	-
2200.20	C3Plus.PositionController_DeadBand	Deadband of position controller			C4_3	no	VP	-	-
2200.1	C3Plus.PositionController_DemandValue	Position setpoint value (sequentially)			C4_3	yes	-	-	-
2200.36	C3Plus.PositionController_Disturbance_Offset	Disturbance compensation (A1)			C4_3	no	Immediately	-	-
2200.30	C3Plus.PositionController_InsideWindow_IPart	Internal window I-term (A1)			C4_3	no	VP	-	-
2200.34	C3Plus.PositionController_IPart_Scaling	Quantifier I-term (A1)			C4_3	no	VP	-	-
2200.37	C3Plus.PositionController_Ki_IPart	I-term for the position controller (main axis)			I16	no	VP	-	-
2200.38	C3Plus.PositionController_Kp_PPart	P-term for the position controller (main axis)			I16	no	VP	-	-
2200.33	C3Plus.PositionController_NegLimit_IPart	Lower limit I-term (A1)			C4_3	no	VP	-	-
2200.31	C3Plus.PositionController_OutsideWindow_IPart	External window I-term (A1)			C4_3	no	VP	-	-
2200.32	C3Plus.PositionController_PosLimit_IPart	Upper limit I-term (A1)			C4_3	no	VP	-	-
2200.35	C3Plus.PositionController_PPart_Scaling	Quantifier P-term (A1)			C4_3	no	VP	-	-
2200.24	C3Plus.PositionController_TrackingErrorFilter_us	Time constant following error filter of position controller			U16	no	VP	-	-
2402.1	C3Plus.PressureCompensation_Ch0_Type	Pressure compensation output 0			I16	no	VP	-	-
2412.1	C3Plus.PressureCompensation_Ch1_Type	Pressure compensation output 1			I16	no	VP	-	-
2422.1	C3Plus.PressureCompensation_Ch2_Type	Pressure compensation output 2			I16	no	VP	-	-
2432.1	C3Plus.PressureCompensation_Ch3_Type	Pressure compensation output 3			I16	no	VP	-	-
2250.24	C3Plus.PressureController_1_ActuatingSignal_Inversion	Inversion of the force controller control variable			I16	no	Immediately	-	-
2250.19	C3Plus.PressureController_1_Derivative_Part_KFd	Derivative action coefficient Kd (A1)			I32	no	VP	-	-
2250.21	C3Plus.PressureController_1_Disturbance_Offset	Disturbance compensation (A1)			C4_3	no	Immediately	-	-
2250.23	C3Plus.PressureController_1_Force_FeedForward_KFs	Force feedforward			U16	no	VP	-	-
2250.15	C3Plus.PressureController_1_InsideWindow_IPart	Internal window I-term (A1)			I32	no	VP	-	-
2250.14	C3Plus.PressureController_1_Integration_Part_KFi	Integration coefficient Ki (A1)			I32	no	VP	-	-
2250.18	C3Plus.PressureController_1_NegLimit_IPart	Negative limit I-term (A1)			I32	no	VP	-	-
2250.16	C3Plus.PressureController_1_OutsideWindow_IPart	External window I-term (A1)			I32	no	VP	-	-
2250.17	C3Plus.PressureController_1_PosLimit_IPart	Positive limit I-term (A1)			I32	no	VP	-	-
2250.13	C3Plus.PressureController_1_Proportional_Part_Kp	Proportional coefficient Kp (A1)			I32	no	VP	-	-
2250.20	C3Plus.PressureController_1_Speed_Feedback_KFv	Speed feedback (A1)			U16	no	VP	-	-
2251.24	C3Plus.PressureController_2_ActuatingSignal_Inversion	Inversion of the force controller control variable (A2)			I16	no	Immediately	-	-
2251.19	C3Plus.PressureController_2_Derivative_Part_KFd	Derivative action coefficient Kd (A2)			I32	no	VP	-	-
2251.21	C3Plus.PressureController_2_Disturbance_Offset	Disturbance compensation (A2)			C4_3	no	Immediately	-	-
2251.23	C3Plus.PressureController_2_Force_FeedForward_KFs	Force feedforward (A2)			U16	no	VP	-	-
2251.15	C3Plus.PressureController_2_InsideWindow_IPart	Internal window I-term (A2)			I32	no	VP	-	-
2251.14	C3Plus.PressureController_2_Integration_Part_KFi	Integration coefficient Ki (A2)			I32	no	VP	-	-
2251.18	C3Plus.PressureController_2_NegLimit_IPart	Negative limit I-term (A2)			I32	no	VP	-	-
2251.16	C3Plus.PressureController_2_OutsideWindow_IPart	External window I-term (A2)			I32	no	VP	-	-
2251.17	C3Plus.PressureController_2_PosLimit_IPart	Positive limit I-term (A2)			I32	no	VP	-	-
2251.13	C3Plus.PressureController_2_Proportional_Part_Kp	Proportional coefficient Kp (A2)			I32	no	VP	-	-
2251.20	C3Plus.PressureController_2_Speed_Feedback_KFv	Speed feedback (A2)			U16	no	VP	-	-
830.2	C3Plus.Profibus_Baudrate	Baud rate			U32	no	-	X	-
830.3	C3Plus.Profibus_NodeAddress	Station address	918		U16	no	-	X	-
830.1	C3Plus.Profibus_Protocol	PPO-type selection switch			U16	no	Immediately	X	-
830.6	C3Plus.Profibus_StandardSignalTable	List of Profidrive standard signals	923.x		U16	no	-	X	-
830.4	C3Plus.Profibus_TelegramSelect	Telegram selection switch	922		U16	no	Immediately	X	-
2000.2	C3Plus.ProfilGenerators_PG2Position	Position value of the setpoint encoder of the virtual axis		0x2061	C4_3	yes	-	-	-
2000.5	C3Plus.ProfilGenerators_PG2Speed	Speed of the virtual axis		0x2064	I32	yes	-	-	-
2000.1	C3Plus.ProfilGenerators_SG1Position	Position value of the setpoint encoder		0x2060	C4_3	yes	-	-	-
2000.4	C3Plus.ProfilGenerators_SG1Speed	Speed of the setpoint encoder		0x2063	I32	yes	-	-	-
152.1	C3Plus.RemoteAnalogInput_I0	PIO analog input 0		0x2082.1	I16	yes	Immediately	-	X
152.2	C3Plus.RemoteAnalogInput_I1	PIO analog input 1		0x2082.2	I16	yes	Immediately	-	X
152.3	C3Plus.RemoteAnalogInput_I2	PIO analog input 2		0x2082.3	I16	yes	Immediately	-	X
152.4	C3Plus.RemoteAnalogInput_I3	PIO analog input 3		0x2082.4	I16	yes	Immediately	-	X
153.1	C3Plus.RemoteAnalogOutput_O0	PIO analog output 0		0x2083.1	I16	yes	Immediately	-	X

No.	Object name	Object	PNU	CAN No.	Format	PD	Valid beginning	Bus object	
								I20	I21 / I22
153.2	C3Plus.RemoteAnalogOutput_O1	PIO analog output 1		0x2083.2	I16	yes	Immediately	-	X
153.3	C3Plus.RemoteAnalogOutput_O2	PIO analog output 2		0x2083.3	I16	yes	Immediately	-	X
153.4	C3Plus.RemoteAnalogOutput_O3	PIO analog output 3		0x2083.4	I16	yes	Immediately	-	X
150.1	C3Plus.RemoteDigInpnt_I0_15	Digital PIO inputs 0...15		0x2080.1	V2	yes	Immediately	-	X
150.2	C3Plus.RemoteDigInpnt_I16_31	Digital PIO inputs 16...31		0x2080.2	V2	yes	Immediately	-	X
150.3	C3Plus.RemoteDigInpnt_I32_47	Digital PIO inputs 32...47		0x2080.3	V2	yes	Immediately	-	X
150.4	C3Plus.RemoteDigInpnt_I48_63	Digital PIO inputs 48...63		0x2080.4	V2	yes	Immediately	-	X
151.1	C3Plus.RemoteDigOutput_O0_15	Digital PIO outputs 0...15		0x2081.1	V2	yes	Immediately	-	X
151.2	C3Plus.RemoteDigOutput_O16_31	Digital PIO outputs 16...31		0x2081.2	V2	yes	Immediately	-	X
151.3	C3Plus.RemoteDigOutput_O32_47	Digital PIO outputs 32...47		0x2081.3	V2	yes	Immediately	-	X
151.4	C3Plus.RemoteDigOutput_O48_63	Digital PIO outputs 48...63		0x2081.4	V2	yes	Immediately	-	X
2403.2	C3Plus.SignalFlowCharacteristic_Ch0_Curve_ID_A	Which characteristic (ID) is used			I16	no	VP	-	-
2403.1	C3Plus.SignalFlowCharacteristic_Ch0_Type	Characteristic output 0			I16	no	VP	-	-
2413.2	C3Plus.SignalFlowCharacteristic_Ch1_Curve_ID_A	Which characteristic (ID) is used			I16	no	VP	-	-
2413.1	C3Plus.SignalFlowCharacteristic_Ch1_Type	Characteristic output 1			I16	no	VP	-	-
2423.2	C3Plus.SignalFlowCharacteristic_Ch2_Curve_ID_A	Which characteristic (ID) is used			I16	no	VP	-	-
2423.1	C3Plus.SignalFlowCharacteristic_Ch2_Type	Characteristic output 2			I16	no	VP	-	-
2433.2	C3Plus.SignalFlowCharacteristic_Ch3_Curve_ID_A	Which characteristic (ID) is used			I16	no	VP	-	-
2433.1	C3Plus.SignalFlowCharacteristic_Ch3_Type	Characteristic output 3			I16	no	VP	-	-
1127.3	C3Plus.SPEED_speed	Target speed in speed control operating mode	7		C4_3	yes	Immediately	-	-
680.8	C3Plus.StatusPosition_Actual_Y4	Status position actual value in the bus format Y4	119	0x2022	Y4	yes	-	X	X
2109.1	C3Plus.TrackingfilterHEDA_TRFSpeed	Time constant tracking filter HEDA-process position			I16	no	VP	-	-
2107.1	C3Plus.TrackingfilterPhysicalSource_TRFSpeed	Time constant tracking filter physical source			U16	no	VP	-	-
2110.7	C3Plus.TrackingfilterSG1_AccelFilter_us	Filter time constant acceleration setpoint generator			U16	no	VP	-	-
2110.6	C3Plus.TrackingfilterSG1_FilterSpeed_us	Filter time constant velocity setpoint generator			U16	no	VP	-	-
2110.1	C3Plus.TrackingfilterSG1_TRFSpeed	Time constant tracking filter setpoint encoder		0x2096	I16	no	VP	-	-
210.9	C3Plus.ValidParameter_CamControlledSwitches	Set cam switching mechanism parameters to valid	338.9	0x2016.9	U16	no	Immediately	-	-
210.5	C3Plus.ValidParameter_FeedForward				U16	no	Immediately	-	-
210.2	C3Plus.ValidParameter_FiltersRSDP				U16	no	Immediately	-	-
180.2	C3Plus.ValveOutput0_Gain	Gain valve output 0			C4_3	no	Immediately	-	-
180.4	C3Plus.ValveOutput0_Offset	Offset valve output 0			I32	no	Immediately	-	-
180.5	C3Plus.ValveOutput0_Value	Value of valve output 0			C4_3	no	Immediately	-	-
181.2	C3Plus.ValveOutput1_Gain	Gain factor real			C4_3	no	Immediately	-	-
181.4	C3Plus.ValveOutput1_Offset	Offset valve output 1			I32	no	Immediately	-	-
181.5	C3Plus.ValveOutput1_Value	Value of valve output 1			C4_3	no	Immediately	-	-
182.2	C3Plus.ValveOutput2_Gain	Gain valve output 2			C4_3	no	Immediately	-	-
182.4	C3Plus.ValveOutput2_Offset	Offset valve output 2			I32	no	Immediately	-	-
182.5	C3Plus.ValveOutput2_Value	Value of valve output 2			C4_3	no	Immediately	-	-
183.2	C3Plus.ValveOutput3_Gain	Gain valve output 3			C4_3	no	Immediately	-	-
183.4	C3Plus.ValveOutput3_Offset	Offset valve output 3			I32	no	Immediately	-	-
183.5	C3Plus.ValveOutput3_Value	Value of valve output 3			C4_3	no	Immediately	-	-

## 7.3 Detailed object list

A detailed object list can be found in the corresponding online help.

# 8. Status values


## In this chapter you can read about:

D/A-Monitor .....	427
Status values .....	427

A list of the status values supports you in optimization and commissioning. Open the optimization function in the C3 ServoManager (double-click on optimization in the tree)  
 You will find the available status values in the lower right part of the window under selection (TAB) "Status values"  
 You can pull them into the oscilloscope (upper part of the left side) or into the status display (upper part of the right side) by the aid of the mouse (drag and drop). The status values are divided into 2 groups (user levels):  
**standard:** here you can find all important status values  
**advanced:** advanced status values, require a better knowledge

### Switching of the user level

The user level can be changed in the optimization window (left hand side lower part under selection (TAB) "optimization") with the following button.



## 8.1 D/A-Monitor

A part of the status values can be output via the D/A monitor channel 0 (X11/4) and channel 1 (X11/3). In the following status list under D/A monitor output: possible / not possible).

The reference for the output voltage can be entered individually in the reference unit of the status value.

### Example: Output Object 2210.2: (actual position unfiltered)

In order to get an output voltage of 10V at  $3000\text{min}^{-1}$ , please enter  $50\text{Umd/s}$  ( $=3000\text{min}^{-1}$ ) as "value of the signal at 10V".

### Hint

The unit of measurement of the D/A monitor values differs from the unit of measurement of the status values.

## 8.2 Status values

Additional information on the topic of "status values" can be found in the online help of the device.

## 9. Error:

All errors lead to error status.

Two error reactions are possible which are assigned to the individual error:

**Reaction 2:** Downramp with error ramp and then switching the valve outputs with high impedance (tristate) or, depending on the set **error reaction** (see page 80, see page 302) remaining in the controlled state. The method of "downramping" depends on the operating mode configured:

**Position AND force control configured**

Downramp with position control

**Pure force control configured**

Downramp with force control

**Reaction 5:** Immediate tristating of the valve outputs (without ramp).

With the aid of the "**SetErrorReaction** (see page 302)" IEC module, additional error reactions can be assigned to individual errors.

**Most pending errors can be acknowledged with Quit!**

**The following errors must be acknowledged with "Power on":**

**0x7381, 0x7382, 0x7391, 0x7392, 0x73A0**

The errors as well as the error history can be viewed in the C3 ServoManager under optimization (at the top right of the optimization window).



# 10. Order code

**In this chapter you can read about:**

Order code device: Compax3 Fluid.....	429
Accessories order code.....	429

## 10.1 Order code device: Compax3 Fluid

	C3	F	0	0	1	D2	F12			
Hydraulics controller		F								
Table Style			0	0	1					
Supply voltage 24VDC						D2				
Feedback Module							F12			
Interface:										
Control via Inputs/Outputs										I11
Control via Inputs/Outputs or COM interface										I12
Profibus DP V0/V1/V2 (12Mbaud)										I20
CANopen										I21
DeviceNet										I22
Ethernet Powerlink										I30
Ethercat										I31
Technology functions:										
Positioning (available as I12T11 & I20T11)										T11
Motion control programmable according to IEC61131-3										T30
Motion control programmable according to IEC61131-3 & electronic cam extension										T40
Options:										
no additional supplement										M00
Expansion 12 digital I/Os & HEDA (Motionbus)										M10
HEDA (Motionbus)										M11
Expansion, 12 digital I/Os										M12

## 10.2 Accessories order code

**Order Code connection set for Compax3 Fluid**

for C3F00xD2

ZBH 02/04

		/	
ZBH	0 2	/	0 4

**Order code for feedback cables**

X11, X13

with connector for Balluff BTL series with SSI- and Start/Stop interface

		/	
GBK	4 0	/	... ..

X13

Feedback cable EnDat2.1

GBK	4 1	/	... ..
-----	-----	---	--------

Encoder – Compax3

GBK	2 3	/	... .. <sup>1</sup>
-----	-----	---	---------------------

### Order code for interface cables and plugs

PC – Compax3 (RS232)		SSK	0	1	/ ... .. <sup>(1)</sup>
PC - Compax3MP (USB)		SSK	3	3	/ ... ..
on X11 (Ref/Analog) and X13 at C3F001D2	with flying leads	SSK	2	1	/ ... .. <sup>(1)</sup>
on X12 / X22 (I/Os digital)	with flying leads	SSK	2	2	/ ... .. <sup>(1)</sup>
on X11 (Ref /Analog)	for I/O terminal block	SSK	2	3	/ ... .. <sup>(1)</sup>
on X12 / X22 (I/Os digital)	for I/O terminal block	SSK	2	4	/ ... .. <sup>(1)</sup>
PC ⇔ POP (RS232)		SSK	2	5	/ ... .. <sup>(1)</sup>
Compax3 ⇔ POP (RS485) for several C3H on request		SSK	2	7	/ ./ ... <sup>(6)</sup>
Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC		SSK	2	8	/ ./ ... <sup>(5)</sup>
Compax3 I30 ⇔ Compax3 I30 or C3M-multi-axis communication					
Compax3 X11 ⇔ Compax3 X11 (encoder coupling of 2 axes)		SSK	2	9	/ ... .. <sup>(1)</sup>
Compax3 X10 ⇔ Modem		SSK	3	1	/ ...
Compax3H adapter cable ⇔ SSK01 (length 15cm, delivered with the device)		SSK	3	2	/ 2 0
Compax3H X10 RS232 connection control ⇔ Programming interface (delivered with the device)		VBK	1	7	/ 0 1
Bus terminal connector (for the 1st and last Compax3 in the HEDA Bus/or multi-axis system).		BUS	0	7	/ 0 1
Profibus cable <sup>(2)</sup>	non prefabricated	SSL	0	1	/ ... .. <sup>(1)</sup>
Profibus plug		BUS	0	8	/ 0 1
CAN-Bus cable <sup>(2)</sup>	non prefabricated	SSL	0	2	/ ... .. <sup>(1)</sup>
CANbus connector		BUS	1	0	/ 0 1

<sup>(x)</sup> Note on the cable (see page 431)

### Order Code operating module

Operating module (for Compax3S and Compax3F)		BDM	0	1	/ 0 1

### Order Code terminal block

for I/Os without luminous indicator	for X11, X12, X22	EAM	0	6	/ 0 1
for I/Os with luminous indicator	for X12, X22	EAM	0	6	/ 0 2

### Order Code decentralized input terminals

PIO 2DI 24VDC 3.0ms	2-channel digital input terminal	PIO	4	0	0
PIO 4DI 24VDC 3.0ms	4-channel digital input terminal	PIO	4	0	2
PIO 8DI 24VDC 3.0ms	8-channel digital input terminal	PIO	4	3	0
PIO 2AI DC ± 10V differential input	2 channel analog input terminal (± 10V differential input)	PIO	4	5	6
PIO 4AI 0-10VDC S.E.	4 channel analog input terminal (0-10V signal voltage)	PIO	4	6	8
PIO 2AI 0 -20mA differential input	2 channel analog input terminal (0 -20mA differential input)	PIO	4	8	0

### Order Code decentralized output terminals

PIO 2DO 24VDC 0.5A	2 channel digital output terminal (output voltage 0.5A)	PIO	5	0	1
PIO 4DO 24VDC 0.5A	4 channel digital output terminal (output voltage 0.5A)	PIO	5	0	4
PIO 8DO 24VDC 0.5A	8 channel digital output terminal (output voltage 0.5A)	PIO	5	3	0
PIO 2AO 0-10VDC	2 channel analog output terminal (0-10V signal voltage)	PIO	5	5	0
PIO 2AO 0 -20mA	2 channel analog output terminal (0-20mA signal voltage)	PIO	5	5	2
PIO 2AO DC ± 10V	2 channel analog output terminal (± 10V signal voltage)	PIO	5	5	6

### Order Code CANopen Fieldbus Coupler

CANopen Standard	max. vectorial sum current for bus terminals 1650mA at 5V	PIO	3	3	7
CANopen ECO	max. vectorial sum current for bus terminals 650mA at 5V	PIO	3	4	7

<sup>(1)</sup> Length code 1

Length [m]	1,0	2,5	5,0	7,5	10,0	12,5	15,0	20,0	25,0	30,0	35,0	40,0	45,0	50,0
Order code	01	02	03	04	05	06	07	08	09	10	11	12	13	14

**Example:**

SSK01/09: length 25m

<sup>(2)</sup> Colours according to DESINA<sup>(3)</sup> with motor plug<sup>(4)</sup> with cable eye for motor terminal box<sup>(5)</sup> Length code 2 for SSK28

Length [m]	0,17	0,25	0,5	1,0	3,0	5,0	10,0
Order code	23	20	21	01	22	03	05

<sup>(6)</sup> Order code: **SSK27/nn/..**

Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)

Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)

Number n (the last two digits)

**Examples:**

SSK27/05/.. for connecting from Pop to 5 Compax3.

SSK27/01/.. for connection from Pop to one Compax3

MOK55 and MOK54 can also be used for linear motors LXR406, LXR412 and BLMA.

<sup>(x)</sup> **Note on the cable** (see page 431)

# 11. Compax3 Accessories

## In this chapter you can read about:

ZBH plug set.....	432
Cable for path measurement systems.....	432
Operator control module BDM.....	435
EAM06: Terminal block for inputs and outputs.....	436
Interface Cables .....	439
Options M1x .....	447
Profibus plug BUS08/01 .....	451
CAN - plug BUS10/01 .....	452
PIO: Inputs/Outputs.....	453

## 11.1 ZBH plug set

The plug set which is available as accessory comprises:

- ◆ a shield connecting terminal for the large area shield connection of the sensor and valve cable (X1, X2), as well as
- ◆ the mating plug connectors for the Compax3 plug connectors X1, X2, X3, and
- ◆ fixing material for the mounting of a supporting rail


### Order Code connection set for Compax3 Fluid

for C3F00xD2

ZBH 02/04

			/		
ZBH	0	2	/	0	4

### ZBH02/04: for Compax3 F00x D2




## 11.2 Cable for path measurement systems

### In this chapter you can read about:

Encoder cable.....	433
Feedback cable (Balluff).....	434
Feedback cable EnDat2.1 .....	435

### 11.2.1. Encoder cable


GBK23/... Connection Encoder - Compax3



You will find the length code in the **accessories order code** (see page 429).

## 11.2.2. Feedback cable (Balluff)


### GBK40/...: Connection Compax3 - Start/Stop or SSI feedback



You will find the length code in the **accessories order code** (see page 429).

### 11.2.3. Feedback cable EnDat2.1

#### GBK41/...: Connection Compax3 - EnDat2.1 feedback



You will find the length code in the **accessories order code** (see page 429).

## 11.3 Operator control module BDM

### Order Code operating module

Operating module (for Compax3S and Compax3F)

		/		
BDM	0 1	/	0 1	

### Flexible service and maintenance



#### Functions:

- ◆ Mobile or stationary handling: can remain on the unit for display and diagnostic purposes, or can be plugged into any unit.
- ◆ Can be plugged in while in operation
- ◆ Power supply via Compax3 servo control
- ◆ Display with 2 times 16 places.
- ◆ Menu-driven operation using 4 keys.
- ◆ Displays and changing of values.
- ◆ Display of Compax3 messages.
- ◆ Duplication of device properties (no valve characteristics) and IEC61131-3 program to another Compax3 with identical hardware.
- ◆ Additional information can be found in the BDM manual. This can be found on the Compax3 CD or on our Homepage: **BDM-manual** ([http://apps.parker.com/divapps/EME/EME/Literature\\_List/dokumentationen/BDM.pdf](http://apps.parker.com/divapps/EME/EME/Literature_List/dokumentationen/BDM.pdf)).





## 11.4 EAM06: Terminal block for inputs and outputs

### Order Code terminal block

for I/Os without luminous indicator	for X11, X12, X22	EAM	0	6	/	0	1
for I/Os with luminous indicator	for X12, X22	EAM	0	6	/	0	2

The terminal block EAM06/.. can be used to route the Compax3 plug connector X11 or X12 for further wiring to a terminal strip and to a Sub-D plug connector.

Via a supporting rail (Design:  or ) the terminal block can be installed on a mounting rail in the control cabinet.


EAM06/ is available in 2 variants:

- ◆ EAM06/01: Terminal block for X11, X12, X22 without luminous indicator
- ◆ EAM06/02: Terminal block for X12, X22 with luminous indicator

Corresponding connecting cables EAM06 - Compax3 are available:


- ◆ from X11 - EAM06/01: SSK23/..
- ◆ from X12, X22 - EAM06/xx: SSK24/..

#### **EAM06/01: Terminal block without luminous indicator for X11, X12 or X22**




Width: 67.5mm

**EAM6/02: Terminal block with luminous indicator for X12, X22**




Width: 67.5mm

**Cable plan SSK23/..: X11 to EAM 06/01**



**Cable plan SSK24/...: X12 to EAM 06/xx**



## 11.5 Interface Cables

**In this chapter you can read about:**

RS232 cable .....441  
 RS485 cable to Pop.....442  
 I/O interface X12 / X22 .....443  
 Ref X11.....444  
 Encoder coupling of 2 Compax3 axes.....445  
 Modem cable SSK31.....446


**Order code for interface cables and plugs**

PC – Compax3 (RS232)	SSK	0	1	/	...	... <sup>(1)</sup>
PC - Compax3MP (USB)	SSK	3	3	/	...	...
on X11 (Ref/Analog) and X13 at C3F001D2	SSK	2	1	/	...	... <sup>(1)</sup>
on X12 / X22 (I/Os digital)	SSK	2	2	/	...	... <sup>(1)</sup>
on X11 (Ref /Analog)	SSK	2	3	/	...	... <sup>(1)</sup>
on X12 / X22 (I/Os digital)	SSK	2	4	/	...	... <sup>(1)</sup>
PC ⇔ POP (RS232)	SSK	2	5	/	...	... <sup>(1)</sup>
Compax3 ⇔ POP (RS485) for several C3H on request	SSK	2	7	/	./	... <sup>(6)</sup>
Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC	SSK	2	8	/	./	... <sup>(5)</sup>
Compax3 I30 ⇔ Compax3 I30 or C3M-multi-axis communication						
Compax3 X11 ⇔ Compax3 X11 (encoder coupling of 2 axes)	SSK	2	9	/	...	... <sup>(1)</sup>
Compax3 X10 ⇔ Modem	SSK	3	1	/	...	
Compax3H adapter cable ⇔ SSK01 (length 15cm, delivered with the device)	SSK	3	2	/	2	0
Compax3H X10 RS232 connection control ⇔ Programming interface (delivered with the device)	VBK	1	7	/	0	1
Bus terminal connector (for the 1st and last Compax3 in the HEDA Bus/or multi-axis system).	BUS	0	7	/	0	1
Profibus cable <sup>(2)</sup>	SSL	0	1	/	...	... <sup>(1)</sup>
Profibus plug	BUS	0	8	/	0	1
CAN-Bus cable <sup>(2)</sup>	SSL	0	2	/	...	... <sup>(1)</sup>
CANbus connector	BUS	1	0	/	0	1

<sup>(x)</sup> **Note on the cable** (see page 431)

**11.5.1. RS232 cable**


**SSK1/..**



You will find the length code in the **accessories order code** (see page 429).

## 11.5.2. RS485 cable to Pop

### SSK27: Connection Pop - Compax3 - Compax3 - ...



R21 = 220 Ohm

**Order code: SSK27/nn/..**


Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)  
 Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)  
 Number n (the last two digits)

**Examples:**

SSK27/05/.. for connecting from Pop to 5 Compax3.  
 SSK27/01/.. for connection from Pop to one Compax3

11.5.3. I/O interface X12 / X22


SSK22/...: Cable for X12 / X22 with flying leads



You will find the length code in the accessories order code (see page 429).

### 11.5.4. Ref X11

#### SSK21/...: Cable for X11 with flying leads




You will find the length code in the **accessories order code** (see page 429).




### 11.5.5. Encoder coupling of 2 Compax3 axes

#### SSK29/...: Cable from Compax3 X11 to Compax3 X11





You will find the length code in the **accessories order code** (see page 429).

#### Layout of SSK28:



# 11.5.6. Modem cable SSK31

## SSK31/..



You will find the length code in the **accessories order code** (see page 429).

## 11.6 Options M1x

### In this chapter you can read about:

Input/output option M12.....	447
HEDA (motion bus) - Option M11.....	448
Option M10 = HEDA (M11) & I/Os (M12).....	450

### 11.6.1. Input/output option M12

An optional input/output extension is available for Compax3. This option is named M12 and offers 12 digital 24V inputs/outputs (Ports) on X22.

The use of the option as inputs or outputs is programmable in groups of 4 (via the object 133.4).

The outputs are written via the object 133.3 "Output word for the I/O option"; this applies only for the ports defined as output.

The inputs are read via the object 121.2 "Input word for the I/O option"; all ports are being read, also the outputs.

#### 11.6.1.1 Assignment of the X22 connector



PIN X22/	Input/output	I/O /X22 High density/Sub D	Access via IEC module:
1	n.c.	Reserved	
2	O0/I0	Output 0 / Input 0 - adjustable	C3_IOAddition_0 (see page 304)
3	O1/I1	Output 1 / Input 1 - adjustable	
4	O2/I2	Output 2 / Input 2 - adjustable	
5	O3/I3	Output 3 / Input 3 - adjustable	
6	O4/I4	Output 4 / Input 4 - adjustable	C3_IOAddition_1 (see page 304)
7	O5/I5	Output 5 / Input 5 - adjustable	
8	O6/I6	Output 6 / Input 6 - adjustable	
9	O7/I7	Output 7 / Input 7 - adjustable	
10	O8/I8	Output 8 / Input 8 - adjustable	C3_IOAddition_2 (see page 305) (not 24VDC)
11	E	24 VDC power supply	
12	O9/I9	Output 9 / Input 9 - adjustable	
13	O10/I10	Output 10 / Input 10 - adjustable	
14	O11/I11	Output 11 / Input 11 - adjustable	
15	E	Gnd 24 V	

The assignment can be adjusted.


All inputs and outputs have 24V level.

Maximum load on an output: 100mA

Maximum capacitive load: 50nF (max. 4 Compax3 inputs)


**Caution! The 24VDC power supply (X22/11) must be supplied from an external source and must be protected by a 1.2A delayed fuse!**

**Input wiring of digital inputs**




The circuit example is valid for all digital inputs!  
 F1: quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

**Output wiring of digital outputs**



The circuit example is valid for all digital outputs!  
 The outputs are short circuit proof; a short circuit generates an error.  
 F1: quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

**11.6.2. HEDA (motion bus) - Option M11**



	RJ45 (X20)	RJ45 (X21)
<b>PIN</b>	<b>HEDA in</b>	<b>HEDA out</b>
1	Rx	Tx
2	Rx/	Tx/
3	Lx	Lx
4	-	Reserved
5	-	Reserved
6	Lx/	Lx/
7	-	Reserved
8	-	Reserved

**Function of the HEDA LEDs**

**Green LED (left)**

HEDA module energized

**Red LED (right)**

Error in the receive area

Possible causes:

- ◆ at the Master
  - ◆ no slave sending back
  - ◆ Wrong cabling
  - ◆ Terminal plug is missing
  - ◆ several masters are sending in the same slot
- ◆ at the slave
  - ◆ several masters in the system
  - ◆ no master active
  - ◆ Terminal plug is missing
  - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)


**HEDA-wiring:**

HEDA-Master



Layout of SSK28 (see page 430, see page 445)

**Design of the HEDA bus terminator BUS 07/01:**



Jumpers: 1-7, 2-8, 3-4, 5-6

## Function of the HEDA LEDs

### Green LED (left)

HEDA module energized

### Red LED (right)

Error in the receive area

Possible causes:

- ◆ at the Master
  - ◆ no slave sending back
  - ◆ Wrong cabling
  - ◆ Terminal plug is missing
  - ◆ several masters are sending in the same slot
- ◆ at the slave
  - ◆ several masters in the system
  - ◆ no master active
  - ◆ Terminal plug is missing
  - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)


## 11.6.3. Option M10 = HEDA (M11) & I/Os (M12)

The M10 option includes the M12 input/output option and the HEDA M11 option.

## 11.7 Profibus plug BUS08/01

We offer a Profibus plug and special cable as meterware for Profibus wiring:

- ◆ Profibus cable: SSL01/.. not prefabricated (color according to DESINA).
- ◆ Profibus plug: BUS08/01 with 2 cable inputs (for one incoming A1, B1 and one continuing Profibus cable- A2, B2 -) and screw terminals as well as a switch for activating the terminal resistor.  
The terminal resistor must be activated on the first and on the last station (= switch setting ON).



# 11.8 CAN - plug BUS10/01

We offer a CAN plug and special cable in any length to order for the CAN-bus wiring:


- ◆ CAN cable: SSL02/.. not prefabricated (colour according to DESINA).
- ◆ CAN plug: BUS10/01 with 2 cable inputs and screw terminals as well as a switch for activating the terminal resistor.  
The terminal resistor must be activated on the first and on the last station (=switch setting ON).

**Note for integrated C3 powerPLmC** (Compax3 interface designation "C1x")


- ◆ The CAN bus of the C3 powerPLmC does already contain a terminal resistor.
- ◆ Therefore it applies for the **C3 powerPLmC**:  
Put switch to OFF  
wire C3 powerPLmC always at the end of the CAN bus!



### CAN wiring



### Schaltbild Circuit Diagram





## 11.9 PIO: Inputs/Outputs

Additional external digital and analog inputs and outputs can be integrated via CANopen.

For this purpose we offer the Parker I/O system (PIO).

PIO offers the convenience of exceptionally simple installation. The individual modules can be installed and removed without any tools.

### Available modules:

#### Order Code decentralized input terminals

PIO 2DI 24VDC 3.0ms	2-channel digital input terminal	PIO	4	0	0	
PIO 4DI 24VDC 3.0ms	4-channel digital input terminal	PIO	4	0	2	
PIO 8DI 24VDC 3.0ms	8-channel digital input terminal	PIO	4	3	0	
PIO 2AI DC $\pm$ 10V differential input	2 channel analog input terminal ( $\pm$ 10V differential input)	PIO	4	5	6	
PIO 4AI 0-10VDC S.E.	4 channel analog input terminal (0-10V signal voltage)	PIO	4	6	8	
PIO 2AI 0 -20mA differential input	2 channel analog input terminal (0 -20mA differential input)	PIO	4	8	0	

#### Order Code decentralized output terminals

PIO 2DO 24VDC 0.5A	2 channel digital output terminal (output voltage 0.5A)	PIO	5	0	1	
PIO 4DO 24VDC 0.5A	4 channel digital output terminal (output voltage 0.5A)	PIO	5	0	4	
PIO 8DO 24VDC 0.5A	8 channel digital output terminal (output voltage 0.5A)	PIO	5	3	0	
PIO 2AO 0-10VDC	2 channel analog output terminal (0-10V signal voltage)	PIO	5	5	0	
PIO 2AO 0 -20mA	2 channel analog output terminal (0-20mA signal voltage)	PIO	5	5	2	
PIO 2AO DC $\pm$ 10V	2 channel analog output terminal ( $\pm$ 10V signal voltage)	PIO	5	5	6	

#### Order Code CANopen Fieldbus Coupler

CANopen Standard	max. vectorial sum current for bus terminals 1650mA at 5V	PIO	3	3	7	
CANopen ECO	max. vectorial sum current for bus terminals 650mA at 5V	PIO	3	4	7	

For additional information please refer to our **catalog**

[http://www.parker.com/euro\\_emd/EME/Literature\\_List/dokumentationen/PIO\\_catalogue%20eng.pdf](http://www.parker.com/euro_emd/EME/Literature_List/dokumentationen/PIO_catalogue%20eng.pdf).

# 12. Specifications

## Technical data

Motion control with motion profiles, suitable for position and force/pressure control for up to 2 axes.

### Command value generator

- ◆ Jerk-limited ramps.
- ◆ Travel data in increments, mm, inch.
- ◆ Specification of speed, acceleration, delay and jerk factor.
- ◆ Force/pressure data in N, bar, psi.

### Monitoring functions

- ◆ Voltage range.
- ◆ Following error monitoring.
- ◆ Hard and Software limit switch

### Technology functions of servo controllers

- ◆ IEC61131-3 programs in the servo controller (T30)
- ◆ Cam function in the servo controller (T40)

## Voltage supply 24VDC

<b>Controller type</b>	<b>Compax3 F001 D2</b>
<b>Voltage range</b>	21 - 27VDC
<b>Mains module</b>	with switch-on current limitation, due to capacitive load
<b>Fuse</b>	MTP miniature circuit breaker or "delayed action fuse", due to capacitive load
<b>Current drain of the device</b>	0.8A (max. 1.5A)
<b>Total current drain</b>	0.8A + total load of the digital outputs
<b>Ripple</b>	<1V <sub>ss</sub>
<b>Requirement according to safe extra low voltage (SELV)</b>	yes

## Size / weight

<b>Controller type</b>	<b>Compax3 F001 D2</b>
<b>Dimensions: HxWxD [mm]</b>	199x80x130
<b>Weight [kg]</b>	2.0
<b>Housing / protection class</b>	Enclosed metal housing, insulation according to EN60529 / IP 20

### Inputs and outputs

<b>Controller type</b>	<b>Compax3 F001 D2</b>
<b>8 control inputs</b>	24VDC / 10kOhm
<b>4 control outputs</b>	active HIGH/short-circuit protected, 24 V / 100 mA
<b>4 analog current inputs</b>	14Bit
<b>2 analog voltage inputs</b>	14Bit
<b>4 analog outputs</b>	16bits, current or voltage
<b>2 analog monitor outputs</b>	8bits

### COM ports

<b>RS232</b>	<ul style="list-style-type: none"> <li>◆ 115200 baud</li> <li>◆ Word length: 8 bits, 1 start bit, 1 stop bit</li> <li>◆ Hardware handshake XON, XOFF</li> </ul>
<b>RS485 (2 or 4-wire)</b>	<ul style="list-style-type: none"> <li>◆ 9600, 19200, 38400, 57600 or 115200 baud</li> <li>◆ Word length 7/8 bit, 1 start bit, 1 stop bit</li> <li>◆ Parity (can be switched off) even/odd</li> <li>◆ 2 or 4-wire</li> </ul>

### Supported valves and feedback systems

<b>Valves</b>	<ul style="list-style-type: none"> <li>◆ D1*FH series</li> </ul>
<b>Absolute encoder</b>	<ul style="list-style-type: none"> <li>◆ Analog 0..20mA, 4..20mA, ±10V</li> <li>◆ Start/Stop - interface</li> <li>◆ SSI interface</li> <li>◆ EnDat 2.1-interface</li> <li>◆ 1VSS (max. 400kHz) Interface, 13.5bits / graduation of the scale</li> <li>◆ RS422 encoder (max. 5MHz), internal quadrature of the resolution</li> </ul>

### EMC limit values

<b>EMC interference emission</b>	Limit values according to EN 61000-6-4: 2001 for the industrial environment
<b>EMC disturbance immunity</b>	Limit values according to EN 61000-6-2: 2001 for the industrial environment

**Environmental requirements Compax3F**

<b>General ambient conditions</b>	According to <b>EN 60 721-3-1 to 3-3</b> Climate (temperature/humidity/barometric pressure): Class 3K3	
<b>Permissible ambient temperature:</b>		
Operation Storage Transport	0 to +45 C -25 to +70 C -25 to +70 C	Class 3K3 Class 2K3 Class 2K3
<b>Tolerated humidity:</b>	No condensation	
Operation Storage Transport	<= 85% class 3K3 <= 95% class 2K3 <= 95% class 2K3	(Relative humidity)
<b>Elevation of operating site</b>	<=1000m above sea level for 100% load ratings <=2000m above sea level for 1% / 100m power reduction Please inquire for greater elevations	
<b>Mechanic resonances:</b>	EN 60068-2-6 (sinusoidal excitation)	
<b>Sealing</b>	IP20 protection class according to EN 60 529	

**Insulation requirements**

<b>Degree of contamination</b>	Level of contamination 2 according to EN 50 178
--------------------------------	---

**UL certification**

<b>conform to UL:</b>	◆USL according to UL508 (Listed) ◆CNL according to C22.2 No. 142-M1987. (Listed)
<b>Certified</b>	◆E-File_No.: E198563

The UL certification is documented by a "UL" logo on the device (type specification plate).



**IEC6113-3 functions**

<b>General</b>	<ul style="list-style-type: none"> <li>◆ Programming based on IEC61131-3</li> <li>◆ Up to 6000 instructions</li> <li>◆ 650 16 bit variables</li> <li>◆ 200 32 bit variables</li> <li>◆ Recipe table with 288 variables</li> <li>◆ 3x16-bit retain-variable</li> <li>◆ 3x32-bit retain-variable</li> </ul>
<b>PLCOpen function modules</b>	<ul style="list-style-type: none"> <li>◆ Positioning: absolute, relative, additive, endless</li> <li>◆ Electronic Gearbox (Gearing)</li> <li>◆ Machine Zero</li> <li>◆ Stop, activating the drive, quit</li> <li>◆ Position, device status, reading axis error</li> </ul>
<b>IEC61131-3 standard modules</b>	<ul style="list-style-type: none"> <li>◆ Up to 8 timers (TON, TOF, TP)</li> <li>◆ Triggers (R_TRIG, F_TRIG)</li> <li>◆ Flip-flops (RS, SR)</li> <li>◆ Counters (CTU, CTD, CTUD)</li> </ul>
<b>Device-specific function modules</b>	<ul style="list-style-type: none"> <li>◆ generates an input process image</li> <li>◆ generates an output process image</li> <li>◆ access to recipe table</li> </ul>
<b>Inputs/Outputs</b>	<ul style="list-style-type: none"> <li>◆ 8 digital inputs (24V level)</li> <li>◆ 4 digital outputs (24-V level)</li> <li>◆ Optional addition of 12 inputs/outputs</li> </ul>

**T40 Functions: Cam**

<b>General</b>	<ul style="list-style-type: none"> <li>◆ Cam control function</li> <li>◆ Programmable based on IEC61131-3</li> <li>◆ Position of selected master signal source via: <ul style="list-style-type: none"> <li>◆ Encoder, Step / direction or +/-10V analog</li> <li>◆ HEDA</li> <li>◆ Virtual Master</li> </ul> </li> </ul>
<b>Cam memory</b>	<ul style="list-style-type: none"> <li>◆ 10.000 interpolation points (master / slave in 24 bit format) saved failure save.</li> <li>◆ Distance of interpolation points can be adapted to curve (non equidistant interpolation points)</li> <li>◆ Linear interpolation between points</li> </ul>
<b>Linking curve segments</b>	<ul style="list-style-type: none"> <li>◆ Up to 20 cam segments can be produced.</li> <li>◆ Virtually random cam links (forwards and backwards)</li> <li>◆ Freely programmable, event-triggered curve branching.</li> <li>◆ Scalable cam segments and complete cam profiles</li> </ul>
<b>Coupling and decoupling functions</b>	<ul style="list-style-type: none"> <li>◆ With the aid of a quadratic function.</li> <li>◆ By means of a change-over function</li> <li>◆ Without overspeeding by coupling over several master cycles.</li> <li>◆ Virtually free set-up of the coupling and decoupling movement</li> <li>◆ master-guided coupling movement.</li> <li>◆ Random standstill position</li> </ul>
<b>Mark synchronization</b>	<ul style="list-style-type: none"> <li>◆ Master or slave oriented (simultaneous, cam-independent).</li> <li>◆ highly precise mark recognition (accuracy &lt; 1 µs)</li> </ul>
<b>Cam generation with renowned Nolte tool.</b>	<ul style="list-style-type: none"> <li>◆ Standard or extended range of functions</li> <li>◆ evaluation of the motion profiles.</li> </ul>

**COM ports**

<b>RS232</b>	<ul style="list-style-type: none"> <li>◆ 115200 baud</li> <li>◆ Word length: 8 bits, 1 start bit, 1 stop bit</li> <li>◆ Hardware handshake XON, XOFF</li> </ul>
<b>RS485 (2 or 4-wire)</b>	<ul style="list-style-type: none"> <li>◆ 9600, 19200, 38400, 57600 or 115200 baud</li> <li>◆ Word length 7/8 bit, 1 start bit, 1 stop bit</li> <li>◆ Parity (can be switched off) even/odd</li> <li>◆ 2 or 4-wire</li> </ul>
<b>USB (Compax3M)</b>	<ul style="list-style-type: none"> <li>◆ USB 2.0 Full Speed compatible</li> </ul>

**I20 Function****Profibus ratings**

<b>Profile</b>	◆ PROFIdrive Profile drive system V3
<b>DP Versions</b>	◆ DPV0/DPV1
<b>Baud rate</b>	◆ up to 12MHz
<b>Profibus ID</b>	◆ C320
<b>Device master file</b>	◆ PAR_C320.GSD (can be found on the Compax3 - CD)
<b>Communication Simatic &lt;-&gt; Compax3</b>	◆ Simatic S7-300/400 - modules for Compax3 I20 and a corresponding help file can be found on the Compax3 CD in the folder: ..\Profibus\S7-moduls\

**I21 Function****CANopen ratings**

<b>Baud rate [kBit/s]</b>	◆ 20, 50, 100, 125, 250, 500, 800, 1000
<b>EDS file</b>	◆ C3.EDS
<b>Service data object</b>	◆ SDO1
<b>Process data objects</b>	◆ PDO1, ... PDO4

**I22 Function****DeviceNet characteristic data**

<b>DeviceNet</b>	◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
<b>Implemented object classes</b>	◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
<b>Baud rate [kBit/s]</b>	◆ 125, 250, 500
<b>permissible cable length</b>	◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
<b>Max. number of nodes</b>	◆ 63 Slave
<b>Insulation</b>	◆ Isolated Device Physical Layer
<b>EDS file</b>	◆ C3_DeviceNet.EDS
<b>Conformance (file in the Internet)</b>	◆ <b>Statement of Conformance</b> <a href="http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf">http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf</a>
<b>Further information:</b>	◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory

**Ethernet Powerlink / EtherCAT characteristics**

<b>Baud rate</b>	◆ 100Mbits (FastEthernet)
<b>Bus file</b> Ethernet Powerlink: EtherCAT:	◆ ◆ C3_EPL_cn.EDS ◆ C3_EtherCAT_xx.XML
<b>Service data object</b>	◆ SDO
<b>Cycle time</b>	◆ 1ms
<b>Synchronicity accuracy</b>	◆ maximum jitter: +/-25µs



# 13. Index

## +

+/-10V Master speed • 85

## 1

10 Steps for cam generation • 260

172.11 • 118

172.3 • 119

172.4 • 118

173.11 • 119

173.3 • 119

173.4 • 119

174.11 • 120

174.3 • 120

174.4 • 120

175.11 • 120

175.3 • 121

175.4 • 121

176.11 • 121

176.3 • 122

176.4 • 121

177.11 • 122

177.3 • 122

177.4 • 122

## 2

2010.23 • 107

2010.24 • 107

2050.10 • 108

2050.9 • 108

2100.10 • 116

2100.11 • 116

2100.13 • 111

2100.14 • 112

2101.13 • 115

2101.14 • 115

2101.7 • 117

2101.8 • 117

2200.11 • 109

2200.24 • 109

2200.30 • 110

2200.31 • 110

2200.32 • 111

2200.33 • 111

2200.37 • 110

2200.38 • 110

2210.8 • 112

2250.13 • 124

2250.14 • 124

2250.15 • 124

2250.16 • 124

2250.17 • 125

2250.18 • 125

2250.19 • 125

2250.20 • 126

2250.22 • 126

2250.23 • 126

2250.24 • 126

2250.8 • 125

2251.13 • 128

2251.14 • 128

2251.15 • 128

2251.16 • 128

2251.17 • 129

2251.18 • 129

2251.19 • 129

2251.20 • 130

2251.22 • 130

2251.23 • 130

2251.24 • 130

2251.8 • 129

2260.14 • 114

2260.15 • 114

2260.16 • 114

2260.17 • 115

2260.21 • 113

2260.22 • 113

2260.8 • 113

2270.8 • 115

2400.3 • 132

2400.4 • 132

2400.6 • 133

2400.7 • 133

2401.4 • 133

2401.5 • 134

2401.6 • 135

2401.7 • 134

2401.8 • 134

2402.1 • 135

2403.1 • 135

2405.1 • 136

2405.2 • 136

2405.3 • 136

2405.4 • 137

## A

Absolute master reference with 180° offset • 231

Absolute master reference without offset • 230

Absolute positioning (MC\_MoveAbsolute) • 179

Absolute slave reference • 234

Acceleration feedback • 144

Acceleration feedforward (advanced) • 145

Access to the Compax3 object directory • 158

Accessories order code • 428

Acknowledging errors (MC\_Reset) • 299

Activation of pressure / force control • 145

Activation of the drive (MC\_Power) • 165

Acyclic parameter channel • 356, 381

Adapt control parameters • 145

Additive positioning (MC\_MoveAdditive) • 185

Adjust force / pressure  
 (C3\_PressureForceAbsolute) • 202  
 Adjusting the bus address • 32, 33, 35  
 Adjusting the machine zero proximity switch • 69  
 Alignment of the slave axis • 245  
 Analog / Encoder (plug X11) • 28  
 Analog Input • 118  
 Analog Input (plug X1) • 25  
 Analog Output (plug X2) • 26  
 Analogue Inputs/Outputs • 426  
 Application note  
 Drift • 285  
 ASCII - record • 345  
 Assignment of the process data channel • 354  
 Assignment of the X22 connector • 446

## B

Back stop • 212  
 Basic procedure • 212  
 Basics • 210  
 Baud rate • 367  
 Behavior depending on the travel direction • 292  
 Behavior of the switch-on/switch-off anticipation • 292  
 Binary record • 346  
 Bit sequence V2 • 364  
 Braking position (MB) • 212  
 Bus format Y2 and Y4 • 363  
 Byte string OS • 364

## C

C3 • 303, 304  
 C3 Master PIO • 367  
 C3 settings for RS485 four wire operation • 343  
 C3 settings for RS485 two wire operation • 342  
 C3.AnalogInput0\_Offset • 118  
 C3.AnalogInput1\_Offset • 119  
 C3.AnalogInput2\_Offset • 120  
 C3.AnalogInput3\_Offset • 121  
 C3.AnalogInput4\_Offset • 121  
 C3.AnalogInput5\_Offset • 122  
 C3.ControllerTuning\_2\_AccelFeedback\_Ka • 115  
 C3.ControllerTuning\_2\_FilterAccel2 • 117  
 C3.ControllerTuning\_2\_FilterSpeed2 • 117  
 C3.ControllerTuning\_2\_SpeedFeedback\_Kv • 115  
 C3.ControllerTuning\_AccelFeedback\_Ka • 112  
 C3.ControllerTuning\_FilterAccel2 • 116  
 C3.ControllerTuning\_FilterSpeed2 • 116  
 C3.ControllerTuning\_SpeedFeedback\_Kv • 111  
 C3.DirectionDependentGain\_Ch0\_Factor\_negative\_Pressure • 134  
 C3.DirectionDependentGain\_Ch0\_Factor\_positive\_Pressure • 134  
 C3.FeedForward\_2\_Accel\_FFW • 108  
 C3.FeedForward\_2\_Speed\_FFW • 108  
 C3.FeedForward\_Speed\_FFW • 107

C3.PositionController\_2\_TrackingErrorFilter\_us • 113  
 C3.PressureController\_1\_ActuatingSignalFilter • 126  
 C3.PressureController\_1\_TimeDelay\_DT1\_T1 • 125  
 C3.PressureController\_2\_ActuatingSignalFilter • 130  
 C3.PressureController\_2\_TimeDelay\_DT1\_T1 • 129  
 C3.SpeedController\_ActuatingSignal\_filt • 112  
 C3.SpeedController2\_ActuatingSignal\_filt • 115  
 C3\_CamIn • 248  
 C3\_CamOut • 256  
 C3\_CamTableSelect • 239  
 C3\_CANopen\_AddNode • 371  
 C3\_CANopen\_ConfigNode • 372  
 C3\_CANopen\_GuardingState • 370  
 C3\_CANopen\_NMT • 373  
 C3\_CANopen\_SDO\_Read4 • 374  
 C3\_CANopen\_SDO\_Write4 • 375  
 C3\_CANopen\_State • 369  
 C3\_Input • 302  
 C3\_IOAddition\_0 • 303  
 C3\_IOAddition\_1 • 303  
 C3\_IOAddition\_2 • 304  
 C3\_Jog • 189  
 C3\_MasterConfig • 242  
 C3\_MasterControl • 236  
 C3\_Output • 302  
 C3\_OutputSelect • 290  
 C3\_ReadArray • 172  
 C3\_SetControlMode • 169  
 C3\_SetErrorReaction • 301  
 C3\_SetMaster • 235  
 C3\_ShiftPosition • 200  
 C3\_TouchProbe • 305  
 C3HydraulicsManager • 44  
 C3Plus.AnalogInput0\_FilterCoefficient • 119  
 C3Plus.AnalogInput0\_Offset\_normed • 118  
 C3Plus.AnalogInput1\_FilterCoefficient • 119  
 C3Plus.AnalogInput1\_Offset\_normed • 119  
 C3Plus.AnalogInput2\_FilterCoefficient • 120  
 C3Plus.AnalogInput2\_Offset\_normed • 120  
 C3Plus.AnalogInput3\_FilterCoefficient • 121  
 C3Plus.AnalogInput3\_Offset\_normed • 120  
 C3Plus.AnalogInput4\_FilterCoefficient • 122  
 C3Plus.AnalogInput4\_Offset\_normed • 121  
 C3Plus.AnalogInput5\_FilterCoefficient • 122  
 C3Plus.AnalogInput5\_Offset\_normed • 122  
 C3Plus.DeadBandCompensation\_Ch0\_A\_Side • 136  
 C3Plus.DeadBandCompensation\_Ch0\_B\_Side • 136  
 C3Plus.DeadBandCompensation\_Ch0\_Threshold • 137  
 C3Plus.DeadBandCompensation\_Ch0\_Type • 136  
 C3Plus.DirectionDependentGain\_Ch0\_Factor\_negative • 134

- C3Plus.DirectionDependentGain\_Ch0\_Factor\_positive • 133
- C3Plus.DirectionDependentGain\_Ch0\_InvertType • 135
- C3Plus.OutputConditioningChain\_Ch0\_Input\_DefaultValue • 133
- C3Plus.OutputConditioningChain\_Ch0\_LowerLimit • 132
- C3Plus.OutputConditioningChain\_Ch0\_Output\_Offset • 133
- C3Plus.OutputConditioningChain\_Ch0\_UpperLimit • 132
- C3Plus.PositionController\_2\_InsideWindow\_IPart • 114
- C3Plus.PositionController\_2\_Ki\_IPart • 113
- C3Plus.PositionController\_2\_Kp\_PPart • 113
- C3Plus.PositionController\_2\_NegLimit\_IPart • 115
- C3Plus.PositionController\_2\_OutsideWindow\_IPart • 114
- C3Plus.PositionController\_2\_PosLimit\_IPart • 114
- C3Plus.PositionController\_InsideWindow\_IPart • 110
- C3Plus.PositionController\_Ki\_IPart • 110
- C3Plus.PositionController\_Kp\_PPart • 110
- C3Plus.PositionController\_NegLimit\_IPart • 111
- C3Plus.PositionController\_OutsideWindow\_IPart • 110
- C3Plus.PositionController\_PosLimit\_IPart • 111
- C3Plus.PositionController\_TrackingErrorFilter • 109
- C3Plus.PositionController\_TrackingErrorFilter\_us • 109
- C3Plus.PressureCompensation\_Ch0\_Type • 135
- C3Plus.PressureController\_1\_ActuatingSignal\_Inversion • 126
- C3Plus.PressureController\_1\_Derivative\_Part\_KFd • 125
- C3Plus.PressureController\_1\_Force\_FeedForward\_KFs • 126
- C3Plus.PressureController\_1\_InsideWindow\_IPart • 124
- C3Plus.PressureController\_1\_Integration\_Part\_KFi • 124
- C3Plus.PressureController\_1\_NegLimit\_IPart • 125
- C3Plus.PressureController\_1\_OutsideWindow\_IPart • 124
- C3Plus.PressureController\_1\_PosLimit\_IPart • 125
- C3Plus.PressureController\_1\_Proportional\_Part\_Kp • 124
- C3Plus.PressureController\_1\_Speed\_Feedback\_KFv • 126
- C3Plus.PressureController\_2\_ActuatingSignal\_Inversion • 130
- C3Plus.PressureController\_2\_Derivative\_Part\_KFd • 129
- C3Plus.PressureController\_2\_Force\_FeedForward\_KFs • 130
- C3Plus.PressureController\_2\_InsideWindow\_IPart • 128
- C3Plus.PressureController\_2\_Integration\_Part\_KFi • 128
- C3Plus.PressureController\_2\_NegLimit\_IPart • 129
- C3Plus.PressureController\_2\_OutsideWindow\_IPart • 128
- C3Plus.PressureController\_2\_PosLimit\_IPart • 129
- C3Plus.PressureController\_2\_Proportional\_Part\_Kp • 128
- C3Plus.PressureController\_2\_Speed\_Feedback\_KFv • 130
- C3Plus.SignalFlowCharacteristic\_Ch0\_Type • 135
- Cable for path measurement systems • 431
- Calling up the HEDA wizard in the C3 ServoManager • 394
- Calling up the input simulation • 147
- Cam applications • 263
- Cam Control • 206
- Cam function structure • 223
- Cam functions of the Compax3 ServoManager / motion laws • 219
- Cam operation with STOP or Error • 238, 241
- Cam parameters / terms • 211
- Cam reference systems • 228
- Cam switching mechanism • 287
- Cam switching mechanism function overview • 287
- Cam types • 210
- CAN - plug BUS10/01 • 451
- CAN communication objects overview sorted according to CAN No. • 378
- CANopen - configuration • 366
- CANopen - Node Settings • 366
- CANopen communication profile • 376
- CANopen connector X23 Interface I21 • 33
- CANopen Operating Mode • 366
- CANopen states • 369
- Change assignment direction reversal / limit switches • 74
- Change initiator logic • 74
- Change-over (CouplingMode = 2) • 253
- Check connection assignment of the pressure sensors • 141
- Check input offset or zero of the pressure sensors • 141
- Check sense of direction • 141
- Checking the feedback direction and the valve output polarity • 98
- Checking the open loop gain • 101
- CiA405\_SDO\_Error (Abort Code) UDINT • 382
- Close control loop • 143
- Closed curve • 210
- CN Controlled Node (Slave) • 387
- CoDeSys / Compax3 target system (Target Package) • 153

CoDeSys-Project for the configuration of the cams • 296

COM port protocol • 344

Communication • 332

Communication objects • 377, 380

Compax3 communication variants • 332

Compax3 - Objects • 413

Compax3 Accessories • 431

Compax3F device description • 21

Compax3F structure image • 45

Compensation of non-linearities of the distance • 99

Compilation, debugging and down/upload of IEC61131 programs • 159

Conditioning Chain Symbols • 132

Conditions of utilization for CE-conform operation • 15

Configuration • 41

Configuration name / comments • 81

Configuration of local modem 1 • 350

Configuration of remote modem 2 • 351

Configuration of the HEDA communication • 394

Configuration of the process-data channel • 354

Configuring drive1 • 47

Configuring drive2 • 49

Configuring Ethernet Powerlink / EtherCAT • 387

Configuring the device • 98

Configuring the signal source • 82

Conformance • 384

Connection of the digital Outputs/Inputs • 30

Connections of the encoder interface • 29, 31

Continuous positioning (MC\_MoveVelocity) • 187

Control and status word • 355

Control functions • 165

Control Loop Dynamics • 97

Control of the cam generator (C3\_CamTableSelect) • 239

Controller optimization • 102

Controller structure of main axis • 105

Controller structure auxiliary axis • 106

Coupling and decoupling • 208

Coupling objects • 411

Coupling position (ME) • 211

Cycle time • 158

Cyclic data channel for C3T30 and C3T40 • 316

Cyclic process data channel • 355

Cylinder / motor selection • 48

**D**

D/A-Monitor • 426

Data formats of the bus objects • 362, 383, 386

Data transfer from Slave to Slave. • 406

Data transfer Master – Slave and back • 395

Data types supported • 157

Debouncing

- Limit switch, machine zero and input 0 • 74

Decoupling position (MA) • 211

Decoupling with change-over function (CouplingMode = 2) • 259

Defining the reference system • 53

Definitions • 394

Description of jerk • 182

Description of the cam wizard • 220

Detailed object list • 425

Determine valve/range parameters (C3\_GetSystemFingerPrint) • 174

Device assignment Compax3 Fluid • 12

DeviceNet • 384

DeviceNet Configuration • 384

DeviceNet connector X23 • 35

DeviceNet object classes • 385

Digital Inputs/Outputs • 30

Digital inputs/outputs (plug X12) • 29

Direct coupling (CouplingMode = 0) • 252

Direct decoupling (CouplingMode = 0) • 257

Direction dependent gain • 142

Drive configuration • 46

Dynamic positioning • 197

Dynamic switching

- Position- on force/pressure - adjustment • 203

## E

EAM06

- Terminal block for inputs and outputs • 436

Electronic gearbox (MC\_GearIn) • 194

Encoder A/B 5V, step/direction or SSI feedback as signal source • 82

Encoder cable • 432

Encoder coupling of 2 Compax3 axes • 444

Encoder Simulation • 79

Error handling • 299

Error reaction to a bus failure • 355, 367, 384, 387, 390, 394

Error response • 80

Error: • 427

Ethernet Powerlink • 387

Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24 • 36

ETHERNET-RS485 NetCOM 113 adapter • 337

Example

- C3 powerPLmC Program & Compax3 Program • 318
- Changing the stiffness • 358
- Communication Master – Slave and back • 402
- Compax3 as CANopen Master with PIOs • 311
- Electronic gearbox with position detection via encoder • 83
- Setting the Oscilloscope • 95
- switching behavior at negative speed (speed<0) • 293
- switching behavior at positive speed (speed>0) • 293
- Working with fast cams • 297

Example 1

- Communication Master - Slave and Slave - Slave. • 407
- Single start of a closed cam • 263

Example 2

- 4-axis application with HEDA • 410
- Change between single start of an open cam and POSA • 266
- Example 3
  - Single Start for run through curve 5 times • 268
- Example 4
  - Composing curves • 270
- Example 5
  - Cyclic operation with event-triggered change of curve • 273
- Example 6
  - Operation with curve segments and standstill area • 275
- Example 7
  - Curve operation with slave reg synchronization • 278
- Example 8
  - Curve operation with master reg synchronization • 280
- Example case of damage • 283
- Example in CFC
  - Cycle mode • 325
  - Positioning 1 • 322
  - Positioning 2 • 323
  - Positioning with set selection • 324
  - Using Compax3-specific function modules and Compax3 objects • 321
- Example in ST
  - Cycle mode with a Move module • 326
- Example of cam function • 288
- Examples in the help file • 181
- Examples of a cam cycle • 288
- Exiting the active curve with coupling movement (C3\_CamOut) • 256

**F**

- Feedback (connector X13) • 30
- Feedback cable (Balluff) • 433
- Feedback cable EnDat2.1 • 434
- Feedforward auxiliary axis (status controller) • 108
- Feedforward main axis (status controller) • 107
- Feedforwards (advanced) • 144
- Filter • 142
- Filter alignment • 101
- Filter auxiliary axis • 117
- Filter main axis • 116
- Fixed point format C4\_3 • 363
- Fixed point format E2\_6 • 362
- Following error limit • 78
- Force feedforward • 146
- Force sensor drive 1 • 50
- Force window - force achieved • 75
- Force-/Pressure Control auxiliary axis • 127
- Force-/Pressure Control main axis • 123
- Function description • 44
- Function modules of the cam • 223
- Function of the Bus LEDs • 32, 34, 36
- Function principle • 208
- Function range supported • 154
- Functionality • 148

**G**

- General • 138
- General hazards • 14
- General rules / timing • 160
- Generating cams • 213
- GSD - File • 458

**H**

- Hardware end limits • 73
- HEDA (motion bus) - Option M11 • 447
- HEDA Bus • 389
- HEDA expansion (HEDA advanced) • 392
- HEDA Master signal source • 85
- HEDA standard mode • 390
- HEDA-Master • 391
- HEDA-Slave • 391
- Homing (MC\_Home) • 191
- Homing modes with home switch (on X12/14) • 58
- Hydraulic corner power limitation • 76
- HydraulicsManager • 44
- Hysteresis • 295

**I**

- I/O interface X12 / X22 • 442
- Identity Object (0x1018) • 380
- Identity Object (0x1018) • 380
- IEC examples • 321
- Important notes • 176
- Initializing the PIOs (PIO\_Init) • 308
- Input simulation • 147
- Input wiring of digital inputs • 447
- Input/output option M12 • 446
- Integer formats • 362
- Integration of Parker I/Os (PIOs) • 308
- Integrator KI • 144
- Interface Cables • 439
- Interface module • 314
- Interface to C3 powerPLmC • 313
- Internal virtual master • 85
- Introduction • 12
  - Electronic cam control • 207
- Introduction to the CamDesigner (example) • 214

**J**

- Jerk value • 182

**L**

- Languages supported • 154
- Level • 30
- Library constants • 161
- Limit and monitoring settings of force • 75
- Limit valve set value • 140
- Load configuration drive1 • 48

**M**

- Machine Zero • 54
- Machine zero modes overview • 56
- Machine zero modes without home switch • 65

- Machine zero only from motor reference • 67
  - Machine zero speed and acceleration • 55
  - Manual operation (C3\_Jog) • 189
  - Mark synchronization • 209
  - Master clock distance (MT) • 211
  - master oriented reg synchronization • 280
  - Master Receive Mapping Table (max. 4) • 400
  - Master receive slots • 399
  - Master signal phase shift (MC\_Phasing) • 243
  - Master signal source • 234
  - Master transmission slots (Transmit Slots) • 398
  - Master Transmit Mapping Table (max. 4) • 399
  - Maximum control deviation of force controller • 76
  - Maximum force • 76
  - Maximum permissible speed • 78
  - Maximum program size • 158
  - MC\_CamIn • 246
  - MC\_Home • 191
  - MC\_MoveAbsolute • 179
  - MC\_MoveAdditive • 185
  - MC\_MoveRelative • 183
  - MC\_MoveSuperImposed • 198
  - MC\_MoveVelocity • 187
  - MC\_Phasing • 243
  - MC\_Power • 165
  - MC\_ReadActualPosition • 170
  - MC\_ReadAxisError • 300
  - MC\_ReadStatus • 173
  - MC\_Reset • 299
  - MC\_Stop • 166
    - Example 1 • 167
    - Example 2 • 168
  - MC\_Stop at pressure/force control • 167
  - Meaning of the Bus LEDs (EtherCAT) • 38
  - Meaning of the Bus LEDs (Ethernet Powerlink) • 37
  - Meaning of the front panel LEDs (via X10) • 21
  - Memorizing the signals with the trigger event (C3\_TouchProbe) • 305
  - MN-M 1, 2
    - Limit switch as machine zero • 68
  - MN-M 11...14
    - With direction reversal switches on the negative side • 64
  - MN-M 128/129
    - Following error threshold when moving to block • 65
  - MN-M 130, 131
    - Determine absolute position via distance coding • 67
  - MN-M 132, 133
    - Determine absolute position via distance coding with direction reversal switches • 69
  - MN-M 17.18
    - Limit switch as machine zero • 66
  - MN-M 19.20
    - MN-Initiator = 1 on the positive side • 58
  - MN-M 21.22
    - MN initiator = 1 on the negative side • 59
  - MN-M 23...26
    - Direction reversal switches on the positive side • 60
  - MN-M 27...30
    - With direction reversal switches on the negative side • 61
  - MN-M 3.4
    - MN-Initiator = 1 on the positive side • 62
  - MN-M 33,34
    - MN at motor zero point • 67
  - MN-M 35
    - MN at the current position • 65
  - MN-M 5.6
    - MN initiator = 1 on the negative side • 63
  - MN-M 7...10
    - Direction reversal switches on the positive side • 64
  - Mode 1
    - Time and maximum values are deduced from Compax3 input values • 151
  - Mode 2
    - Compax3 input values are deduced from times and maximum values • 151
  - Modem cable SSK31 • 445
  - Modem Westermo TD-36 485 • 339
  - Monitor information • 89
  - Motion control • 152
  - Motion laws: • 222
  - Motion objects in Compax3 • 150
  - Motion set • 150
  - Mounting and dimensions • 40
  - Move drive controlledly • 140
- ## N
- Note
    - No switching operation with overlapping cams • 295
- ## O
- Object 172.11
    - IN0 Offset • 118
  - Object 172.3
    - IN0 Filter • 119
  - Object 172.4
    - IN0 Offset • 118
  - Object 173.11
    - IN1 Offset • 119
  - Object 173.3
    - IN1 Filter • 119
  - Object 173.4
    - IN1 Offset • 119
  - Object 174.11
    - IN2 Offset • 120
  - Object 174.3
    - IN2 Filter • 120
  - Object 174.4
    - IN2 Offset • 120
  - Object 175.11
    - IN3 Offset • 120
  - Object 175.3
    - IN3 Filter • 121
  - Object 175.4
    - IN3 Offset • 121

- Object 176.11
  - IN4 Offset • 121
- Object 176.3
  - IN4 Filter • 122
- Object 176.4
  - IN4 Offset • 121
- Object 177.11
  - IN5 Offset • 122
- Object 177.3
  - IN5 Filter • 122
- Object 177.4
  - IN5 Offset • 122
- Object 2010.23
  - Speed • 107
- Object 2010.24
  - Acceleration • 107
- Object 2050.10
  - Acceleration • 108
- Object 2050.9
  - Speed • 108
- Object 2100.10
  - Filter 2 actual speed • 116
- Object 2100.11
  - Filter 2 actual accel • 116
- Object 2100.13
  - Speed feedback • 111
- Object 2100.14
  - Acceleration feedback • 112
- Object 2101.13
  - Speed feedback • 115
- Object 2101.14
  - Acceleration feedback • 115
- Object 2101.7
  - Filter 2 actual speed • 117
- Object 2101.8
  - Filter 2 actual accel • 117
- Object 2200.11
  - Filter - Following Error • 109
- Object 2200.24
  - Filter - Following Error • 109
- Object 2200.30
  - Internal window I-term • 110
- Object 2200.31
  - External window I-term • 110
- Object 2200.32
  - Positive limit I-term • 111
- Object 2200.33
  - Negative limit I-term • 111
- Object 2200.37
  - I-term • 110
- Object 2200.38
  - P-term • 110
- Object 2210.8
  - Filter control signal • 112
- Object 2250.13
  - P-term • 124
- Object 2250.14
  - I-term • 124
- Object 2250.15
  - Internal window I-term • 124
- Object 2250.16
  - External window I-term • 124
- Object 2250.17
  - Positive limit I-term • 125
- Object 2250.18
  - Negative limit I-term • 125
- Object 2250.19
  - D-term • 125
- Object 2250.20
  - Speed feedback • 126
- Object 2250.22
  - Filter control signal • 126
- Object 2250.23
  - Force feedforward • 126
- Object 2250.24
  - Inversion of the control variable [on/off] • 126
- Object 2250.8
  - Delay T1 • 125
- Object 2251.13
  - P-term • 128
- Object 2251.14
  - I-term • 128
- Object 2251.15
  - Internal window I-term • 128
- Object 2251.16
  - External window I-term • 128
- Object 2251.17
  - Positive limit I-term • 129
- Object 2251.18
  - Negative limit I-term • 129
- Object 2251.19
  - D-term • 129
- Object 2251.20
  - Speed feedback • 130
- Object 2251.22
  - Filter control signal • 130
- Object 2251.23
  - Force feedforward • 130
- Object 2251.24
  - Inversion of the control variable [on/off] • 130
- Object 2251.8
  - Delay T1 • 129
- Object 2260.14
  - Internal window I-term • 114
- Object 2260.15
  - External window I-term • 114
- Object 2260.16
  - Positive limit I-term • 114
- Object 2260.17
  - Negative limit I-term • 115
- Object 2260.21
  - I-term • 113
- Object 2260.22
  - P-term • 113
- Object 2260.8
  - Filter - Following Error • 113
- Object 2270.8
  - Filter control signal • 115
- Object 2400.3
  - Upper limit of ocontrol signal • 132
- Object 2400.4
  - Lower limit of the control signal • 132
- Object 2400.6
  - Output Offset • 133

Object 2400.7  
 Replacement value (inactive Chain 0) • 133

Object 2401.4  
 Gain factor positive • 133

Object 2401.5  
 Gain factor negative • 134

Object 2401.6  
 Inversion [on/off] • 135

Object 2401.7  
 Gain positive direction (Force-/Pressure-control) • 134

Object 2401.8  
 Gain negative direction (Force-/Pressure-control) • 134

Object 2402.1  
 Pressure Compensation [on/off] • 135

Object 2403.1  
 Characteristic flow [on/off] • 135

Object 2405.1  
 Deadband [on/off] • 136

Object 2405.2  
 Deadband A-side • 136

Object 2405.3  
 Deadband B-side • 136

Object 2405.4  
 Deadband threshold value • 137

Object classes • 386

Object overview sorted by object name (T40) • 416

Object types • 377

Object up-/download via RS232 / RS485 • 383

Objects for the process data channel • 414

Objects of the cam switching mechanism • 291

Open curve • 210

Operator control module BDM • 435

Operators supported • 154

Optimization • 87

Optimization of position controller • 142

Optimization of pressure/Force Controller • 145

Optimization window • 88

Option M10 = HEDA (M11) & I/Os (M12) • 449

Options M1x • 446

Order and response processing • 357

Order code • 428

Order code device  
 Compax3 Fluid • 428

Oscilloscope operating mode switch: • 91

Output signal conditioning 0 • 131

Output wiring of digital outputs • 447

Overview • 209

Overview of the DeviceNet object classes • 386

## P

Parameter access with DPV0  
 Required data channel • 356

Parameters for manual movement/jogging mode and test movement. • 139

PC <-> C3M device combination (USB) • 335

PC <-> Compax3 (RS232) • 333

PC <-> Compax3 (RS485) • 334

Physical Source • 82

PIO  
 Inputs/Outputs • 452

PIO\_Init • 308

PIO\_Inputx...y • 309

PIO\_Outputx...y • 310

PKW parameter channel • 355

Plug and connector assignment • 22

Plug and connector assignment Compax3 Fluid • 21

Plug and connector assignment complete • 23

Plug assignment Compax3S0xx V2 • 27

Position controller auxiliary axis (status controller) • 113

Position controller main axis (status controller) • 109

Position feedback system drive1 • 47

Position mode in reset operation • 181

Position transducer • 53

Positioning after homing run • 54

Positioning functions (standard) • 178

Positioning window - Position reached • 77

Positioning with IEC61131-3 • 17

Possible PDO assignment • 368, 388

Preparatory settings for the controller alignment • 98

Prerequisites • 152

Pressure and force sensor drive 2 • 51

Pressure sensors • 49

Procedure • 139

Procedure when working with the C3\_getSystemFingerPrint • 177

Process image • 302

Profibus • 353  
 Emulating the ProfiDrive profile (C3F\_ProfiDrive\_Statemachine) • 328

Profibus configuration • 353

Profibus connector X23 with Interface I20 • 32

Profibus plug BUS08/01 • 450

ProfileViewer for the optimization of the motion profile • 150

Program development and test • 153

Programming based on IEC61131-3 • 152

Proportional factor KP • 143

## Q

Quadratic coupling (CouplingMode = 1) • 250

Quadratic decoupling (CouplingMode = 1) • 258

## R

Ramp upon error and switch to currentless • 74

Read access to the (C3\_ReadArray) array • 172

Reading an object in another node (C3\_CANopen\_SDO\_Read4) • 374

Reading axis errors (MC\_ReadAxisError) • 300

Reading digital inputs (C3\_Input) • 302

Reading the current position (MC\_ReadActualPosition) • 170

Reading the device status (MC\_ReadStatus) • 173



- Reading the PIO inputs 0-15 (PIO\_Inputx...y) • 309
- Reading values • 170
- Reading/writing optional inputs/outputs • 303
- Recipe management • 154
- Recipe table • 80
- Recipe table with 9 columns and 32 lines • 157
- Recommendations for preparing the modem operation • 352
- Recording the position of the selected master source (C3\_MasterControl) • 236
- Redirect the fast cams directly to the physical output (C3\_OutputSelect) • 290
- Ref X11 • 443
- Relative master reference with 180° offset • 229
- Relative master reference without offset • 228
- Relative positioning (MC\_MoveRelative) • 183
- Relative slave reference • 231
- Relative slave reference example 1 • 232
- Relative slave reference example 2 • 233
- Remote diagnosis via Modem • 349
- Retain Variables • 157
- RS232 / RS485 interface (plug X10) • 27
- RS232 cable • 440
- RS232 plug assignment • 27
- RS485 cable to Pop • 441
- RS485 plug assignment • 27
- RS485 setting values • 344
- S**
- Safety Instructions • 14
- Safety-conscious working • 14
- Scope • 89
- Selection and configuration of the valves • 52
- Sensors • 49
- Service Data Objects (SDO) • 381
- Set control parameters • 143
- Set error reaction (C3\_SetErrorReaction) • 301
- Set Ethernet Powerlink (option I30) bus address • 37
- Set filter for speed- and acceleration actual value. • 142
- Set position (only analog feedback) • 142
- Set valve offset • 141
- Setting the HEDA master • 397
- Setting the HEDA slave • 400
- Setting the position of the selected master source (C3\_SetMaster) • 235
- Setting the positioning mode in reset mode • 181
- Setting the time basis XDIV • 91
- Setting up Compax3 • 41
- Settings for channels 1..4 • 92
- Setup mode • 149
- Signal filtering for external setpoint specification and electronic cam • 104
- Signal filtering for external setpoint specification and electronic gearbox • 103
- Signal filtering with external command value • 102
- Signal image • 224
- Signal image with absolute master reference • 225
- Signal image with relative master reference • 226
- Simatic S7 -300/400 - modules • 365
- Slave clock distance (ST) • 211
- Slave Receive Mapping table • 401
- Slave receive slots • 401
- Slave transmission slots (Transmit Slots) • 401
- Slave Transmit Mapping table • 401
- Slave with configuration via master • 387
- Slave-oriented reg synchronization. • 278
- Software end limits • 70
- Special functions • 93
- Special safety instructions • 15
- Specifications • 453
- Speed control • 187
- Speed feedback • 144
- Speed feedforward (advanced) • 144
- SSI configuration • 84
- Standard function modules supported • 156
- Standard functions supported • 155
- Standstill position Slave (S0) • 212
- Start cam / coupling • 245
- Starting a selected curve (MC\_CamIn) • 246
- Starting a selected curve with coupling movement (C3\_CamIn) • 248
- State of delivery • 21
- Status diagram of Compax3F auxiliary axis • 163
- Status diagram of Compax3F main axis • 162
- Status diagram of the virtual master • 164
- Status diagrams • 162
- Status values • 426
- Step 1
  - C3 ServoManager • 260
- Step 10
  - Starting and monitoring cam • 262
- Step 2
  - Connect motor. • 260
- Step 3
  - Supply & I/O wiring • 260
- Step 4
  - RS232 connection & C3 ServoManager • 260
- Step 5
  - Set Compax3 device type • 261
- Step 6
  - Configuration • 261
- Step 7
  - Selecting Master signal source • 261
- Step 8
  - Generating the cam • 261
- Step 9
  - Create IEC program • 262
- Step-by-step optimization • 138
- Stop (MC\_Stop) • 166
- Structure • 349
- Structure of the databases • 44
- Superimposed motion • 197
- Superimposed positioning (MC\_MoveSuperImposed) • 198
- Supporting IEC modules • 368

**Switching**

- from force to position mode (C3\_pQ) • 204
- Switching behavior with reset operation • 294
- Switch-on anticipation is corrected via reset distance • 294
- Symbols of the signal image • 227
- Synchronous position (MS) • 211

**T**

- Technical data of the HEDA interface / overview • 393
- The possibilities of the HEDA expansion • 392
- Time grid of master signal source • 85
- Trackingfilter • 102
- Transmission cycle time • 368
- Travel Limit Settings • 70
- Trigger settings • 93
- Type specification plate Compax3 Fluid • 13
- Typical application with fieldbus and IEC61131 • 353

**U**

- Unsigned - Formats • 362
- Upload/download objects via the Profibus • 360
- Usage in accordance with intended purpose • 14
- USB - RS232 converter • 27
- USB-RS485 Moxa Uport 1130 adapter • 336
- User interface • 90

**V**

- Value range for positioning parameters • 178
- Valve configuration • 51
- Voltage supply (plug X3) • 27

**W**

- Warranty conditions • 15
- Wiring of analog outputs • 26
- Wiring of the analog inputs • 25
- With direction reversal switches • 60, 63, 68
- With motor reference point • 62, 67
- Without direction reversal switches • 58, 62
- Without motor reference point • 58, 65
- Write digital outputs (C3\_Output) • 302
- Writing an object in another node (C3\_CANopen\_SDO\_Write4) • 375
- Writing the PIO outputs 0-15 (PIO\_Outputx...y) • 310

**X**

- X10 • 27
- X12 • 29

**Z**

- ZBH plug set • 431
- Zero point shift caused by superimposed positioning (C3\_ShiftPosition) • 200

Autoryzowany dystrybutor Parker:

**ARA****PNEUMATIK**53-012 Wrocław tel. 71 364 72 82  
ul. Wyścigowa 38 fax 71 364 72 83[www.arapneumatik.pl](http://www.arapneumatik.pl)