

# Air line accessories


– Ball valves

## Ball valves without venting

Order Instructions		A	A1	B	C	D	E	Ø	SW1	SW2	p <sub>max</sub> (bar)
Type	Order No.	tap.									
KHM-18AI	KW0709	R1/8	G1/8	8	35.5	19	21	5.5	14	14	20
KHM-14AI	KW0708	R1/4	G1/4	11	38.0	19	21	5.5	14	14	20

Other sizes on request

Dimensions in mm



**ARA**<sup>®</sup>  
PNEUMATIK

53-012 Wrocław tel. 71 364 72 82  
ul. Wyscigowa 38 fax 71 364 72 83  
[www.arapneumatik.pl](http://www.arapneumatik.pl)

